

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
OMB NO. 1004-0135
Expires: November 30, 2000

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.

SUBMIT IN TRIPLICATE - Other instructions on reverse side

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

OXY USA WTP Limited Partnership

192463

3a. Address

P.O. Box 50250, Midland, TX 79710-0250

3b. Phone No. (include area code)

432-685-5717

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1450 FNL 660 FEL SENE(H) Sec 3 T17S R31E

5. Lease Serial No.

NMLC029426A

6. If Indian, Allottee or Tribe Name

7. If Unit or CA/Agreement, Name and/or No

8. Well Name and No.

OXY Pralines & #1
Cream Federal

9. API Well No.

30-015-32982

10. Field and Pool, or Exploratory Area

Fren Morrow

11. County or Parish, State

Eddy NM

JUL 26 2007

OCD-ARTESIA

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- | | | | |
|---|--|--|---|
| <input type="checkbox"/> Acidize | <input type="checkbox"/> Deepen | <input type="checkbox"/> Production (Start/Resume) | <input type="checkbox"/> Water Shut-Off |
| <input type="checkbox"/> Alter Casing | <input type="checkbox"/> Fracture Treat | <input type="checkbox"/> Reclamation | <input type="checkbox"/> Well Integrity |
| <input type="checkbox"/> Casing Repair | <input type="checkbox"/> New Construction | <input type="checkbox"/> Recomplete | <input type="checkbox"/> Other _____ |
| <input type="checkbox"/> Change Plans | <input checked="" type="checkbox"/> Plug and Abandon | <input type="checkbox"/> Temporarily Abandon | |
| <input type="checkbox"/> Convert to Injection | <input type="checkbox"/> Plug Back | <input type="checkbox"/> Water Disposal | |

13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleate horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleation in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the final site is ready for final inspection.)

TD-12250' PBD-12156' Perfs-11968-11978'
13-3/8" 48# csg @ 694' w/ 715sx, 17-1/2" hole, TOC-Surf-Circ
9-5/8" 36# csg @ 4500' w/ 1200sx, 12-1/4" hole, TOC-Surf-Circ
5-1/2" 17# csg @ 12250' w/ 1300sx, 8-3/4" hole, TOC-7450'-CBL

1. RIH & Set CIBP @ 11915', dump 7sx cmt to 11965'
2. M&P 25sx cmt @ 11000-10900'
3. M&P 25sx cmt @ 8550-8450'
4. Cut & Pull 5-1/2" csg @ +/- 7400'
5. M&P 45sx cmt @ 7450-7350' WOC-Tag
6. M&P 65sx cmt @ 6000-5900'
7. M&P 65sx cmt @ 4550-4450' WOC-Tag
8. M&P 50sx cmt @ 2850-2750'
9. M&P 45sx cmt @ 1900-1800'
10. M&P 45sx cmt @ 744-644' WOC-Tag
11. M&P 25sx cmt surface plug
10# MLF between plugs

Accepted for record
NMOCD

SEE ATTACHED FOR
CONDITIONS OF APPROVAL

14. I hereby certify that the foregoing is true and correct
Name (Printed/Typed)

David Stewart

Title

Sr. Regulatory Analyst

Date

7/10/07

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by

Title

Date

Office

JUL 23 2007

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Title 18 U.S.C. Section 1001, and Title 43 U.S.C. Section 1212, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

PETROLEUM ENGINEER

OXY USA WTP LP - Proposed
OXY Pralines & Cream Federal #1
API No. 30-015-32982

25sx Surface

45sx @ 744-644' WOC-Tag

45sx @ 1900-1800'

50sx @ 2850-2750'

65sx @ 4550-4450' WOC-Tag


65sx @ 6000-5900'

45sx @ 7450-7350' WOC-Tag

25sx @ 8550-8450'



25sx @ 1000-10900'

CIBP @ 11915', dump 7sx



17-1/2" hole @ 694'
13-3/8" csg @ 694'
w/715sx-TOC-Surf-Circ

12-1/4" hole @ 4500'
9-5/8" csg @ 4500'
w/1200sx-TOC-Surf-Circ



Cut & Pull 5-1/2" csg @ +/-7400'

Accepted for record
NMOCD

8-3/4" hole @ 12250'
5-1/2" csg @ 12250'
w/1300sx-TOC-7450'-CBL

Perfs @ 11968-11978'

TD-12250'

**OXY Pralines and Cream Federal #1
OXY USA WTP Limited Partnership**

July 23, 2007


**Plug and Abandonment
Conditions of Approval**

1. Cement top will be 11865'.
2. Plug should be 210' in length. May require additional cement. Strawn formation.
3. Plug should be set at 8580' and should be 190' in length. Wolfcamp formation.
4. Ok.
5. Extend plug to cover the top of the Abo at 7190'. Top of plug to be at a minimum depth of 7150'. Additional cement required. Tag plug.
 - a. Separate 170' plug could be set for top of Abo. Plug will have to be tagged, since it is in open hole.
6. Plug to be 160' in length. Top of plug should be 5900' or shallower Paddock formation. Tag plug.
 - a. Plug required at top of Glorietta. Plug to be 150' in length and should be placed from 5050-5150'. Plug to be tagged and should be tagged at 5150' or shallower. Approximately 65 sacks.
7. Ok
8. Plug to be set at 2940'. Queen formation.
9. Base of Salt/top of Yates plug. Set plug at 2020'. Tag plug at 1763' or shallower.
10. Extend plug to cover top of Salt. Plug to be set at 900' and be tagged at 644' or shallower.
11. Ok
12. Install dry hole marker and clean location.

WWI 072307

**Accepted for record
NMOCD**

OXY USA WTP LP - Current
OXY Pralines & Cream Federal #1
API No. 30-015-32982



17-1/2" hole @ 694'
13-3/8" csg @ 694'
w/715sx-TOC-Surf-Circ

12-1/4" hole @ 4500'
9-5/8" csg @ 4500'
w/1200sx-TOC-Surf-Circ

Accepted for record
NMOCD

8-3/4" hole @ 12250'
5-1/2" csg @ 12250'
w/1300sx-TOC-7450'-CBL

Perfs @ 11968-11978'

TD-12250'

**BUREAU OF LAND MANAGEMENT
Carlsbad Field Office
620 East Greene Street
Carlsbad, New Mexico 88220
505-234-5972**

**Permanent Abandonment of Federal Wells
Conditions of Approval**

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within ninety (90) days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90th day provide this office, prior to the 90th day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

2. Notification: Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 505-627-0272; Eddy County, call 505-361-2822; Lea County, call 505-393-3612.

3. Blowout Preventers: A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.

4. Mud Requirement: Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of water. Minimum nine (9) pounds per gallon.

5. Cement Requirement: Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. In lieu of a cement plug in a cased hole, a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient.

Unless otherwise specified in the approved procedure, the cement plug shall consist of either class "C", for up to 7,500 feet of depth, mixed at 14.8 lbs/gal with 6.3 gallons of fresh water per sack or class "H", for deeper than 7,500 feet plugs, mixed at 16.4 lbs/gal with 4.3 gallons of fresh water per sack.

6. Dry Hole Marker: All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement. The following information shall be permanently inscribed on the dry hole marker: well name and number, name of the operator, lease serial number, surveyed location (quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer such as metes and bounds).

7. Subsequent Plugging Reporting: Within 30 days after plugging work is completed, file one original and five copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. **Show date well was plugged.**

8. Trash: All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration conditions of approval will be developed and furnished to you.

**Accepted for record
NMOCD**



UNITED STATES DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

Carlsbad Field Office
620 E. Greene St.
Carlsbad, NM 88220

Interim Reclamation Procedures for Permanently Abandoned Federal Wells

1. After Subsequent Report of Abandonment, Form 3160-5, is filed and approved by the BLM the surface protection specialist (SPS) will conduct a surface inspection of the abandonment. The SPS will establish the reclamation requirements the operator will need to complete. **DO NOT START RECLAMATION UNTIL THE SPS HAS INSPECTED THE LOCATION.**

2. The reclamation requirements will be given to an environmental protection specialist (EPS). The EPS will issue the operator a Notice of Written Order outlining the reclamation requirements. **DO NOT START RECLAMATION UNTIL A NOTICE OF WRITTEN ORDER FOR RECLAMATION HAS BEEN RECEIVED.** The EPS will be responsible for all further abandonment work and inspections.

3. **Notification: CONTACT THE EPS 3 DAYS PRIOR TO RECLAMATION WORK.** This notification gives the EPS an opportunity to discuss by phone or on location the reclamation requirements, any special concerns and the timeframes. It also allows the EPS an opportunity to witness various aspects of the reclamation work to determine if an adequate seedbed has been prepared and all reclamation requirements have been completed. **CONTACT THE EPS AT LEAST 3 DAYS PRIOR TO SEEDING.** This allows the EPS to witness the seeding operation to make sure the location is seeded properly and with the appropriate seed mixture. **DO NOT START RECLAMATION UNTIL THE EPS HAS BEEN NOTIFIED.**

4. After reclamation work has been completed, submit the **I & E copy of the Notice of Written Order** to the BLM. It will need to be signed by a company representative and dated. Also submit one original and five copies of the **Final Abandonment Notice, Form 3160-5.** The report should state that all reclamation work has been completed, and the location is ready for a final abandonment inspection.

5. The BLM will continue to monitor the location to ensure the location vegetates successfully, and salts from the reserve pit do not leach to the surface. The location will be monitored until such time as vegetation (20%) is established evenly across the location (including the reserve pit and access road). Once EPS determines that vegetation (20%) is evenly spread across the location, final abandonment will be authorized.

If there are any questions please feel free to contact any of the following:

Jim Amos
Supervisory Environmental Protection Specialist
(505) 234-5909

Barry Hunt
Surface Protection Specialist
(505) 234-5965

Todd Suter
Surface Protection Specialist
(505) 234-5987

Trishia Bad Bear
Natural Resource Specialist – Lea County
(505) 393-3612

Cody Layton
Natural Resource Specialist
(505) 234-5959

Paul Evans
Environmental Protection Specialist
(505) 234-5977

Terry Gregston
Environmental Protection Specialist
(505) 234-5958

**Accepted for record
NMOCD**

10/18/2006