

Spud well w/ 17-1/2" hole @ 9:00 AM 9/4/2007 Drilled 17-1/2" hole to a depth of 354' Run 13-3/8" as follows:

1	Texas Pattern Shoe	1'
1 Jt	13-3/8" 61# J-55 BT&C	38'
1	Float Collar	2'
8 Jts	13-3/8" 61# J-55 BT&C	<u>316'</u>
		357'

Set casing @ 354'. Cement with 180 SXS Thixotropic cement + 10% A10 + 1% CaCl + .25 #/SX CF + 10 #/SX LCM-1 followed by 400 SXS Class "C" + 2% CaCl + 125# CF Plug down. Bumped plug, float did not hold. Did not circulate cement. SI w/ 100 PSIG WOC 6 HRS. Ran temp survey TOC @ 125' Ran 4 jts of 1" to 119' and tag TOC. Cement to surface with 178 SXS Class "C" Circulated 5 SXS to pit. Cut off conductor and 13-3/8" casing Weld on wellhead & test to 600 PSI OK Pick up, nipple up and test BOPE to 600 PSI. Held OK for 30 min. WOC total of 22 HRS TIH with bit and drill cement and float collar. Test casing to 600 PSI. Held OK for 30 min. Drill shoe and resume drilling 12-1/4" hole.

30-015-35679