

Submit 3 Copies To Appropriate District Office
District I
1625 N. French Dr , Hobbs, NM 88240
District II
1301 W. Grand Ave , Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505



DEC 26 2007
OCD-ARTESIA

Form C-103
Revised June 10, 2003

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS)		WELL API NO. 30-015-00176
1. Type of Well: Oil Well <input type="checkbox"/> Gas Well <input checked="" type="checkbox"/> Other— <u>Water Injection Well</u>		5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
2. Name of Operator Devon Energy Production Company, LP		6. State Oil & Gas Lease No.
3. Address of Operator 20 North Broadway, Suite 1500, Oklahoma City, Oklahoma 73102		7. Lease Name or Unit Agreement Name Atoka San Andres Unit
4. Well Location Unit Letter <u>J</u> : 1645' feet from the <u>South</u> line and <u>2310'</u> feet from the <u>East</u> line Section <u>11</u> Township <u>18S</u> Range <u>26E</u> Eddy County		8. Well Number 113
	11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3316' GL; 3322' KB	9. OGRID Number 6137
		10. Pool name or Wildcat Atoka San Andres

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	MULTIPLE COMPLETION <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

1. MIRU PA rig on 12/2/07. POOH w/ 2-3/8" IPC tubing. Dump bail 35' cement on top of existing CIBP at 1,576'.
2. Circulate wellbore with 9.5 ppg salt gel mud.
3. Spot 25 Sx cement in 5-1/2" casing plug at 1,275'. Tagged TOC @ 1,046'. (8-5/8" casing shoe at 1,225')
4. Spot 60' surface plug.
5. Cut wellhead off 3' below ground level, set P&A marker, clean location.
6. Wellbore plugged & abandoned – 12/20/07.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Ronnie Slack TITLE: Engineering Technician DATE 12/20/07

Type or print name Ronnie Slack E-mail address: Ronnie.Slack@dvn.com Telephone No. 405-552-4615

(This space for State use)

APPROVED BY [Signature] TITLE Compliance Officer DATE 1/7/2008
Conditions of approval, if any:

Approved for plugging of well bore only.
Liability under bond is retained pending receipt of C-103 (Subsequent Report of Well Plugging) which may be found at OCD Web Page under forms. www.emnrd.state.us/ocd

DEC 26 2007

OOD-ARTESIA

S


DEVON ENERGY PRODUCTION COMPANY LP

Well Name: ATOKA SAN ANDRES UNIT #113		Field: ATOKA SAN ANDRES	
Location: 1645' FSL & 2310' FEL; SEC 11-T18S-R26E		County: EDDY	State: NM
Elevation: 3316' GL; 3322' KB		Spud Date: 8/17/56	Compl Date: 9/3/56
API#: 30-015-00176	Prepared by: Ronnie Slack	Date: 12/20/07	Rev:

PLUGGED & ABANDONED
12/20/07

Plug & Abandonment

1. Spot 60' surface plug.
2. Cut wellhead off, set dry hole marker, clean location.
3. Wellbore plugged - 12/20/07



9.5# mud

9.5# mud

11" Hole
8-5/8", 29#, @ 1,225'
 Cmt'd w/700 Sx. TOC at surface

Plug & Abandonment

1. Spot 25 Sx cement at 1,275'.
2. Tagged TOC @ 1,046'.

SAN ANDRES
 1,654' - 1,672 (4 spf)

Plug & Abandonment

1. Dump 35' cement on existing CIBP at 1,576'.
2. Circulate wellbore w/9.5# salt gel mud

CIBP @ 1,576' (3/18/82)

7-7/8" Hole
5-1/2", 15#, @ 1,797'
 Cmt'd w/350 Sx. TOC at surface

1,788' PBD

1,797' TD