Form 3160-5 (August 2007)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

OCD-ARTESIA BECEIVED	
----------------------	--

FORM APPROVED OMB No 1004-0137 Expires July 31, 2010


SUNDRY NOTICES AND REPORTS ON WELLS

5 Lease Serial No


	n for proposals to drill or to re-el e Form 3160-3 (APD) for such pro		JAN -5 2010	6 If Indian, Allottee of	or Tribe Name		
		NN NN	OCD ARTE	NA			
SUBMIT IN TRIPLIC	CATE - Other instruction	ons on page	2.	7 If Unit or CA/Agree	ement, Name and/or No		
1 Type of Well				NA	NM 7.2629 pu		
X Oil Well Gas We	Il Other		*	8 Well Name and No			
2 Name of Operator					Eland AFC Federal Com #1		
Yates Petroleum Corporation					9 API Well No		
3a Address 3b Phone No (include area code)				30-015-25978			
105 S. 4th Str., Artesia, NM 8821	575-748-1471		10 Field and Pool or Exploratory Area				
4 Location of Well (Footage, Sec ,T ,R.,M., OR			Burton Flat; Strawn, East				
330'FSL & 1650'FWL of Section 12-T20S-R29E (Unit N, SESW)				11 County or Pansh, State			
736'FNL & 526'FWL of Section 13	Eddy County, New Mexico						
12. CHECK APPROPRIA'	TE BOX(ES) TO INDICA	TE NATURE	OF NOTICE, RE	PORT, OR OTH	IER DATA		
TYPE OF SUBMISSION		PE OF ACTION					
! [Acidize	Deepen	Production (S	Start/Resume)	Water Shut-Off		
X Notice of Intent	Alter Casing	Fracture Treat	Reclamation		Well Integrity		
		<u> </u>		Г			
Subsequent Report	Casing Repair	New Construction	Recomplete	L	Other		
	Change Plans X	Plug and Abandon	Temporarily	Abandon			
Final Abandonment Notice	Convert to Injection	Plug Back	Water Dispos	sal			
NOTE: This is a directional well and to casing inspection log ran 11/4/08. Or at 3630'. This put cement behind the 1. MIRU WSU. NU BOP. RU all safe 2. Spot a 250' cement plug from 10,6'. 3. Spot a 200' cement plug from 9672 4. Spot a 450' cement plug from 3754 WOC and tag, reset if necessary. 5. Spot a 140' cement plug from 3324 6. Spot a 140' cement plug from 3168 7. Perforate 4 squeeze holes at 383'. across the surface casing shoe. W 8. Perforate 4 squeeze holes at 100'. the casing from 0-100'. This will lead 9. Remove all surface equipment and NOTE: Yates Petroleum Corporate 14 Thereby certify that the foregoing is true and Name (Printed/Typed)	n 6/7/89 a cementing squee 5-1/2" casing from +/-1550 ety equipment as needed. If 76'-10,926'. WOC and tag, reselv-4204'. Pull 15 stands and This will leave a plug across 1'-3464'. This will leave a plug-3308'. This will leave a plug-3308'. This will leave a plug-spot a 100' cement plug in Tie onto the casing and estave a plug from the surface weld dry hole marker per ston will use steel pits and total pits	eze job consist of down to the hole of the plug if neces of the plug if neces of the casing state of the casing of the	ing of 300 sx was hole at 3630', making of 300', making very will be attempore. This will set ecessary. This will pump 5 bbls to so ub. Delaware top. Intermediate cash de the said from the said from the cash at and tag plug, reserved.	pumped through ing it impossible pted. a plug over exist a plug over exist gueeze the ceme of the ceme	a hole in the casing to pull parted casing. ting Strawn perfs. cross Wolfcamp top. ent into the openhale. If APPROVAL. It is will leave a plug g inside and outside		
Tina Huert	a		gulatory Complia	nec	-000		
Signature (June)	THIS SPACE FOR FEE	<u> </u>	cember 10, 2009	DEC	30 Kriston		
Approved by	THIS SPACE FOR FED			13	OF LAND MANAGEMENT SBAD FIELD OFFICE		
Approved by	proval of this paties does not were	Titl	e	BUREPAU CARL	SBAD FIELU UITA		
Conditions of approval, if any, are attached Applicant holds legal or equitable which would entitle the applicant to conduct operations.	title to those rights in the subjec		ce	L	-		

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States

any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction



4.55



Eland AFC Federal Com #1 30-015-25978 Yates Petroleum Corporation December 30, 2009 Conditions of Approval

- 1. OK MIRU
- 2. Need cement plug from 11,126'-10,826 so it covers all the Strawn perfs
- 3. OK Wolfcamp
 - a. Need 100' + 10% depth spacer plug set anywhere from 9220' to 6,672'. Must perf and sqz since no cmt is behind csg. Tag Plug.
 - b. Need 160' plug 50' \pm Bone Spring formation @ 6,170'. Must perf and squeeze since there is no cement behind csg. Tag Plug.
- 4. OK Csg stub
- 5. OK Delaware
- 6. OK Csg shoe
 - a. Need 115' plug to isolate the base of the salt formation @ 1,463'. Must perf and squeeze since there is no cement behind csg. Tag Plug
- 7. Perf and sqz @ 400' and set plug inside and outside csg all the way to surface since well is in High Cave/Karst. If cement does not circulate may have to 1" from surface.
- 8. Satisfied by step #7.
- 9. OK RDMO
- 10. See attached general plugging COA and reclamation procedures

MAK 123009

BUREAU OF LAND MANAGEMENT

Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

Permanent Abandonment of Federal Wells Conditions of Approval

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within <u>ninety (90)</u> days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90th day provide this office, prior to the 90th day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

The rig used for the plugging procedure cannot be released and moved off without the prior approval of the authorized officer. Failure to do so may result in enforcement action.

- 2. <u>Notification:</u> Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 575-627-0272; Eddy County, call 575-361-2822; Lea County, call 575-393-3612.
- 3. <u>Blowout Preventers</u>: A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.
- 4. <u>Mud Requirement:</u> Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of **brine** water. Minimum nine (9) pounds per gallon.
- 5. <u>Cement Requirement</u>: Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. In lieu of a cement plug in a cased hole, a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient. Any plug that requires a tag will have a minimum WOC time of 4 hours.

Unless otherwise specified in the approved procedure, the cement plug shall consist of either Neat Class "C", for up to 7,500 feet of depth or Neat Class "H", for deeper than 7,500 feet plugs.

- 6. <u>Dry Hole Marker</u>: All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). **The BLM is to be notified when the wellhead is cut off to verify that cement is to surface in the casing and all annuluses.** The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement. The following information shall be permanently inscribed on the dry hole marker: well name and number, name of the operator, lease serial number, surveyed location (quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer such as metes and bounds).
- 7. <u>Subsequent Plugging Reporting:</u> Within 30 days after plugging work is completed, file one original and five copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. **Show date well was plugged.**
- 8. <u>Trash:</u> All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration will be required. See attached reclamation procedure.

DHW 112309



United States Department of the Interior

BUREAU OF LAND MANAGEMENT

Carlsbad Field Office 620 E Greene St Carlsbad, New Mexico 88220-6292 www.blm.gov/nm



In Reply Refer To. 1310

Reclamation Objectives and Procedures

Reclamation Objective: Oil and gas development is one of many uses of the public lands and resources. While development may have a short- or long-term effect on the land, successful reclamation can ensure the effect is not permanent. During the life of the development, all disturbed areas not needed for active support of production operations should undergo "interim" reclamation in order to minimize the environmental impacts of development on other resources and uses. At final abandonment, well locations, production facilities, and access roads must undergo "final" reclamation so that the character and productivity of the land and water are restored.

The long-term objective of final reclamation is to set the course for eventual ecosystem restoration, including the restoration of the natural vegetation community, hydrology, and wildlife habitats. In most cases this means returning the land to a condition approximating or equal to that which existed prior to the disturbance. The final goal of reclamation is to restore the character of the land and water to its predisturbance condition. The operator is generally not responsible for achieving full ecological restoration of the site. Instead, the operator must achieve the short-term stability, visual, hydrological, and productivity objectives of the surface management agency and take steps necessary to ensure that long-term objectives will be reached through natural processes.

To achieve these objectives, remove any and all contaminants, scrap/trash, equipment, pipelines and powerlines. Strip and remove caliche, contour the location to blend with the surrounding landscape, redistribute the native soils, provide erosion control as needed, rip and seed as specified in the original APD COA. This will apply to well pads, facilities, and access roads. Barricade access road at the starting point. If reserve pits have not reclaimed due to salts or other contaminants, submit a plan for approval, as to how you propose to provide adequate restoration of the pit area.

- The Application for Permit to Drill or Reenter (APD, Form 3160-3), Surface Use Plan of
 Operations must include adequate measures for stabilization and reclamation of disturbed lands.
 Oil and Gas operators must plan for reclamation, both interim and final, up front in the APD
 process as per Onshore Oil and Gas Order No. 1.
- 2. For wells and/or access roads not having an approved plan, or an inadequate plan for surface reclamation (either interim or final reclamation), the operator must submit a proposal describing the procedures for reclamation. For interim reclamation, the appropriate time for submittal would be when filing the Well Completion or Recompletion Report and Log (Form 3160-4). For final reclamation, the appropriate time for submittal would be when filing the Notice of Intent, or the Subsequent Report of Abandonment, Sundry Notices and Reports on Wells (Form 3160-5). Interim reclamation is to be completed within 6 months of well completion, and final reclamation is to be completed within 6 months of well abandonment.
- 3. The operator must file a Subsequent Report Plug and Abandonment (Form 3160-5) following the plugging of a well.
- 4. Previous instruction had you waiting for a BLM specialist to inspect the location and provide you with reclamation requirements. If you have an approved Surface Use Plan of Operation and/or an approved Sundry Notice, you are free to proceed with reclamation as per approved APD. If you have issues or concerns, contact a BLM specialist to assist you. It would be in your interest to have a BLM specialist look at the location and access road prior to the removal of reclamation

- equipment to ensure that it meets BLM objectives. Upon conclusion submit a Form 3160-5, Subsequent Report of Reclamation. This will prompt a specialist to inspect the location to verify work was completed as per approved plans.
- 5. The approved Subsequent Report of Reclamation will be your notice that the native soils, contour and seedbed have been reestablished. If the BLM objectives have not been met the operator will be notified and corrective actions may be required.
- 6. It is the responsibility of the operator to monitor these locations and/or access roads until such time as the operator feels that the BLM objective has been met. If after two growing seasons the location and/or access roads are not showing the potential for successful revegetation, additional actions may be needed. When you feel the BLM objectives have been met submit a Final Abandonment Notice (FAN), Form 3160-5, stating that all reclamation requirements have been achieved and the location and/or access road is ready for a final abandonment inspection.
- 7. At this time the BLM specialist will inspect the location and/or access road. If the native soils and contour have been restored, and the revegetation is successful, the FAN will be approved, releasing the operator of any further liability of the location and/or access road. If the location and/or access road have not achieved the objective, you will be notified as to additional work needed or additional time being needed to achieve the objective.

If there are any questions, please feel free to contact any of the following specialists:

Jim Amos Supervisory Environmental Protection Specialist 575-234-5909, 575-361-2648 (Cell)

Terry Gregston Environmental Protection Specialist 575-234-5958

Bobby Ballard Environmental Protection Specialist 575-234-2230

Randy Rust Environmental Protection Specialist 575-234-5943

Linda Denniston Environmental Protection Specialist 575-234-5974

Jennifer Van Curen Environmental Protection Specialist 575-234-5905

Justin Frye Environmental Protection Specialist 575-234-5922 Cody Layton Natural Resource Specialist 575-234-5959

Trishia Bad Bear Natural Resource Specialist 575-393-3612

Todd Suter Surface Protection Specialist 575-234-5987

Doug Hoag Civil Engineering Technician 575-234-5979