Submit 3 Copies To Appropriate District Office State of New Mexico Office		Form C-103 June 19, 2008
District I Energy, Minerals and Natural Resources 1625 N French Dr., Hobbs, NM 88240		WELL API NO.
District II 1301 W Grand Ave., Artesia, NM 88210 District III 1000 Rio Brazos Rd, Aztec, NM 87410 OIL CONSERVATION DIVISION 1220 South St. Francis Dr.		3000563170 5. Indicate Type of Lease
		STATE FEE
District IV Santa Fe, NM 8/505		6. State Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM 87505		
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A		7. Lease Name or Unit Agreement Name
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FOI PROPOSALS.)	\	J. Kyle
1. Type of Well: Oil Well Gas Well Other	RECEIVED	8. Well Number 1
2. Name of Operator M.E.W. Enterprise	MAR 1 8 2010	9. OGRID Number 160190
3. Address of Operator	NMOCD ARTESIA	10. Pool name or Wildcat
PO Box 39, Roswell NM 88202	MINIOCO ARTESIA	Elkins San Andres
4. Well Location		
	North line and	
Section 26 Township	7S Range 28E phether DR, RKB, RT, GR, etc.	NMPM County Chaves
4057 GL		
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data		
		SSEQUENT REPORT OF: RK ALTERING CASING
PULL OR ALTER CASING	☐ CASING/CEMEN	-
DOWNHOLE COMMINGLE		
OTHER:	OTHER:	
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date		
of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.		
1. Move in rig up and install BOP		
2. Pick up tubing and tagged existing CIBP with cement on top at 2441'		
 Circulate hole with mud and brine. POH with tubing RIH with wireline and perf at 1923', 1430', 1230', & 372' 		
5. RIH with tubing and set packer at 1703'. Pressured up to 500 psi and held for 15 minutes. No drop. Released packer and		
RIH to 1978' and spot 25 sx class C cement. WOC and tag at 1769'		
 6. POH to 1289' set packer and squeezed perfs at 1430' with 25 sx class C cement. Released packer POH and SION. 7. RIH and tag plug at 1296'. 		
8. POH set packer at 1038' and squeeze perfs at 1230' with 25 sx class C cement. WOC and tag at 1175'.		
9. POH and lay down remaining tubing. Rig up on 5 ½ casing and pump 100 sx class C cement to perfs at 372' and up		
5 1/2 x 8 5/8 annulus to surface.		
10. Install dry hole marker and cut off anchors		
I hereby certify that the information above is true and complete to the best of my knowledge and belief.		
2		
SIGNATURE Shull White TIT	LE Pri	DATE 3-15-10
Type or print name Resell Uted E-mail address: meneral egmilion PHONE: 575-1223665		
For State Use Only		
APPROVED BY:	Approved for plugging of well	bore only. ed pending receipt of Wall Physical ATE 3/8/200
Conditions of Approval (if any):	which may be found at OCD	Web Page under
	Forms, www.emnrd.state.nm.t	na/ora-