å *			KN.
Submit 3 Copies To Appropriate District Office	State of No	ew Mexico	Form C-103
District I	Energy, Minerals an	d Natural Resources	May 27, 2004
1625 N. French Dr., Hobbs, NM 88240 District II			WELL API NO.
1301 W Grand Ave., Artesia, NM 88210	OIL CONSERVA		30-005-63062 5. Indicate Type of Lease
istrict III 1220 South St. Francis Dr.		STATE FEE	
1000 Rio Brazos Rd., Aztec, NM 87410 District IV	Santa Fe, 1	NM 87505	6. State Oil & Gas Lease No.
1220 S. St. Francis Dr , Santa Fe, NM 8750			V-2982
	TICES AND REPORTS ON V		7. Lease Name or Unit Agreement Name:
(DO NOT USE THIS FORM FOR PROPO DIFFERENT RESERVOIR. USE "APPLIC			Quincy AMQ State
PROPOSALS.)			
1. Type of Well: Oil Well	Gas Well Other	RECEIVED	8. Well No. 12
2. Name of Operator	-	11 151 # # 2040	9. OGRID Number
Hanson Operating Com	pany, Inc.	JUN 1 1 2010	10. Pool name or Wildcat
3. Address of Operator PO Box 1515, Roswell, N	JM 88202-1515	NMOCD ARTESIA	1
4. Well Location	WI 00202-1313	ININIOCO ADTESTA	Queen
Unit Letter E: 1650 feet from the North line and 330 feet from the West line			
Section 12	Township 8-S	Range 27- E	NMPM County Chaves
防水 美美女 基 零	11. Elevation (Show wheth	er DR, RKB, RT, GR, etc.)	
· 第一卷 李 · 李 · 秦 · 秦		3973' GR	
Pit or Below-grade Tank Applica			
	dwater Distance from	nearest fresh water well	Distance from nearest surface water
			bls; Construction Material
12. Check A	Appropriate Box to Indic	ate Nature of Notice, I	Report or Other Data
NOTICE OF I	NTENTION TO:	SUB	SEQUENT REPORT OF:
PERFORM REMEDIAL WORK		REMEDIAL WORK	
TEMPORARILY ABANDON	CHANGE PLANS	COMMENCE DRIL	
PULL OR ALTER CASING		CASING/CEMENT	JOB 🔲
	COMPLETION		
	COMPLETION [OTHER:	. п
OTHER:		OTHER:	ve pertinent dates including estimated date of
OTHER: 13. Describe proposed or complete	ed operations. (Clearly state	all pertinent details, and gi	ve pertinent dates, including estimated date of ellbore diagram of proposed completion or
OTHER: 13. Describe proposed or complete starting any proposed work).	ed operations. (Clearly state	all pertinent details, and gi	ve pertinent dates, including estimated date of ellbore diagram of proposed completion or
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion.	ed operations. (Clearly state SEE RULE 1103. For Multip	all pertinent details, and gi ble Completions: Attach w	
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementing 1050'. Circulate hole w/ mud laid.	ed operations. (Clearly state SEE RULE 1103. For Multip ng equipment. POH w/ pum len fluid. Spot 25 sx class C	all pertinent details, and gi ole Completions: Attach w	ellbore diagram of proposed completion or
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementing 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. For the starting of the	ed operations. (Clearly state SEE RULE 1103. For Multip ing equipment. POH w/ pum den fluid. Spot 25 sx class C Rig down move off.	all pertinent details, and gible Completions: Attach was and rods. Dig out cellar cement on top of CIBP.	r, NU BOP. POH w/ tbg. Set CIBP @ POH to 512'. Circulate cement to surface w/
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementing 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. For the starting of the	ed operations. (Clearly state SEE RULE 1103. For Multip ing equipment. POH w/ pum den fluid. Spot 25 sx class C Rig down move off.	all pertinent details, and gible Completions: Attach was and rods. Dig out cellar cement on top of CIBP.	ellbore diagram of proposed completion or r, NU BOP. POH w/ tbg. Set CIBP @
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementing 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. For the starting of the	ed operations. (Clearly state SEE RULE 1103. For Multip ing equipment. POH w/ pum den fluid. Spot 25 sx class C Rig down move off.	all pertinent details, and gible Completions: Attach was and rods. Dig out cellar cement on top of CIBP.	r, NU BOP. POH w/ tbg. Set CIBP @ POH to 512'. Circulate cement to surface w/
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementing 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. For the starting of the	ed operations. (Clearly state SEE RULE 1103. For Multip ing equipment. POH w/ pum den fluid. Spot 25 sx class C Rig down move off.	all pertinent details, and gible Completions: Attach was and rods. Dig out cellar cement on top of CIBP.	r, NU BOP. POH w/ tbg. Set CIBP @ POH to 512'. Circulate cement to surface w/
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementing 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. For the starting of the	ed operations. (Clearly state SEE RULE 1103. For Multip ing equipment. POH w/ pum den fluid. Spot 25 sx class C Rig down move off.	all pertinent details, and gible Completions: Attach was and rods. Dig out cellar cement on top of CIBP.	r, NU BOP. POH w/ tbg. Set CIBP @ POH to 512'. Circulate cement to surface w/
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementing 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. For the starting of the	ed operations. (Clearly state SEE RULE 1103. For Multip ing equipment. POH w/ pum den fluid. Spot 25 sx class C Rig down move off.	all pertinent details, and gible Completions: Attach was and rods. Dig out cellar cement on top of CIBP.	r, NU BOP. POH w/ tbg. Set CIBP @ POH to 512'. Circulate cement to surface w/
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementing 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. For the starting of the	ed operations. (Clearly state SEE RULE 1103. For Multip ing equipment. POH w/ pum den fluid. Spot 25 sx class C Rig down move off.	all pertinent details, and gible Completions: Attach was and rods. Dig out cellar cement on top of CIBP.	r, NU BOP. POH w/ tbg. Set CIBP @ POH to 512'. Circulate cement to surface w/
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementing 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. For the starting of the	ed operations. (Clearly state SEE RULE 1103. For Multip ing equipment. POH w/ pum den fluid. Spot 25 sx class C Rig down move off.	all pertinent details, and gible Completions: Attach was and rods. Dig out cellar cement on top of CIBP.	r, NU BOP. POH w/ tbg. Set CIBP @ POH to 512'. Circulate cement to surface w/
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementing 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. Recomplete the starting star	ed operations. (Clearly state SEE RULE 1103. For Multip ing equipment. POH w/ pum den fluid. Spot 25 sx class C Rig down move off.	all pertinent details, and gible Completions: Attach was and rods. Dig out cellar cement on top of CIBP.	r, NU BOP. POH w/ tbg. Set CIBP @ POH to 512'. Circulate cement to surface w/
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementing 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. Recomplete the starting star	ed operations. (Clearly state SEE RULE 1103. For Multip ing equipment. POH w/ pum den fluid. Spot 25 sx class C Rig down move off.	all pertinent details, and gible Completions: Attach was and rods. Dig out cellar cement on top of CIBP.	r, NU BOP. POH w/ tbg. Set CIBP @ POH to 512'. Circulate cement to surface w/
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementing 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. Recomplete the starting star	ed operations. (Clearly state SEE RULE 1103. For Multip ing equipment. POH w/ pum den fluid. Spot 25 sx class C Rig down move off.	all pertinent details, and gible Completions: Attach was and rods. Dig out cellar cement on top of CIBP.	r, NU BOP. POH w/ tbg. Set CIBP @ POH to 512'. Circulate cement to surface w/
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementing 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. Recomplete the starting star	ed operations. (Clearly state SEE RULE 1103. For Multip ing equipment. POH w/ pum den fluid. Spot 25 sx class C Rig down move off.	all pertinent details, and gible Completions: Attach was and rods. Dig out cellar cement on top of CIBP.	r, NU BOP. POH w/ tbg. Set CIBP @ POH to 512'. Circulate cement to surface w/
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementing 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. Recomplete to 105/03/10 Move in welder and based on the starting proposed work).	ed operations. (Clearly state SEE RULE 1103. For Multiping equipment. POH w/ pumblen fluid. Spot 25 sx class CRig down move off. ckhoe. Cut off wellhead and cove is true and complete to the bove is true and complete to the bove.	all pertinent details, and gible Completions: Attach was and rods. Dig out cellar cement on top of CIBP. It weld on Dry Hole Marketest of my knowledge and beli	ellbore diagram of proposed completion or r, NU BOP. POH w/ tbg. Set CIBP @ POH to 512'. Circulate cement to surface w/ er. Back fill cellar. Clean loc. Move off. ef. I further certify that any pit or below-grade tank
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementing 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. Recomplete to 105/03/10 Move in welder and based on the starting proposed work).	ed operations. (Clearly state SEE RULE 1103. For Multiping equipment. POH w/ pumblen fluid. Spot 25 sx class CRig down move off. ckhoe. Cut off wellhead and cove is true and complete to the bove is true and complete to the bove.	all pertinent details, and gible Completions: Attach was and rods. Dig out cellar cement on top of CIBP. It weld on Dry Hole Marketest of my knowledge and beli	ellbore diagram of proposed completion or r, NU BOP. POH w/ tbg. Set CIBP @ POH to 512'. Circulate cement to surface w/er. Back fill cellar. Clean loc. Move off.
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementing 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. Recompletion of the starting and base of the starting and proposed or complete starting any proposed or complete starting any proposed work). The starting any proposed or complete starting any proposed work). The starting and starting and starting any proposed work and starting and star	ed operations. (Clearly state SEE RULE 1103. For Multipling equipment. POH w/ pumblen fluid. Spot 25 sx class CRig down move off. ckhoe. Cut off wellhead and cover is true and complete to the baccording to NMOCD guideline	all pertinent details, and gible Completions: Attach was and rods. Dig out cellar cement on top of CIBP. It weld on Dry Hole Marketest of my knowledge and belies X, a general permit or a	ellbore diagram of proposed completion or r, NU BOP. POH w/ tbg. Set CIBP @ POH to 512'. Circulate cement to surface w/ er. Back fill cellar. Clean loc. Move off. ef. I further certify that any pit or below-grade tank an (attached) alternative OCD-approved plan .
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementing 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. Recomplete to 105/03/10 Move in welder and based on the starting proposed work).	ed operations. (Clearly state SEE RULE 1103. For Multipling equipment. POH w/ pumblen fluid. Spot 25 sx class CRig down move off. ckhoe. Cut off wellhead and cover is true and complete to the baccording to NMOCD guideline	all pertinent details, and gible Completions: Attach was and rods. Dig out cellar cement on top of CIBP. It weld on Dry Hole Marketest of my knowledge and beli	ellbore diagram of proposed completion or r, NU BOP. POH w/ tbg. Set CIBP @ POH to 512'. Circulate cement to surface w/ er. Back fill cellar. Clean loc. Move off. ef. I further certify that any pit or below-grade tank an (attached) alternative OCD-approved plan .
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementiant 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. Recompletion of the start of t	ed operations. (Clearly state SEE RULE 1103. For Multipung equipment. POH w/ pumblen fluid. Spot 25 sx class CRig down move off. ckhoe. Cut off wellhead and over is true and complete to the baccording to NMOCD guideline.	all pertinent details, and gible Completions: Attach was and rods. Dig out cellar cement on top of CIBP. If weld on Dry Hole Mark weld on Dry Hole Mark west of my knowledge and belies X, a general permit or a large of the control o	ellbore diagram of proposed completion or r, NU BOP. POH w/ tbg. Set CIBP @ POH to 512'. Circulate cement to surface w/ er. Back fill cellar. Clean loc. Move off. ef. I further certify that any pit or below-grade tank an (attached) alternative OCD-approved plan b. DATE 6/9/2010
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementing 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. Recompletion of the starting and base of the starting and base of the starting and base of the starting and seen will be constructed or closed SIGNATURE And J. Type or print name Carol J.	ed operations. (Clearly state SEE RULE 1103. For Multipling equipment. POH w/ pumblen fluid. Spot 25 sx class CRig down move off. ckhoe. Cut off wellhead and convolve is true and complete to the baccording to NMOCD guideline.	all pertinent details, and gible Completions: Attach was and rods. Dig out cellar cement on top of CIBP. It weld on Dry Hole Mark lest of my knowledge and belies X, a general permit or a structure of the control of t	ellbore diagram of proposed completion or r, NU BOP. POH w/ tbg. Set CIBP @ POH to 512'. Circulate cement to surface w/ er. Back fill cellar. Clean loc. Move off. ef. I further certify that any pit or below-grade tank an (attached) alternative OCD-approved plan DATE 6/9/2010 Telephone No. 575-622-7330
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementiant 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. Recompletion of the start of t	ed operations. (Clearly state SEE RULE 1103. For Multipling equipment. POH w/ pumblen fluid. Spot 25 sx class CRig down move off. ckhoe. Cut off wellhead and convolve is true and complete to the baccording to NMOCD guideline.	all pertinent details, and gible Completions: Attach was pand rods. Dig out cellar cement on top of CIBP. If weld on Dry Hole Mark lest of my knowledge and belies X, a general permit or a structure of the control of	r, NU BOP. POH w/ tbg. Set CIBP @ POH to 512'. Circulate cement to surface w/ er. Back fill cellar. Clean loc. Move off. ef. I further certify that any pit or below-grade tank an (attached) alternative OCD-approved plan . DATE 6/9/2010 Telephone No. 575-622-7330
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementing 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. Recompletion of the starting and base of the starting and base of the starting and base of the starting and seen will be constructed or closed SIGNATURE And J. Type or print name Carol J.	ed operations. (Clearly state SEE RULE 1103. For Multipling equipment. POH w/ pumblen fluid. Spot 25 sx class CRig down move off. ckhoe. Cut off wellhead and convolve is true and complete to the baccording to NMOCD guideline.	all pertinent details, and gible Completions: Attach was and rods. Dig out cellar cement on top of CIBP. It weld on Dry Hole Mark weld on Dry Hole Mark is X, a general permit or a structure of the plugging of was a general permit or a structure of the plugging of was a general permit o	ellbore diagram of proposed completion or r, NU BOP. POH w/ tbg. Set CIBP @ POH to 512'. Circulate cement to surface w/ er. Back fill cellar. Clean loc. Move off. ef. I further certify that any pit or below-grade tank an (attached) alternative OCD-approved plan DATE 6/9/2010 Telephone No. 575-622-7330 ell bore only. and pending receipt and DATE
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementing 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. Recompletion of the start of th	ed operations. (Clearly state SEE RULE 1103. For Multipling equipment. POH w/ pumblen fluid. Spot 25 sx class CRig down move off. ckhoe. Cut off wellhead and convolve is true and complete to the baccording to NMOCD guideline.	all pertinent details, and gible Completions: Attach was and rods. Dig out cellar cement on top of CIBP. It weld on Dry Hole Mark weld on Dry Hole Mark is X, a general permit or a structure of the plugging of was a general permit or a structure of the plugging of was a general permit o	ellbore diagram of proposed completion or r, NU BOP. POH w/ tbg. Set CIBP @ POH to 512'. Circulate cement to surface w/ er. Back fill cellar. Clean loc. Move off. ef. I further certify that any pit or below-grade tank an (attached) alternative OCD-approved plan DATE 6/9/2010 Telephone No. 575-622-7330 ell bore only. and pending receipt and DATE
OTHER: 13. Describe proposed or complete starting any proposed work). recompletion. 04/30/10 MIRU rig and cementing 1050'. Circulate hole w/ mud laid 50 sx class C cement. ND BOP. Recomplete to 105/03/10 Move in welder and based based or closed signature. I hereby certify that the information about has been/will be constructed or closed signature. Type or print name Carol J. For State Use Only APPROVED BY	ed operations. (Clearly state SEE RULE 1103. For Multipling equipment. POH w/ pumblen fluid. Spot 25 sx class CRig down move off. ckhoe. Cut off wellhead and convolve is true and complete to the baccording to NMOCD guideline.	all pertinent details, and gible Completions: Attach was and rods. Dig out cellar cement on top of CIBP. It weld on Dry Hole Mark weld on Dry Hole Mark is X, a general permit or a structure of the plugging of was a general permit or a structure of the plugging of was a general permit o	ellbore diagram of proposed completion or r, NU BOP. POH w/ tbg. Set CIBP @ POH to 512'. Circulate cement to surface w/ er. Back fill cellar. Clean loc. Move off. ef. I further certify that any pit or below-grade tank an (attached) alternative OCD-approved plan b. DATE 6/9/2010 Telephone No. 575-622-7330 ent bore only. Control of the cont