Submit 1 Copy To Appropriate District Office	State of New Mexico		Form C-103 October 13, 2009	
<u>District I</u> 1625 N. French Dr., Hobbs, NM 88240	Energy, Minerals and Natural Resources		WELL API NO.	
District II ~ 1301 W. Grand Ave., Artesia, NM 88210	OIL CONSERVATION DIVISION		30-015-26719	
District III	1220 South St. Francis Dr.		5. Indicate Type of STATE	of Lease FEE
1000 Rio Brazos Rd., Aztec, NM 87410 District IV	Santa Fe, NM 87505		6. State Oil & Ga	
1220 S St. Francis Dr., Santa Fe, NM 87505				
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)			7. Lease Name or Unit Agreement Name NDDUP Unit 8. Well Number	
1. Type of Well: Oil Well	Gas Well Other	REVISED	59	
2. Name of Operator			9. OGRID Number	
Yates Petroleum Corporation 3. Address of Operator			025575 10. Pool name or Wildcat	
105 South Fourth Street, Artesia, NM 88210			Dagger Draw; Upper Penn, North	
4. Well Location				
Unit Letter G:	1780 feet from the Nor	th line and	1980 feet from	the East line
Section 19	Township 19S R	Range 25E	NMPM Edd	y County
The second secon	11. Elevation (Show whether D.) y ;	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
	360	0'GR		. 0.
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data				
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:				
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK				
TEMPORARILY ABANDON				P AND A
PULL OR ALTER CASING	MULTIPLE COMPL	CASING/CEMEN	T JOB 🔲	
DOWNHOLE COMMINGLE				
OTHER: Turn well over to ranche		OTHER:		
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.				
Yates Petroleum Corporation plans to plug and abandon this well as follows:				
 NU BOP. Rig up any safety equipment as needed. No casing recovery will be attempted. POOH with tubing and packer if any exist. Set a CIBP at 7697' with 35' cement on top. This will place a plug over open Canyon perforations. Spot a 160' cement plug from 5324'-5484'. This will leave a plug across Wolfcamp top. Spot a 140' cement plug from 3188'-3328'. This will leave a plug across Bone Spring top. Spot a 120' cement plug from 2033'-2153'. This will leave a plug across Glorieta top. Spot a 150' cement plug from 1115'-1265'. WOC and tag plug, reset if necessary. This will leave a plug across surface casing shoe. 				
7. Spot a 150' cement plug from 586'-736'. This will leave a plug across San Andres top.8. Remove all surface equipment and turn well over to the Rancher.				RECEIVED
			SEP 2.9 2010	
				NMOCD ARTESIA
				TOTAL TRANSPORT
Spud Date:	Rig Release I	Date:		
				
I hereby certify that the information above is true and complete to the best of my knowledge and belief.				
SIGNATURE TITLE Regulatory Compliance Supervisor DATE September 28, 2010				
Type or print name Tina Hu For State Use Only	erta E-mail address:	tinah@yatespetroleur	n.com PHONI	E: <u>575-748-4168</u>
APPROVED BY: Conditions of Approval (if any):	TITLE AP	proval Granted providi	ng work DA	TE 9/30/800



