

UNITED STATES *Copy J.F.*
 DEPARTMENT OF THE INTERIOR *SUBMIT (Other in reverse side)*
 GEOLOGICAL SURVEY *REPLICATE* (This is on re-*

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

MM-01908

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL GAS WELL OTHER

2. NAME OF OPERATOR
Jack L. McClellan ✓

3. ADDRESS OF OPERATOR
P. O. Box 848, Roswell, New Mexico

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1620' FEL & 2275' PSL

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
Barbara Federal

9. WELL NO.
1

10. FIELD AND POOL, OR WILDCAT
Crow Flats-San Andres

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec. 22-168-28E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3665' OL

12. COUNTY OR PARISH
Eddy

13. STATE
New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF
FRACTURE TREAT
SHOOT OR ACIDIZE
REPAIR WELL
(Other)

PULL OR ALTER CASING
MULTIPLE COMPLETE
ABANDON*
CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF
FRACTURE TREATMENT
SHOOTING OR ACIDIZING
(Other)

REPAIRING WELL
ALTERING CASING
ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

On November 24th I perforated the captioned well with 1 shot per foot at 2366, 2376, 2381, 2385, 2478, 2492, 2496, 2501, 2510 and 2516. Set retrievable bridge plug at 2550 feet, packer 2450 feet. Acidized perms from 2478 to 2516 with with 4000 gallons 15% acid. Swabbed and flowed spent acid water, oil and water. Set retrievable bridge plug at 2450 feet, packer 2320 feet. Acidized perms from 2366 to 2384 feet with 2250 gallons 15% acid. Swabbed spent acid water. Did not recover load. Pulled all packers, reran tubing. Set on intermitter, kicked off with pulling unit. Now testing.

RECEIVED

DEC 3 1964

D. G. F.
ARTESIAN OFFICE

18. I hereby certify that the foregoing is true and correct

SIGNED

J. McClellan

TITLE

Operator

DATE

11/30/64

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED
DEC 2 1964
[Signature]
 ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

