

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIP DATE
(Other instruction
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC-061638

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

RECEIVED

7. UNIT AGREEMENT NAME

FEB 20 1981

8. FARM OR LEASE NAME

Brewer

O.C.D.

9. WELL NO.

23

ARTESIAL OFFICE

10. FIELD AND POOL, OR WILDCAT

High Lonesome

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 14, T-16S, R-29E

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

1. OIL WELL GAS WELL OTHER Water Injection

2. NAME OF OPERATOR
General American Oil Company of Texas ✓

3. ADDRESS OF OPERATOR
P. O. Box 128 Loco Hills, New Mexico 88255

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.)
At surface

660' FSL and 1980' PEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3704' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF
FRACTURE TREAT
SHOOT OR ACIDIZE
REPAIR WELL
(Other)

PULL OR ALTER CASING
MULTIPLE COMPLETE
ABANDON*
CHANGE PLANS

WATER SHUT-OFF
FRACTURE TREATMENT
SHOOTING OR ACIDIZING
(Other)


REPAIRING WELL
ALTERING CASING
ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

We propose to plug and abandon this well as follows:

1. Pull tubing.
2. Run casing scraper.
3. Run freepoint and shoot 7" casing off and pull from hole.
4. Run in hole with tubing and spot 100' cement plug, 2046'-1946'.
(This will cover open hole section 2024'-2046').
5. Set 100' cement plug where casing was shot off. (50' in and 50' out of casing stub).
6. Set 100' cement plug from 905'-805'. (Base of Salt 855').
7. Set 100' cement plug from 400'-500'. (Top of Salt 450').
8. Set 100' cement plug from 300'-400'. (Across water zone).
9. Set 10 sack cement plug at surface and install dry hole marker.
10. Remove all debris from location and fill pits. Rip location and roads as necessary.



18. I hereby certify that the foregoing is true and correct

SIGNED Rendell T. Hawkins

TITLE Field Superintendent

DATE February 5, 1981

(This space for Federal or State office use)

APPROVED BY (Orig. Sgd.) PETER W. CHESTER
CONDITIONS OF APPROVAL, IF ANY:

TITLE ACTING DISTRICT ENGINEER

DATE FEB 10 1981