

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 028731 (a)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

M. Dodd "A"

9. WELL NO.

14

10. FIELD AND POOL, OR WILDCAT

Grayburg Jackson(SR-Q-G-S)

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 22, T 17-S, R 29-E

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR
Sun Oil Company

3. ADDRESS OF OPERATOR
P. O. Box 1861 Midland, Texas 79702

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface
330' FSL, 2310' FWL, Unit 1tr "N"
2309

14. PERMIT NO.
3546 DF

15. ELEVATIONS (Show whether DF, RT, GR, etc.)
O. C. D.
ARTESIA, OFFICE

JUN 27 1980

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐

(Other)

PULL OR ALTER CASING ☐MULTIPLE COMPLETION ☐ABANDON* ☐CHANGE PLANS ☐

Shut off waterflow

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐

(Other)

REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. MIRU. Pull rods. Install BOP - tag PBTD & tally out tbq.
2. RIH w/RBP & full bore pkr. Set RBP @ 2000' & test to 1000#.
3. Test csg to 500#. If no test isolate csg. leaks.
4. If csg tests OK POH. GOI shut 4-way sqz shot @ 1550'. Dump 2 sx sd on RBP w/dump bailer
5. RIH w/full bore pkr & SN. Set pkr @ 1350'. EIR & sqz perfs @ 1550' w/250 sx Class C near cmt. Displace to 1500' & WOC 4 hrs., POH. Run temp survey to find TOC, if cmt does not circ.
6. RIH w/4-3/4" bit & DC's. Tag cmt & D.O. Press & swab test, sqz, POH.
7. RIH w/ret head. Wash sd off RBP, latch & POH.
8. RIH w/bit & circ sd out to TD 3263'.
9. Rerun pump setup w/SN & 30' mud anchor. Tag TD & pick up to 1st collar. Run 1-1/4" pump on "66" -C- grade rods. RD, RR.

RECEIVED

JUN 27 1980
U.S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

Sonia Williams

TITLE

Sr. Accounting Assistant

DATE 6-23-80

(This space for Federal or State office use)

APPROVED BY

Robert L. G. Jr.

TITLE

ACTING DISTRICT ENGINEER

DATE

JUN 25 1980

CONDITIONS OF APPROVAL, IF ANY: