OIL CONS. COMMISSION Drawer DD Artesia, NM 88210

Form 9-331

- 1998

* # 40 1 14

Form Approved.

JAMES A. GILLHAM DISTRICT SUPERVISOR

Budget Bureau No. 42-R1424 Dec. 1973 UNITED STATES 5. LEASE V.L. Foster DEPARTMENT OF THE INTERIOR 6. IF INDIAN, ALLOTTEE OR TRIBE NAME **GEOLOGICAL SURVEY** 0/5F RECEIVED 7. UNIT AGREEMENT NAME SUNDRY NOTICES AND REPORTS ON WELLS (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.) DEC 2 8 1981 8. FARM OR LEASE NAME V.L. Foster gas well 🖸 O. C. D. other WIW 9. WELL NO. well ARTESIA, OFFICE 6 2. NAME OF OPERATOR Sun Giff 10. FIELD OR WILDCAT NAME Company Grayburg- Jackson 3. ADDRESS OF OPERATOR 11. SEC., T., R., M., OR BLK. AND SURVEY OR P.O. Box 1861, Midland, Texas 79702 AREA Unit Letter G 4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 Sec. 17, T. 17-S, Range 31-E below.) 12. COUNTY OR PARISH 13. STATE AT SURFACE: New Mexico AT TOP PROD. INTERVAL: Eddy AT TOTAL DEPTH: 14. API NO. 16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, Federal LC-049998 (a) REPORT, OR OTHER DATA 15. ELEVATIONS (SHOW DF. KDB, AND WD) SUBSEQUENT REPORT OF: REQUEST FOR APPROVAL TO: TEST WATER SHUT-OFF FRACTURE TREAT SHOOT OR ACIDIZE (NOTE: results of multiple completion or zone change on Form 9–330.) REPAIR WELL 21 1981 PULL OR ALTER CASING MULTIPLE COMPLETE CHANGE ZONES OIL & GAS ABANDON* U.S. GEOLOGICAL SURVEY (other) ROSWELL, NEW MEXICO 17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)* MIRU csg. PU. Install BOP. POH w/oild 2-3/8 tbg. RIH w/2-3/8" tbg. to 3465. Load Hole w/9.5# mud laden fluid. POH. RIH w/CIBP on SL. Set CIBP @2840, dump 2 sx cmt on top CIBP Stretch scg & locate free point. Cut csg. Above free point & POH w/4-1/2"csg. RIH w/CIBP on SL. Set CIBP @1960', dump 2 sx cmt on top CIBP. Stretch csg & locate free point. Cut csg above free point & POH w/7" Csg. RIH w/2-3/8" tbg. Spot 20 sx cmt from 1410 to 1310', 30 sx cmt @ 561'. Spot 10 sx cmt @.Surface. Cut scg off 3' below surface, weld on steel plate. Weld on dry hole marker, clean up location. Set @ __ Subsurface Safety Valve: Manu. and Type ___ 18. I hereby certify that the foregoing is true and correct 12-18-81 Acct. Asst. II DATE SIGNED. TITLE (This space for Federal or State office use) APPROVED AS AMENDED APPROVED BY DAT SEE ATTACHED FOR CONDITIONS OF APPROVAL, IF ANY: CONDITIONS OF APPROVAL

*See Instructions on Reverse Side