

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TR. CATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

1. LEASE DESIGNATION AND SERIAL NO.

LC 029395 (a)

5. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☒ GAS WELL ☐ OTHER

2. NAME OF OPERATOR

Atlantic Richfield Company ✓

3. ADDRESS OF OPERATOR

P. O. Box 1710, Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

2310' FNL & 990' FEL (Unit letter H)

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3698' GR

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Turner "A"

9. WELL NO.

20

10. FIELD AND POOL, OR WILDCAT

Fren 7Rivers

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

19-T17S-R31E

12. COUNTY OR PARISH

Eddy

13. STATE

N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

Plug & abandon

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

TD 1935'. Completed OH interval 1866-1935'.

7" OD 20# csg set @ 510'. Cmtd w/50 sx.

5½" OD 14# csg set @ 1866'. Cmtd w/100 sx.

90' - 4½" OD rotary drill pipe for liner, slotted thru pay section 1875-1920'.

This well is depleted in the Fren Seven Rivers zone and is not needed in the future for Fren sand Waterflood. Propose to plug & abandon in the following manner:

1. Rig up, install BOP.

2. Run 2-3/8" tbgs OE to 1766', spot 30 sx Cl C cmt to cover bottom 100' of 5½" OD csg.

3. Run free point on 5½" OD csg. Cut from free point @ approx 1100' & pull.

4. Fill hole w/heavy gelled mud between cmt plugs.

5. Spot 35 sx Cl C cmt (100' cmt plug) across 5½" OD csg stub.

6. Spot 40 sx Cl C cmt (100' cmt plug) across 7" OD csg shoe & top of salt @ 510'.

7. Spot 10 sx Cl C cmt @ surface, install regulation dry hole marker, clean & level:
location.RECEIVED
NOV 25 1975
U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Dist. Drlg. Supv.

DATE 11/24/75

(This space for Federal or State office use)


APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side



ATLANTIC RICHFIELD COMPANY
Blow Out Preventer Program

Lease Name Turner "A"

Well No. 20

Location 2310' FNL & 990' FEL
Sec 19-T17S-R31E

BOP to be tested before installed on well and will be maintained in good working condition during workover. All wellhead fittings to be of sufficient pressure to operate in a safe manner.