

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TR\*  
(Other instructi  
verse side)DATE\*  
on re-Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 031844

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Fren Oil Company

9. WELL NO.

6

10. FIELD AND POOL, OR WILDCAT

Grayburg Jackson

11. SEC., T., R., M., OR BLE. AND  
SURVEY OR AREA

19-17S-31E

12. COUNTY OR PARISH

Eddy

13. STATE

N.M.

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1.

OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Atlantic Richfield Company

3. ADDRESS OF OPERATOR

P. O. Box 1710, Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)  
At surface

990' FSL &amp; 1650' FEL (Unit letter O)

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3591' DF

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐

(Other)

Plug &amp; Abandon

PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON\* ☐CHANGE PLANS ☐

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐

(Other)

REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT\* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

TD 3643'. Present perfs 2911-2939, 3037-3057, 3065-3078, 3542-3546'. Top of salt @ 480'.  
8-5/8" OD 24# csg set @ 500' & cmt'd w/75 sx.

7" OD 20# csg set @ 1818' &amp; cmt'd w/130 sx.

4 1/2" OD 9.5# csg f/liner set from 1767-3643' &amp; cmt'd w/295 sx.

This well has gone to 100% water and will not be needed in the future proposed Fren sand flood. Propose to P&amp;A in the following manner:

1. Rig up, install BOP &amp; pull completion assy.

2. RIH w/bit &amp; csg scraper to 2911'.

3. RIH w/4 1/2" cmt retr on tbg &amp; set @ 2900'.

4. Cmt squeeze thru retr w/75 sx Cl C cont'g 4% gel &amp; 8# salt/sk. Pull up &amp; spot 2 sx on top of retr.

5. Fill hole w/heavy mud.

6. Spot 20 sx Cl C cmt (100' plug) across top of liner @ 1767'.

7. Cut 7" csg from free pt indicated @ approx 500' &amp; pull.

8. Spot 30 sx Cl C cmt half in 7" csg stub &amp; half out and top of salt @ 480'.

9. Perf 8-5/8" csg @ approx 380' w/4 holes. RIH w/8-5/8" cmt retr &amp; squeeze cmt w/75 sx Cl C

10. Spot 10 sx @ surface. Install regulation dry hole marker, clean &amp; level location.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Dist. Drlg. Supv.

DATE 8/26/75

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side