

N. M. O. C. C. COPY
UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY
SUBMIT IN TRI DATE*
(Other instruction on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 029395 (b)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Turner "B"

9. WELL NO.

28

10. FIELD AND POOL, OR WILDCAT

Fren Seven Rivers

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

20-17S-31E

12. COUNTY OR PARISH 13. STATE

Eddy

N.M.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Atlantic Richfield Company

3. ADDRESS OF OPERATOR

P. O. Box 1710, Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

ARTESIA, OFFICE

2310' FNL & 330' FWL (Unit letter E)

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3617' GR

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other) Plug & abandon

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.) *

TD 1949'. Completed in OH interval 1873-1949'.

7" OD 20# csg set @ 511' & cmtd w/50 sx.

5½" OD 14# csg set @ 1873' & cmtd w/100 sx.

This well is depleted in the Fren Seven Rivers zone and is not needed in the future for
Fren Sand waterflood. Propose to plug & abandon in the following manner:

1. Rig up, install BOP.

2. Run 2-3/8" OD EUE tbg OE to 1849' & spot 30 sx Cl C cmt to cover bottom 100' of 5½"
OD csg.

3. Fill hole w/heavy gelled mud between all cmt plugs.

4. Run free point on 5½" csg. Cut csg from freepoint @ approx 1250' & pull.

5. Spot 35 sx Cl C cmt (100' plug) across 5½" csg stub.

6. Spot 40 sx Cl C cmt (100' plug) across 7" OD csg shoe & top of salt @ 500'.

7. Spot 10 sx Cl C cmt @ surface, install regulation dry hole marker, clean & level
location.

RECEIVED

NOV 25 1975

U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Dist. Drlg. Supv.

DATE 11/24/75


(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

*See Instructions on Reverse Side



ATLANTIC RICHFIELD COMPANY
Blow Out Preventer Program

Lease Name Turner "B"

Well No. 28

Location 2310' FNL & 330' FVL
Sec 20-17S-31E, Eddy Co.

BOP to be tested before installed on well and will be maintained in good working condition during workover. All wellhead fittings to be of sufficient pressure to operate in a safe manner.