16.

## N. M. O. C. C. CC

SUBMIT IN 1. STATES G\_ . IV. DEPARTMENT OF THE INTERIOR (Other interior verse side)

instructions on re-

N.M.

5. LEASE DESIGNATION AND SERIAL NO.

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

LC 029395 (b)

Eddy

GEOLOGICAL SURVEY						
SUNDRY	NOTICES	AND	REPORTS	ON	WELLS	

(Do not use this form for proposals to drill or to deepen or plu Use "APPLICATION FOR PERMIT—" for such		
OIL X GAS OTHER	RECEIVED	7. UNIT AGREEMENT NAME  8. FARM OR LEASE NAME
Atlantic Richfield Company	JAN 24 1975	Turner "B" /
P. O. Box 1710, Hobbs, New Mexico 88240 L LOCATION OF WELL (Report location clearly and in accordance with a	any State refulrements.	45 10. FIELD AND POOL, OR WILDCAT
See also space 17 below.) At surface	ARTESIA, OFFICE	Grayburg Jackson  11. SEC., T., B., M., OR BLK. AND SURVEY OR AREA
2080' FEL & 660' FST. (Unit letter O)	P. P. C. ate.)	Sec 20-T17S-R31E  12. COUNTY OR PARISH   13. STATE
15 REEVATIONS (Show whether	r Dr. Ri, GR. CAD.	1

## Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

3699' DF

NOT	ICE OF INTENTION TO:	SUBSEQUENT REPORT OF:		
TEST WATER SHUT-OFF	PULL OR ALTER CASING	WATER SHUT-OFF REPAIRING WELL	"	
IBSI WAIDA GEOLOGO		FRACTURE TREATMENT ALTERING CASIN	NG	
FRACTURE TREAT	MULTIPLE COMPLETE			
SHOOT OR ACIDIZE	ABANDON*	SHOOTING OR ACIDIZING ABANDONMENT		
REPAIR WELL	CHANGE PLANS	(Other) results of multiple completion on	Well	
(Other) Plug	& Abandon X	(Note: Report results of multiple completion on Completion or Recompletion Report and Log form.)	)	

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) \*

TD 3350', PBD 3320'. Present perforations 3158-3317'. RBP @ 3280'.

8-5/8" OD 28# casing set @ 558' & cmtd w/50 sx.

5-1/2" OD 14# casing set @ 3349' & cmtd w/200 sx. TOC @ 1715'.

Propose to plug & abandon in the following manner:

- 1. Rig up & make trip w/bit & scraper to 3100'.
- 2. Run cmt retr on tbg & set @ 3100' & cmt w/100 sx.
- 3. Load hole w/9# gel mud.
- 4. Cut off & recover 53" csg from free point.
- 5. Spot 40 sk cmt plug half in & half out of 51 csg stub.
- 6. Spot 40 sk cmt plug across 8-5/8" OD csg shoe @ 558'. Top of salt @ 528'.
- 7. Spot 10 sk cmt plug @ surface.
- 8. Install regulation dry hole marker. Clean & level location.

RECEIVED

JAN 23 1975 U.S. GEOLOGICAL SURVEY ARTESIA, NEW MEXICO

•		
18. I hereby certify that the forego	TITLE Dist. Drlg. Supv.	DATE1/21/75
(This pare for Federal or Stat	TIONAL	DATE
AD CONDICIONS OF APPROVAL	IF ANY:  TITLE  APPROVED SUBJECT TO POSSIBLE ADDITIONAL  APPROVED SUBJECT TO P	
al fine land	*See Instructions on Reverse Side	

ACTING DISTRICT ENGINEER CONTACT THIS OFFICE REGARDING ABOVE BEFORE MARINO AL CLEANUP.