

Skelly Unit Well No. 76  
Proposed Plugging Procedure

- 1) Inform BLM 24 hrs. prior to commencement of work.
- 2) MIRU pulling unit. Install BOP.
- 3) RIH with 2 3/8" tubing to PBTD 2125'. Load hole with salt gel mud consisting of 10 lb. brine with 25 lbs. of gel per barrel. TOH.
- 4) Perforate two squeeze holes at each of the following depths: 1620', 715', 50'.
- 5) RIH with tubing and cement retainer. Set retainer at 1520' (base of salt 1520'). Establish circulation through squeeze holes at 1620'. Pump 35 sx of Class "C" cement (1.32 cuft/sx). Flush tubing with 4 BBLS of water. Sting out of retainer and flush remaining cement on top of retainer. TOH
- 6) RIH with tubing and cement retainer. Set retainer at 450' (top of salt at 553', surface casing shoe at 663'). Establish circulation through squeeze holes at 715'. Pump 70 sx of Class "C" cement (1.32 cuft/sx). Sting out of retainer and flush cement remaining in tubing on top of retainer. TOH
- 7) Establish circulation through squeeze holes at 50' until circulated to surface up the 7" annulus.
- 8) Pump Class "C" cement (1.32 cuft/sx) down the 7" casing until circulated to surface through the 7" annulus. Estimated 12 sx.
- 9) Cut off wellhead. Install marker. Clean location.