

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1 ✓
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

RECEIVED

NEW MEXICO OIL CONSERVATION COMMISSION

JUL 20 1973

O. C. C.  
ARTESIA, OFFICE

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. 50710
7. Unit Agreement Name
8. Farm or Lease Name Continental "U-15"
9. Well No. 3
10. Field and Pool, or Wildcat Grayburg Jackson
12. County Eddy

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Water Injection Well</b>
2. Name of Operator <b>Sun Oil Company</b> ✓
3. Address of Operator <b>Box 1861, Midland, Texas 79701</b>
4. Location of Well UNIT LETTER <b>F</b> , <b>1980</b> FEET FROM THE <b>North</b> LINE AND <b>1980</b> FEET FROM THE <b>West</b> LINE, SECTION <b>15</b> TOWNSHIP <b>17-S</b> RANGE <b>29-E</b> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) <b>3577 KB</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. MIRU pulling unit.
2. Release tension packer, pull 2 3/8" tubing and Baker AD-1 packer.
3. Run 2 3/8" tubing open ended, load hole with 9.5# mud.
4. Spot 15 sx cement plug 2450' to 2300'.
5. Shoot and pull 4 1/2" casing at free point (est 1500) TOC 1560.-
6. Spot 30 sx cement plug from 50' inside 4 1/2" casing stub into open hole.
7. Spot 35 sx cement plug from 600' to 800' across 8 5/8" casing seat.
8. Place 10 sx plug at surface, weld cap on 8 5/8", install permanent marker and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Charles R. Price TITLE Engineer DATE 7-13-73  
APPROVED BY W. A. Gressett TITLE OIL AND GAS INSPECTOR DATE JUL 31 1973  
CONDITIONS OF APPROVAL, IF ANY:

Notify N.M.O.C.C. in sufficient time to witness

Plugging

Vertical line on the right side of the page.

Handwritten text at the bottom right, possibly a signature or date.