

(November 1983)
(Formerly 9-331)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN APPLICATION
(Other instructions on re-
verse side)

Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO. *clsf*

NM-01165

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

RECEIVED

1. OIL ☒ GAS ☐ OTHER ☐
WELL WELL

2. NAME OF OPERATOR

TXO Production Corp.

APR 23 '90

3. ADDRESS OF OPERATOR

415 West Wall, Suite 900, Midland, Texas 79701-4468

C. C. D.

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.)

See also space 17 below.)
At surface

ARTESIA, OFFICE

990' FSL & 1980' FWL

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Yates Federal

9. WELL NO.

#5

10. FIELD AND POOL, OR WILDCAT

Wolfcat
Burton East, East (Wolfcamp)

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 17, T-20-S, R-29-E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3290 GL, 3306 KB

12. COUNTY OR PARISH

Eddy

13. STATE

NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☐

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☒

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

Wolfcamp Recompletion

2-21-90 MIRU PU. Set CIBP @ 10,287'. Dump 50' cmt on top of CIBP.

2-22-90 Perf w/1 9/16" tbg gun 9493'-9510'. Swb perfs.

2-23-90 Acidize perfs w/250G 15% NEFE acid. Swb back load.

2-24-90 Flow & tst well.

thru

2-26-90

2-27-90 Acidize perfs w/1500G 15% NEFE acid & 25 BS's. Swb back load.

2-28-90 Flow & tst well.

thru

3-17-90

3-18-90 SI for PBU.

thru

4-6-90

4-7-90 Flow & potential well.

thru

4-17-90

18. I hereby certify that the foregoing is true and correct

SIGNED

Jay Pulte
Jay Pulte

TITLE Production Engineer

DATE April 19, 1990

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side