

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.

30-015-24964

5. Indicate Type of Lease

STATE ☒

FEE ☐

6. State Oil & Gas Lease No.

LG-2041

7. Lease Name or Unit Agreement Name

Anthill AAK State

8. Well No.

1

9. Pool name or Wildcat

East Burton Flat Strawn

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL
WELL ☐

GAS
WELL ☒

OTHER

2. Name of Operator

YATES PETROLEUM CORPORATION

3. Address of Operator

105 South 4th St., Artesia, NM 88210

4. Well Location

Unit Letter 0 : 660 Feet From The South Line and 2150 Feet From The East Line

Section 2

Township 20S

Range 29E

NMPM

Eddy

County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

4181.3' GR

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: Isolate & repair casing leak & pump acid ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to clean out paraffin with coiled tubing unit, isolate and repair suspected casing leak and acidize perforations 10626-10726' (Strawn) and return to production as follows:

1. Rig up coiled tubing unit and hot oiler. RIH w/jetting head on coiled tubing unit, rig up hot oiler and wash paraffin out of 2-3/8" tubing with hot water until coiled tubing falls free of paraffin.
2. Nipple down tree, nipple up BOP. Inspect tubing.
3. RIH w/RBP and packer and isolate suspected casing leak. After leak is squeezed and tested or if there is no leak, RIH w/packer and acidize perforations 10626-10726'.
4. Swab/flow back acid load and test well.
5. Put well on pump.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

Rusty Klein

TITLE

Production Clerk

DATE

2-21-95

TYPE OR PRINT NAME

Rusty Klein

TELEPHONE NO. 505/748-1471

(This space for State Use)

ORIGINAL SIGNED BY TIM W. GUM
DISTRICT SUPERVISOR

APPROVED BY

TITLE

DATE

FEB 27 1995

CONDITIONS OF APPROVAL, IF ANY: