

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

YATES PETROLEUM CORPORATION (505) 748-1471

3. Address and Telephone No.

105 South 4th St., Artesia, NM 88210

4. Location of Well (Footage, Sec., T., R., M., of Survey Description)

1980' FSL & 1980' FWL of Section 9-T22S-R24E (Unit K, NESW)

NM OIL CONS COMMISSION
Drawer DD

Artesia NM 88210
FORM APPROVED

Budget Bureau No. 1004-0135

Expires: March 31, 1993

5. Lease Designation and Serial No.

NM-78214

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Anemone ANE Federal #1

9. API Well No.

30-015-28041

10. Field and Pool or Exploratory Area

Undesignated Canyon

11. County or Parish, State

Eddy Co., NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☒ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other _____
- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to abandon Morrow completion and recomplete to Canyon as follows:

1. Rig up wireline. Set standing valve in profile nipple at approximately 9990'. Blow tubing down and load with KCL water.
2. Nipple down tree, nipple up BOP. Unlatch tubing from on/off tool and TOOH. RIH w/RBP and set at 9950'. Test to 2000 psi. TOOH with tubing. NOTE: May set 2 sacks of sand on RBP.
3. Perforate 7855-8006' w/30 holes (1 SPF - Canyon) as follows: 7855, 57, 59, 82, 83, 84, 88, 89, 90, 7908, 11, 12, 13, 27, 28 & 7929' (16 holes) and 7976, 78, 80, 82, 84, 86, 88, 90, 92, 94, 8000, 02, 04 & 8006' (14 holes).
4. TIH with tubing, packer and RBP. Straddle perforations 7976-8006' and acidize w/2000 gallons 20% NEFE HCL acid and ball sealers.
5. Straddle perforations 7855-7929' and acidize with 2000 gallons 20% NEFE HCL acid and ball sealers.
6. Straddle perforations 7855-8006' and acidize with 42000 gallons 20% NEFE HCL acid with ball sealers.
7. Swab. Put well on pump.

RECEIVED

APR 28 1995

OIL CON. DIV.
DIST. 2

14. I hereby certify that the foregoing is true and correct

Signed Rusty T. Allen

Title Production Clerk

Date March 29, 1995

(This space for Federal or State office use)

(ONG. 900.) JOE G. LARA

PETROLEUM ENGINEER

Approved by
Conditions of approval, if any:

Title

Date

4/26/95