

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLI
(Other instructions
reverse side)E*
re-Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM 0558260

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS RECEIVED

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT--" for such proposals.)1. OIL WELL ☐ GAS WELL ☒ OTHER ☐ JAN 31 1980

2. NAME OF OPERATOR

American Quasar Petroleum Co. of New Mexico O. C. D.

3. ADDRESS OF OPERATOR

1000 Midland National Bank Tower, Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1675 FSL & 1675 FWL, Sec 7, T 23 S, R 24 E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4181 Gr.

7. UNIT AGREEMENT NAME

Robina Draw Unit

8. FARM OR LEASE NAME

Robina Draw Unit

9. WELL NO.

#1

10. FIELD AND POOL, OR WILDCAT

Wildcat Morrow GAS

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec 7, T23S, R 24S

12. COUNTY OR PARISH

13. STATE

Eddy

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☐
☐

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

☐
☐
☒(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Set CIBP @ 9865' & capped with 35 ft. of cement.
2. Circulate hole with mud laden fluid - 10#.
3. Cut 5½" csg. @ 6910 ft. Pulled & laid down csg.
4. Run tbg. to 100 ft. inside 5½" csg. Stub & spot a 120 sax plug. WOC & tagged plug @ 6800 ft.
5. Pulled tbg. up hole & spotted the following plugs:
 - a. 6000 - 5800 ft. with 60 sax
 - b. 4150 - 4050 ft. with 45 sax
 - c. 2510 - 2410 ft. with 55 sax
 - d. 7 sax surf. plug

6. Cut off well. Installed dry hole marker. Rigged down.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE P. & A. Contractor

DATE 8-26-78

(This space for Federal or State office use)

ACTING DISTRICT ENGINEER

APPROVED BY

TITLE

DATE JAN 29 1980

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side