

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

RECEIVED

2003 FEB 26 AM 11: 41

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well
☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Roddy Production Co., Inc.

3. Address and Telephone No.

P. O. Box 2221, Farmington, NM, 87499 505-325-5750

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1250' FNL - 2035' FEL, Section 19, T31N, R12W, NMPM

5. Lease Designation and Serial No.
SF078243

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.
Owen No. 2B

9. API Well No.
30 - 045 - 31146

10. Field and Pool, or Exploratory Area
Blanco Mesa Verde

11. County or Parish, State
San Juan, New Mexico

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other _____
- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Roddy Production Co., Inc. cleaned out cement inside the 4 1/2" casing to 3690'. Casing either parted or severely bent at this point. Ran CBL. Shows free pipe. Propose to plug and abandon this well as per the following procedure which was verbally approved by the BLM staff after review of the log and well data.

Plug No. 1: Shoot squeeze holes at 3450'. Set cement retainer at 3350'. Spot cement plug from 3350 - 3450', inside and outside 4 1/2" casing using caliper for outside volume and 50' of excess for inside volume.

Plug No. 2: Shoot squeeze holes at 2352'. Set cement retainer at 2063'. Establish rate through retainer. If circulation with bradenhead is established, spot as one plug from 1747' to 2352' inside and outside 4 1/2" casing. Use caliper for outside volume and 50' excess for inside volumes. If circulation through bradenhead is not possible, do as two plugs with additional squeeze holes perforated at 1847' and an additional retainer at 1747'.

Plug No. 3: Spot inside plug from 1053' to 1153' plus 50' excess.

Plug No. 4: Shoot squeeze holes at 603'. Establish circulation through bradenhead and pump adequate cement volume to bring cement to surface inside and outside 4 1/2" casing. Use caliper volume for outside volume and 50' excess for inside volume.

14. I hereby certify the foregoing is true and correct

Signed Robert E. Fitch

Title Agent

Date February 22, 2003

(This space for Federal or State office use)

Approved by Original Signed: Stephen Mason
Conditions of approval, if any:

Title _____

Date 2/27/03

NMOC