		/		
Form 3160-5 (August 1999)	UNITED STATI DEPARTMENT OF THE BUREAU OF LAND MAN	INTERIOR /	OMB N Expires: N	I APPROVED NO. 1004-0135 ovember 30, 2000
	NDRY NOTICES AND REPO		5. Lease Serial No. NMSF078049	
Do not abando	use this form for proposals t ned well. Use form 3160-3 (Al	o drill or to re-enter an PD) for such proposals.	6. If Indian, Allottee	or Tribe Name
SUBMIT	IN TRIPLICATE - Other instru	ictions on reverse side.	7. If Unit or CA/Agr	eement, Name and/or No.
Type of Well Oil Well	l Other		8. Well Name and No HUGHES C 1).
Name of Operator BP AMERICA PRODU	ICTION CO	MARY CORLEY STORY	9. API Well No. 30-045-07713-	00-S1
3a. Address P. O. BOX 3092 HOUSTON, TX 77253		3b. Phone No tinclude area code Ph: 281.366;4491 JA/\/20 Fx: 281.366;0700		r Exploratory POINT LOOKOUT
	ge, Sec., T., R., M., or Survey Descripti ENE 1157FNL 0883FEL 17540 W Lon	on) On One	SAN JUAN CC	
12. CHEC	K APPROPRIATE BOX(ES) T	O INDICATE NATURE OF I	OPIČE, REPORT, OR OTHE	ER DATA
TYPE OF SUBMISSION)N	ТҮРЕ О	FACTION	
Notice of Intent ☐ Subsequent Report ☐ Final Abandonment N	Convert to Injection	–	☐ Production (Start/Resume) ☐ Reclamation ☐ Recomplete ☐ Temporarily Abandon ☐ Water Disposal ☐ Water Shut-Off ☐ Well Integrity ☐ Other ☐ Workover Operation	
Attach the Bond under which following completion of the testing has been completed. determined that the site is real. BP America Production	oleted Operation (clearly state all pertin directionally or recomplete horizontally the the work will be performed or provio- involved operations. If the operation in Final Abandonment Notices shall be feady for final inspection.) In Company respectfully request per the attached procedure.	y, give subsurface locations and measu le the Bond No. on file with BLM/BLA results in a multiple completion or reco filed only after all requirements, include	ired and true vertical depths of all pert Required subsequent reports shall bompletion in a new interval, a Form 31 ling reclamation, have been completed	inent markers and zones. e filed within 30 days

processing by Sleve Mason on 01/28/2003 (03SXM0228SE)
Title AUTHORIZED REPRESENTATIVE
Date 12/05/2002
FOR FEDERAL OR STATE OFFICE USE
TitlePETROLEUM ENGINEER Date 01/28/20
does not warrant or n the subject lease Office Farmington
PACE

Hughes C #1


T29N-R8W-Sec33 API #: 30-045-07713

Procedure:

- 1. Check anchors. MIRU workover rig.
- 2. If necessary, kill with 2% KCL water. Nipple down WH. NU BOPs.
- 3. Tag for fill and tally OH with 2-3/8" production tubing currently set at 5275'. Visually inspect tbg while POOH.
- 4. TIH with bit and 7" scraper to 4300' and 5-1/2" casing scraper to 5082'.
- 5. RIH with 5-1/2" CIBP. Set CIBP at 5062'.
- 6. RIH with GR log. Log Menefee interval.
- 7. RIH with casing guns. Perforate Menefee formation (correlate to GR log).
- 8. RIH with 2-7/8" frac string and 5-1/2" packer. Set packer at (to be determined from GR log).
- 9. RU frac equipment. Use 2% KCL-N2 foam in fracture stimulation.
- 10. Frac Menefee according to pump schedule.
- 11. Flowback frac fluid immediately.
- 12. Release PKR and POOH with frac string.
- 13. TIH with tubing and bit. Cleanout fill and drill bridge plug set at 5062'. Cleanout fill to PBTD at 5310'. Blow well dry at PBTD.
- 14. Remove one joint of 2-3/8" production tubing and land at 5245'.
- 15. ND BOP's. NU WH. Test well for air. Return well to production.

Hughes C #1

Sec 33, T29N, R8W API #: 3004507713



TD: 5370'

updated: 05/08/2002 mnp