Form 3160-5 (August 1999)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APP	ROVED
OMB NO./10	04-0135
Expires: Novemb	

P	SUNDRY NOTICES AND REPORTS ON WELLS Do not use this form for proposals to drill or to re-enter an abandoned well. Use form 3160-3 (APD) for such proposals.					Lease Serial No. NMSF078390 If Indian, Allouee or Tribe Name			
	SUBMIT IN TRIPLICATE - Other instructions on reverse side.						7. If Unit or CA/Agreement, Name and/or No.		
1.	Type of Well ☐ Oil Well ☑ Gas Well ☐ Oth	8. Well Name and No. JONES A LS 5							
	2. Name of Operator BP AMERICA PRODUCTION CO Contact: MARY CORL E-Mail: corleym					9. API Well No. 30-045-07408-00-S1			
	Address P. O. BOX 3092 HOUSTON, TX 77253	3b. Phone No. Ph: 281.366 Fx: 281.366		e)	10. Field and Pool, or Exploratory BLANCO MESAVERDE				
4. Location of Well (Footage, Sec., T., R., M., or Survey Description) Sec 13 T28N R8W NESW 1550FSL 1800FWL 36.65836 N Lat, 107.63469 W Lon						11. County or Parish, and State SAN JUAN COUNTY, NM			
12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA									
	TYPE OF SUBMISSION	JBMISSION TYPE OF ACTION							
	Notice of Intent	☐ Acidize	□ Deep		_	ion (Start/Resume)	☐ Water Shut-Off		
	Cubsoquent Penert	☐ Alter Casing	_	ure Treat	☐ Reclam		☐ Well Integrity		
	☐ Subsequent Report	☐ Casing Repair	_	Construction	☐ Recomp		☑ Other Workover Operations		
	☐ Final Abandonment Notice	☐ Change Plans	_	and Abandon		arily Abandon	worker operations		
		☐ Convert to Injection ☐ Plug Back				☐ Water Disposal			
	13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.) BP America Production Company respectfully request permission to add pay and stimulate in the Menefee formation within the Mesaverde Pool as per the attached procedure.								
Electronic Submission #16349 verified by the BLM Well Information System For BP AMERICA PRODUCTION CO, sent to the Farmington Committed to AFMSS for processing by Matthew Halbert on 01/21/2003 (03MXH0370SE) Name (Printed/Typed) MARY CORLEY Title AUTHORIZED REPRESENTATIVE									
_	Traine (1 1 sine at 1) pear WiFit Cl	JACE 1	AOTHORIZED REI REGER			REGERTATIVE			
	Signature (Electronic S	Submission)		Date 11/21	/2002				
		THIS SPACE FO	OR FEDERA	L OR STATI	E OFFICE U	SE			
_A ₁	pproved By	ovato		Title		JAN 21	2003 _{Date}		
certi	ditions of approval, if any, are attache ify that the applicant holds legal or eq ch would entitle the applicant to condu	uitable title to those rights in the		Office					
	e 18 U.S.C. Section 1001 and Title 43 ates any false, fictitious or fraudulent					ake to any department or	agency of the United		

Jones A LS #5


T28N-R8W-Sec13 API#: 30-045-07408

Procedure:

- 1. Check anchors. MIRU workover rig.
- 2. If necessary, kill with 2% KCL water. Nipple down WH. NU BOPs.
- 3. Tag for fill and tally OH with 2-3/8" production tubing currently set at 5134'. Visually inspect tbg while POOH.
- 4. TIH with bit and scraper for 5-1/2" casing to 5052'.
- 5. RIH with 5-1/2" CIBP. Set CIBP at 5032'...
- 6. RIH with GR log. Log Menefee interval.
- 7. RIH with casing guns. Perforate Menefee formation (correlate to GR log).
- 8. RIH with frac string and 5-1/2" packer. Set packer at (to be determined from GR log)'.
- 9. RU frac equipment. Use 2% KCL-N2 foam in fracture stimulation.
- 10. Frac Menefee according to pump schedule.
- 11. Flowback frac fluid immediately.
- 12. Release PKR and POOH with frac string.
- 13. TIH with tubing and bit. Cleanout fill and drill bridge plug set at 5032'. Cleanout fill to PBTD. Blow well dry at PBTD.
- 14. Land 2-3/8" production tubing at 5134'.
- 15. ND BOP's. NU WH. Test well for air. Return well to production.

Jones A LS #5

Sec 13, T28N, R8W API #: 3004507408



updated: 04/25/02 mnp

Note: Diagram drawn from Dwights data only.