

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

RECEIVED

2003 MAR 25 AM 11:14

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT--" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well
☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Roddy Production Company, Inc.

3. Address and Telephone No.

P. O. Box 2221, Farmington, New Mexico, 87499 (505)325-5750

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1270' FNL-2020' FEL, Section 19, T31N, R12W, NMPM

5. Lease Designation and Serial No.
SF078243

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.
Owen No. 2C

9. API Well No.
30-045-31398

10. Field and Pool, or Exploratory Area
Blanco Mesa Verde

11. County or Parish, State
San Juan, New Mexico

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☐ Notice of Intent
☒ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Plugged and abandoned this well as follows:

Plug # 1: 3921' to 3703': 10 bbl gel/poz spacer followed by 57 sacks (67.3 cf) of Class B mixed at 15.6 ppg. Displace to spot with 3.5 bbls gel/poz spacer and 48 bbls mud. Good circulation throughout spot. Pull out of hole to 2366'. WOC 4 hours. Trip in hole to tag top of plug at 3703'.

Plug # 2: 2361'-1368': 10 bbl gel/poz preflush followed with 259 sacks (305.62 cf) of Class B mixed at 15.6 ppg. Displace to spot with 3.5 bbls gel/poz spacer and 15 bbls mud. Good circulation throughout spot. Plug on spot at 4:45 AM, 3.11.03.

Plug # 3: 625'-406': Load hole with 11.5 bbls mud. Pump 5 bbl fresh water preflush followed by 57 sacks (67.3 cf) of Class B mixed at 15.5-15.8 ppg. Displace to spot with 1.8 bbls fresh water and 4 bbls mud. Good circulation throughout spot. Plug on spot at 7:00 AM, 3.11.03.

Plug # 4: 375'-156': Load hole with 1.7 bbls fresh water. Pump 6.5 bbl fresh water spacer followed by 57 sacks (67.3 cf) of Class B mixed at 15.5-15.8 ppg. Displace to spot with 2.3 bbls fresh water. Good circulation throughout spot. Plug on spot at 7:30 AM, 3.11.03.

Plug # 5: 63'-surface: Pump 2 bbl fresh water preflush followed by 19 sacks (22.42 cf) of Class B mixed at 14.6 - 15.0 ppg to get cement returns to surface. Displace with 2 bbls fresh water to clear pumps and lines. Good circulation throughout spot. Plug on spot at 8:00 AM, 3.11.03.

Nipple down BOPE. Remove well head. Install casing collar. Move out drilling rig. Will install dry hole marker and clean up location when roads dry out. A sundry advising of progress will be sent in.

14. I hereby certify the foregoing is true and correct

Signed

Robert E. Felt

Title Agent

Date March 18, 2003

(This space for Federal or State office use)

Approved by

Conditions of approval, if any:

Title

ACCEPTED FOR RECORD

APR 02 2003

NMOC

FARMINGTON FIELD OFFICE
BY *sm*