

Submit 3 Copies To Appropriate District
Office
District I
1625 N. French Dr., Hobbs, NM 87240
District II
1301 W. Grand Ave., Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised May 08, 2003

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-045-23030
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name: BOLACK B
8. Well Number 1
9. OGRID Number 167067
10. Pool name or Wildcat GALLEGOS FRUITLAND SAND

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: Oil Well <input type="checkbox"/> Gas Well <input checked="" type="checkbox"/> Other	
2. Name of Operator XTO Energy Inc.	
3. Address of Operator 2700 Farmington Ave., Bldg. K. Ste 1 Farmington, NM 87401	
4. Well Location Unit Letter B : 1190 feet from the NORTH line and 1550 feet from the EAST line Section 28 Township 27N Range 11W NMPM County SAN JUAN	
11. Elevation (Show whether DR, RKB, RT, GR, etc.)	

12. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

XTO Energy Inc. proposes to plug and abandon this well per attached document.



I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Holly C Perkins TITLE REGULATORY COMPLIANCE TECH DATE 6/7/04

Type or print name HOLLY C. PERKINS Telephone No. 505-324-1090

(This space for State use)

APPROVED BY Charles R TITLE DEPUTY OIL & GAS INSPECTOR, DIST. 2 DATE JUN 14 2004
Conditions of approval, if any:

TWD _____
DLC _____

XTO Energy Inc.
Plug and Abandon Procedure

Bolack B #1
1,190' FNL & 1,550' FEL, Unit B, Sec 28, T-27-N, R-11-W
San Juan County, New Mexico

Formation: Gallegos Fruitland Sand

Production Casing: 2-7/8", 6.5# csg @ 1,989'. Cmt'd w/75 sx of 65/35 Pozmix w/2% gel & 100 sx Class B cmt w/0.75% CF4-2 & 12-1/2# gilsonite/sx.

Tubing: N/A.

Perforations: FS: 1,620' – 24' & 1,630' – 38' w/2 JSPF.

Current Status: SI.

Purpose: Plug and Abandon.

1. Notify BLM & NMOCD 24 hrs in advance of pending operations.
2. Test rig anchors. Dig & line blow down pit.
3. MIRU A-Plus Well Service rig. Kill well w/water if necessary. ND WH. NU BOP.
4. Load wellbore with water and establish injection rate. Monitor bradenhead for flow or blow. Drop 12 RCN balls in water and record pump rate and pressure. Confirm there is not a casing leak.
5. Pressure test bradenhead. If bradenhead tests then pump plug #1. If bradenhead does not test, then displace cement to 200'. WOC and perforate casing at 91' and circulate cement to surface out bradenhead.
6. Plug #1 from 1,638' to surface with 80 sxs Type II cement (30% excess) to fill 2-7/8" casing to surface. Do not displace cement. SWI. WOC.
7. ND BOP. Cut off WH below surf casing. Install P&A marker. RDMO A-Plus Well Service rig.
8. Haul all equipment to XTO yard. Reclaim loc per BLM specs.