State of New Mexico Submit 3 Copies Form C-103 Energy, Minerals and Natural Resources Department to Appropriate Revised 1-1-89 District Office OIL CONSERVATION DIVISION DISTRICT I P.O. Box 2088 P.O. Box 1980, Hobbs, NM 88240 WELL APLNO Santa Fe, New Mexico 8750 DISTRICT II 30-031-20721 P.O. Drawer DD, Artesia, NM 88210 Indicate Type of Lease DISTRICT III STATE FEE 1000 Rio Brazos Rd., Aztec, NM 87410 e Oil & Gas Lease No LH-3667 SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUE BACK Lease Name or Unit Agreement Name DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT **STATE** (FORM C-101) FOR SUCH PROPOSALS.) 1. Type of Well WELL OTHER 2. Name of Operate ROBERT L. BAYLESS 9 Pool name or Wildcat 3. Address of Operator P.O. BOX 168 FARMINGTON, NM 87499 North Miguel Creek Field 4. Well Location 330 **SOUTH** WEST Feet from The Unit Lette Feet from the 16N McKINLEY Township Range NMPM Section County (Show whether DF, RKB, RT, GR, etc.) Elevation 6588 GL Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data 11 NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PLUG AND ABANDON ALTERING CASING PERFORM REMEDIAL WORK REMEDIAL WORK CHANGE PLANS COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT TEMPORARILY ABANDON CASING TEST AND CEMENT JOB PULL OR ALTER CASING OTHER: OTHER: (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed 12. Describe Proposed or Completed Operations work) SEE RULE 1103. Robert L. Bayless plugged and abandoned this well 5/29/03. The procedure is attached. I hearby certify that the information above is tr **ENGINEER** 6/19/03 SIGNATURE TITLE DATE (505) 327-2659 TYPE OR PRINT NAME om McCarthy TELEPHONE NO BEFUTY OIL & GAS HISTLETOR, DIST. #3 (This space for State Use) APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

Robert L. Bayless Plug and Abandon Report

State No. 1 330' FSL & 990' FWL, Section 16, T16N, R6W McKinley County, NM

5/29/2003: Rig up JC Well Service. Pressure test tubing, OK. Trip out rods and pump, and used rod count as tally. Trip in and tag PBD at 1193'. Roll hole with water. Mix and spot 23 sack bottom plug at 1193'. Trip out tubing and WOC. Trip in and tag plug at 992'. Pressure test casing to 200 PSI, OK. Mix and pump 6 sack surface plug at 50'. Rigged down. Class B cement was used.

Top off cement. Installed abandonment marker and backfilled pit. Cleaned up location.