Submit 3 Copies To Appropriate District State of New Mex	kico Form C-103				
Office District I Energy, Minerals and Natur	al Resources Revised March 25, 1999				
1625 N. French Dr., Hobbs, NM 88240 District II 811 South First Artesia, NM 88210 OIL CONSERVATION	WELL API NO. 30-045-07135				
811 South First, Artesia, NM 88210 OIL CONSERVATION District III 1220 South St. France	5. Indicate Type of Lease				
1000 Rio Brazos Rd., Aztec, NM 87410 District IV Santa Fe, NM 87	SIAIE FEE				
1220 S. St. Francis Dr., Santa Fe, NM 87505	WW. 13. 15. 25 P.				
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLU DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM (**10)) FOI PROPOSALS.) 1. Type of Well: Oil Well	(Also filed on BLM Form 3160-5 Federal Lease SF - 03549)				
2. Name of Operator BP America Production Company Attn: Mary Corley	% . Well No.				
3. Address of Operator	9. Pool name or Wildcat				
P.O. Box 3092 Houston, TX 77253 4. Well Location	Blanco Mesaverde/Blanco Pictured Cliffs				
Unit Letter L 1750 feet from the South line and 990 feet from the West line					
Section 30 Township 28N Range 08W NMPM San Juan County					
10. Elevation (Show whether DR, RKB, RT, GR, etc.) 5854' GR					
11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data					
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK □ PLUG AND ABANDON □	SUBSEQUENT REPORT OF: REMEDIAL WORK				
TEMPORARILY ABANDON	COMMENCE DRILLING OPNS. PLUG AND				
PULL OR ALTER CASING	ABANDONMENT ABANDONMENT CASING TEST AND				
COMPLETION	CEMENT JOB				
OTHER: Downhole Commingle	OTHER:				
 Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation. BP America Production Company request permission to convert the subject well from a dual string completion to a single string completion, add pay in the Mesaverde and commingle production downhole from the Blanco Pictured Cliffs & Blanco Mesaverde Pools as per the attached procedure. 					
The Blanco Pictured Cliffs (72359) & the Blanco Mesaverde (72319) Pools are Pre-Approved Pools for Downhole Commingling per NMOCD order R-11363.					
The working, overriding, and royalty interest owners in the proposed commingled pools are identical; therefore, no notification of this application need be submitted via certified mail.					
Production is proposed to be allocated based on actual production from tattached allocation chart.	poth the Pictured Cliffs and Mesaverde Pools as reflected on the				
Commingling Production Downhole in the subject well from the proposed production.	Pools with not reduce the value of the total remaining				
I hereby certify that the information above is true and complete to the b	est of my knowledge and belief.				
SIGNATURE //////// TITLE Sr. Regulatory Analyst DATE 04/22/2003					
Type or print name Mary Corley (This space for State use) Telephone No. 281-366-4491					
	DIL & GAS PERFECTOR, DIST. B3 APR 2 3 2003				

√

Florance C LS 006 PC/MV

Sec 30, T28N, R8W API# 3004507135

- 1. Check anchors. MIRU workover rig.
- 2. Blow down well. Kill with 2% KCL water ONLY if necessary. ND WH and NU BOP's.
- 3. Tag for fill and TOH with 1-1/4" short string set at 2179'. LD production tbg.
- 4. TOH with 2-3/8" long string set at 4460'.
- 5. Mill 5 1/2" production packer set at 2313'.
- 6. Clean out to PBTD at 4589'.
- 7. RIH and set CIBP at 4350'. Test casing to 2500 psi.
- 8. RIH w/ GR log.
- 9. RIH with 3-1/8" casing guns 1 SPF 120 deg phasing with Schlumberger's Prospector, select-fire charge. Perforate Menefee (correlate to GR log).
- 10. RU frac equipment. Use 2% KCL-N2 foam in fracture stimulation.
- 11. Frac Menefee according to pump schedule.
- 12. Flowback frac fluid immediately.
- 13. POH with frac string.
- 14. RIH with work string and bit. Drill out CIBP set at 4350'. Continue clean out hole to PBTD at 4589'. Blow well dry with air package at PBTD. POH with work string.
- 15. Rabbit tubing and RIH with 2-3/8" production tubing (with X-nipple and plug on bottom). Replace any joints that fail the pressure test.
- 16. Land 2-3/8" production tubing at 4540'.
- 17. Swab water from tubing with the sandline.
- 18. RU slickline unit. Run gauge ring for 2-3/8" tubing. Pull plug. RD slickline unit.
- 19. ND BOP's. NU WH. Test well for air. Return well to production.

Allocation Based on Year 2002 Production					
Pool	Oil	%	Gas	%	
Pictured Cliffs	0	0%	8628	19%	
Mesaverde	98	100%	35852	81%	

Florance C LS 006 PC/MV

API# 3004507135 Sec 30, T28N, R8W

