UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT



AUG 16 2011

Sundry Notices and Reports on Wells			Farmington Field Office Bureau of Land Managemen		
1. Type of Well			5. 6.	Lease Number SF-077875 If Indian, All. or	
GAS			7.	Tribe Name Unit Agreement Name	
2. Name of Operator BURLINGTON RESCURCES OIL	& GAS COMPANY LP				
3. Address & Phone No. of Operator			8.	Well Name & Number Rowley 3	
PO Box 4289, Farmington, NM 87499 (505) 326-9700			9. —	API Well No.	
4. Location of Well, Footage, Sec., T, R, M Unit I (NESE), 1650' FSL & 800' FEL, Section 7, T27N, R10W, NMPM			10.	30-045-06647 Field and Pool Basin FC / Fulcher Kutz PC	
			11.	County and State San Juan, NM	
12. CHECK APPROPRIATE BOX	TO INDICATE NATURE OF	NOTICE REPORT (THER I)ATA	
	e of Action X Abandonment Recompletion	Change of Plans New Construction		Other -	
X Subsequent Report Final Abandonment	Plugging Casing Repair Altering Casing	Non-Routine Fracturing Water Shut off Conversion to Injection		147576171819202723	
13. Describe Proposed or Comple The subject well was P&A'd on 7/6/2	•	and the attached report.		2 RECEIVED TO	
	•			OIL CONS. DIV. DIST. 3	
14. I hereby certify that the foreg	oing is true and correct.				
Signed Angelal T	afoya Crystal Tafoya	Title: Staff Regu	atory Tec	Chnician Date 8 16 11	
(This space for Federal or State Offi APPROVED BY	Title			Date	
CONDITION OF APPROVAL, if a Trile 18 U S C Section 1001, makes it a crime for any perso the United States any false, fictitious or fraudulent statement	n knowingly and willfully to make any department or age		ASSE	PTED FOR RECORD	
			. ,	AUS 17 2011	
			FARMI	AGTON FIELD OFFICE	

A-PLUS WELL SERVICE, INC.

P.O. BOX 1979 Farmington, New Mexico 87499` 505-325-2627 * fax: 505-325-1211

Burlington Resources Oil & Gas Company LP Rowley #3

July 06, 2011 Page 1 of 1

1650' FSL & 800' FEL, Section 7, T-27-N, R-10-W San Juan County, NM Lease Number: SF-077875 API #30-045-06647

Plug and Abandonment Report

Notified NMOCD and BLM on 6/28/11

Plug and Abandonment Summary:

- 6/28/11 Rode rig and equipment to location. Set up entrance signs. Spot in and RU rig and equipment. SDFD.
- Open up well and blow down 35 PSI on 2-7/8" casing. Pump 20 bbls of water down casing to kill well. NU companion flange and BOP; test. RU Basin Wireline. Round trip 2-7/8" Basin gauge ring to 1500'. RIH and set 2-7/8" wireline CIBP at 1483'. Run CBL from 1483' to surface. Found TOC from 805' to 430'. Wait on orders. Dig out bradenhead valve and remove 2" cemented outlet. B. Powell, NMOCD and L. Pixley, BLM approved procedure change. Tally and TIH with A-Plus tubing workstring; tag BP at 1483'.

Plug #1 with CIBP at 1483', spot 16 sxs Class B cement (18.88 cf) inside casing above BP to 900' to cover the Fruitland interval.

Circulate casing clean. PUH and WOC. SI well. SDFD.

6/30/11 Open up well; no pressures. TIH and tag cement at 1065'. Load casing with 6 bbls of water and circulate about 1 bbl of green cement to surface.

Plug #2 spot 17 sxs Class B cement with 2% CaCl₂ (20.06 cf) inside casing from 1065' to 450' to cover the Kirtland and Ojo Alamo tops.

PUH to 490' and circulate casing clean with additional 5 bbls of water; circulate ½ bbl to 1 bbl of cement out casing.

TOH with tubing and LD plugging sub. SI well and WOC. RIH with wireline and tag cement at 585'. Perforate 3 bi-wire squeeze holes at 176'. Establish circulation out IM casing with 5 bbls of water.

Plug #3 with 40 sxs Class B cement (47.2 cf) down 2-7/8" casing from 176' to surface, circulate good cement out casing valve and IM casing.

SI well and WOC. ND BOP. Dig out wellhead. Monitor wellhead. Issue Hot Work Permit. Cut off wellhead. Found cement at surface in 5." X 8-5/8" annulus, down 8' in 2-7/8" x 5-1/2" annulus and down 20' in 2-7/8" casing.

Plug #4 spot 36 sxs Class B cement (42.48 cf) to top off casing and annulus, then install P&A marker. SDFD.

7/06/11 RD. MOL.

J. Yates, Conoco representative, was on location. Larry Pixley, BLM representative, was on location.