04

UNITED STATES DEPARTMENT OF THE INTERIOR **BUREAU OF LAND MANAGEMENT**

RECEIVED

SEP 27 2011

			Farmington Field Office Bureau of Land Managemen.		
Sundry Notices and Reports on Wells					
· · · · · · · · · · · · · · · · · · ·			5.	Lease N	(umber
				SF-0784	
1. Type of Well			6.		n, All. or
GAS				Tribe N	ame
			7.		reement Name
2. Name of Operator				San Jua	n 29-7 Unit
BURLINGTON					
RESOURCES OIL & GAS COMP	'ANY LP		0	Wall Na	C. Nivember
3. Address & Phone No. of Operator			8. Well Name & Numb San Juan 29-7 Unit 1		
-	20< 0500		•		
PO Box 4289, Farmington, NM 87499 (505) 326-9700		9.	API We	ell No.	
4. Location of Well, Footage, Sec., T, R, M				30-039-2	25710
Unit A (NENE), 1085' FNL & 1040' FEL, Section 9, T29N, R7W, NMPM		10.	Field an	ıd Pool	
			Blanco Pictured Cliffs		
·			11.	County and State	
					iba, NM
Type of Submission Notice of Intent X Abandor Recompl X Subsequent Report Plugging Casing R Altering	letion	Change of Plans New Construction Non-Routine Fracturing Water Shut off Conversion to Injection		Other —	
13. Describe Proposed or Completed Operations	S				
Γhe subject well was P&A'd on 8/31/2011 per the a		•			
·	•				
					•
14. I hereby certify that the foregoing is true and	d correct.				
Signed <u>arystal</u> Taloya	Crystal Tafoya Title: Staff Regula		atory Technician Date 9/27/20		
This space for Federal or State Office use)					
ÀPPROVED BY	Title			Date	
CONDITION OF APPROVAL, if any:					
Fitle 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully the United States any false, fictitious or fraudulent statements or representations as to					

ASSEPTED FOR RECORD

SEP 28 2011



A-PLUS WELL SERVICE, INC.

P.O. BOX 1979

Farmington, New Mexico 87499 505-325-2627 * fax: 505-325-1211

ConocoPhillips
San Juan 29-7 Unit #155

August 31, 2011 Page 1 of 1

1085' FNL & 1040' FEL, Section 9, T-29-N, R-7-W Rio Arriba County, NM Lease Number: NMSF-078423 API #30-039-25710

Plug and Abandonment Report Notified NMOCD and BLM on 8/29/11

Plug and Abandonment Summary:

Road rig and equipment to location. LO/TO equip on location. Spot rig at WH. Check derrick for safety pins. RU rig and cement. Check PSI on well: casing 160#, BH was open. No tubing in well. Layout relief lines to pit. Blow well down. RU WL (A-Plus). Round trip 2.80" gauge ring to 2950'. TIH and set 3-½" P-W CIBP at 2935'. ND WH. NU 3-½" wellhead and BOP, test. PU A-Plus 1-½" IJ, 2.3" tubing and tag CIBP at 2935'. Load the BH with 1/8 bbls water. Pressure test BH to 300# for 5 min. Load the hole with 14 bbls water and circulate clean with another 13 bbls, total 27 bbls. Test casing to 800# for 10 minutes.

Plug # 1 with CIBP at 2935', mix & pump 14 sxs (16.5 cf) Class B cement inside casing from 2935' to 2597' to cover the Pictured Cliffs and Fruitland tops. PUH to 2229'. SI well. SDFN.

. 8/31/11 Open up well; no pressures. Load casing with 1-3/4 bbls of water.

Plug # 2 mix and pump 17sxs (20.0 cf) Class B cement inside casing from 2229' to 1839' to cover the Kirtland and Ojo Alamo tops. LD tubing to 692'. Load the hole with 2 ½ bbls water.

Plug # 3 mix and pump 40 sxs (47.2 cf) Class B cement inside casing from 692' to surface to cover the Nacimiento top with good cement returns out casing valve. TOH and LD the tubing. ND BOP. Dig out WH. Write hot work permit. Monitor well. Cut off WH. Run 100' tally tape down BH; did not tag cement. PU 4 jts 1 ¼" tubing and stack out in BH at 126'.

Plug # 4 mix and pump 49 sxs cement and top off 8 5/8" & 3 ½" casings and install P&A marker.

RD Rig & cement equip. MOL. Remove LO/TO equip. Leave 4 anchors due to dry weeds SDFN.

Jimmy Morris, MVCI representative, was on location. Mike Gilbreath, BLM representative, was on location.