

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

RECEIVED

FORM APPROVED
OMB No. 1004-0137
Expires July 31, 2010

JUN 20 2012

Case Serial No

NM-0702

SUNDRY NOTICES AND REPORTS ON WELLS
Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.

If Indian, Allottee or Tribe Name

SUBMIT IN TRIPLICATE - Other instructions on page 2.

1 Type of Well

☐ Oil Well

☒ Gas Well

☐ Other

7. If Unit of CA/Agreement, Name and/or No

8 Well Name and No

Wilson 1

2 Name of Operator

Burlington Resources Oil & Gas Company LP

9. API Well No

30-045-07701

3a Address

PO Box 4289, Farmington, NM 87499

3b. Phone No. (include area code)

(505) 326-9700

10 Field and Pool or Exploratory Area

Fulcher Kutz Pictured Cliffs

4 Location of Well (Footage, Sec., T., R., M., or Survey Description)

Surface Unit H (SENE), 1650' FNL & 1290' FEL, Sec. 31, T29N, R10W

11. Country or Parish, State

San Juan, New Mexico

12. CHECK THE APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION			
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Acidize	<input type="checkbox"/> Deepen	<input type="checkbox"/> Production (Start/Resume)	<input type="checkbox"/> Water Shut-Off
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Alter Casing	<input type="checkbox"/> Fracture Treat	<input type="checkbox"/> Reclamation	<input type="checkbox"/> Well Integrity
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> New Construction	<input type="checkbox"/> Recomplete	<input type="checkbox"/> Other
	<input type="checkbox"/> Change Plans	<input checked="" type="checkbox"/> Plug and Abandon	<input type="checkbox"/> Temporarily Abandon	
	<input type="checkbox"/> Convert to Injection	<input type="checkbox"/> Plug Back	<input type="checkbox"/> Water Disposal	

13. Describe Proposed or Completed Operation Clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleat in a new interval, a Form 3160-4 must be filed once Testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection.)

Burlington Resources requests permission to P&A the subject well per the attached procedure, current and proposed wellbore schematics.

Notify NMOCD 24 hrs
prior to beginning
operations

RCVD JUN 27 '12
OIL CONS. DIV.

DIST. 3

* Run CBL prior to cementing plug #1

14. I hereby certify that the foregoing is true and correct. Name (Printed/Typed)

Dollie L. Busse

Title Staff Regulatory Technician

Signature

Date

6/20/12

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by

Original Signed: Stephen Mason

Title

Date

JUN 22 2012

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office

Title 18 U S C Section 1001 and Title 43 U S C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instruction on page 2)

NMOCD

ConocoPhillips

WILSON 1

Expense - P&A

Lat 36° 41' 6.72" N

Long 107° 55' 13.764" W

PROCEDURE

This project requires a NMOCD C-144 CLEZ Closed-Loop System Permit for the use of an A-Plus steel tank to handle waste fluids circulated from the well and cement wash up.

1. Hold pre-job safety meeting. Comply with all NMOCD, BLM, and COPC safety and environmental regulations. Test rig anchors prior to moving in rig.
2. MIRU work over rig. Check casing, tubing, and bradenhead pressures and record them in Wellview.
3. When an existing primary valve (i.e. casing valve) is to be used, the existing piping should be removed and replaced with the appropriate piping for the intended operation.
4. RU blow lines from casing valves and begin blowing down casing pressure. Kill well with water, as necessary, and at least pump tubing capacity of water down tubing.
5. ND wellhead and NU BOPE. Pressure and function test BOP. PU and remove tubing hanger.
6. TOOH with tubing/rods (per pertinent data sheet). LD tubing bailer (if applicable).

Rods:	No	Size:		Length:	
Tubing:	Yes	Size:	1.66"	Length:	1,862'
Packer:	No	Size:		Depth:	

If this well has rods or a packer, then modify the work sequence in step #2 as appropriate. Round trip casing scraper through deepest perforation or as deep as possible.

All cement volumes use 100% excess outside pipe and 50' excess inside pipe. The stabilizing wellbore fluid will be 8.3 ppg, sufficient to balance all exposed formation pressures. All cement will be ASTM Type II mixed at 15.6 ppg with a 1.18 cf/sk yield.

7. Plug 1 (Pictured Cliffs/Fruitland, 1235-1750', 24 Sacks Class B Cement)

RIH and set 3 1/2" CR at 1,750'. Load casing and circulate well clean. Pressure test tubing. Mix 24 sxs Class B cement and spot above CR to isolate Pictured Cliff perforations and top and Fruitland top. POOH.

8. Plug 2 (Kirtland/Ojo Alamo, 550-805', 13 Sacks Class B Cement)

RIH w/ wireline and run CBL. Based on TOC in CBL, adjust plugs as needed. TIH w/ tbq and load casing if needed. Mix 13 sxs Class B cement and spot a balanced plug inside casing to cover Kirtland and Ojo Alamo tops. POOH. *plug outside 5 1/2" casing from 605'-550'*


9. Plug 3 (Surface, 0-187', 87 Sacks Class B Cement)

RIH w/ wireline. Perforate 3 HSC holes at 187'. Establish circulation through squeeze holes. Mix 87 sxs Class B cement. Sqz Class B cement into HSC holes and circulate cement to surface through bradenhead to isolate the surface casing & bradenhead. Shut in well and WOC. Tag cement top and top out cement as necessary.

10. Nipple down BOP and cut off casing below the casing flange. Install P&A marker with cement to comply with regulations. Rig down, move off location, cut off anchors, and restore location.

District SOUTH	Field Name FULCHER KUTZ PC (GAS)	API / UWI 3004507701	County SAN JUAN	State/Province NEW MEXICO	Edit
Original Spud Date 12/15/1955	Surface Legal Location NMPM,031-029N-010W	East/West Distance (ft) 0.00	East/West Reference	North/South Distance (ft) 0.00	North/South Reference

Well Config: - Original Hole, 6/15/2012 2:41:38 PM




Schematic

ConocoPhillips

Well Name: WILSON #1

API / UWI	Surface Legal Location	Field Name	License No.	State / Province	Well Configuration Type	Edit
3004507701	NMPM,031-029N-010W	FULCHER KUTZ PC (G...		NEW MEXICO		
Ground Elevation (ft)	Original KB/RT Elevation (ft)	KB-Gravel Distance (ft)	KB-Casing Flange Distance (ft)	KB-Tubing Hanger Distance (ft)		
5,598.00	5,608.00	10.00				

Well Config: Original Hole: 1/1/2020



**UNITED STATES DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
FARMINGTON DISTRICT OFFICE
6251 COLLEGE BLVD.
FARMINGTON, NEW MEXICO 87402**

Attachment to notice of
Intention to Abandon:

Re: Permanent Abandonment
Well: 1 Wilson

CONDITIONS OF APPROVAL

1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal and Indian Lease."
2. Farmington Office is to be notified at least 24 hours before the plugging operations commence (505) 564-7750.
3. The following modifications to your plugging program are to be made:
 - a) Place the Kirtland/Ojo Alamo plug from 805' – 550' inside the 3 ½" and outside the 5 ½" casing.

You are also required to place cement excesses per 4.2 and 4.4 of the attached General Requirements.

Office Hours: 7:45 a.m. to 4:30 p.m.