

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or reenter an abandoned well. Use Form 3160-3 (APD) for such proposals.

FORM APPROVED  
OMB No. 1004-0135  
Expires July 31, 1996

5. Lease Serial No.

Contract 200

6. If Indian, Allottee or Tribe Name

Jicarilla Apache

7. If Unit or CA/Agreement, Name and/or N

**SUBMIT IN TRIPLICATE - Other instructions on reverse side**

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Benson-Montin-Greer Drilling Corp.

3a. Address

4900 College Blvd., Farmington, NM 87402

3b. Phone No. (include area code)

505-325-8874

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660' FNL & 825' FWL

Sec. 21-T27N-R1W

8. Well Name and No.

Jicarilla 200 #1 (D-21)

9. API Well No.

30-039-08126

10. Field and Pool, or Exploratory Area

West Puerto Chiquito Mancos

11. County or Parish, State

Rio Arriba, New Mexico

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Acidize <input type="checkbox"/> Deepen <input type="checkbox"/> Production (Start/Resume) <input type="checkbox"/> Water Shut-Off
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Alter Casing <input type="checkbox"/> Fracture Treat <input type="checkbox"/> Reclamation <input type="checkbox"/> Well Integrity
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Casing Repair <input type="checkbox"/> New Construction <input type="checkbox"/> Recomplete <input type="checkbox"/> Other
	<input type="checkbox"/> Change Plans <input checked="" type="checkbox"/> Plug and Abandon <input type="checkbox"/> Temporarily Abandon
	<input type="checkbox"/> Convert to Injection <input type="checkbox"/> Plug Back <input type="checkbox"/> Water Disposal

13. Describe Proposed or Completed Operations (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleat in a new interval, a Form 3160-4 shall be filed once Testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)

Benson-Montin-Greer Drilling Corporation proposes to plug and abandoned the Jicarilla 200 #1 (D-21) per attached procedures.

14. I hereby certify that the foregoing is true and correct

Name (Printed/Typed)

Trudy Grubelnik

Title

Production Technician

Signature

Date

June 28, 2005

THIS SPACE FOR FEDERAL OR STATE USE

Approved by

Original Signed: Stephen Mason

Title

Date

JUL 08 2005

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on reverse)

NMOCGD

PROPOSED P&A PROCEDURE  
Benson-Montin-Greer Drlg. Corp., Inc.  
Jicarilla 200 #1 (D-21)  
660' FNL-825' FWL Sec. 21-T27N-R1W

1. MIRU A Plus Well Service. RU Basin Wire Line Co., run CBL from PBSD (7100') to cement top estimated at 5000'. GIH with 2 7/8" tbg, set 5 1/2" cement retainer at 7000', squeeze Niobrara perms with 50 sks regular cement. → place cement on top retainer to 6615' & excess fall to 5530'-5430'
2. Assuming Mesaverde Zone is covered with cement (top of Mesaverde is 5480") → 3440' perf squeeze holes at base of Pictured Cliffs at 3600', set cement retainer at 3575', attempt to circulate back to surface. If successful, pump enough cement (5.12 ft fill-up per sk of cement) to cover Ojo Alamo at 2800'. If unable to obtain circulation, squeeze with 25 sks cement, perf additional squeeze holes above Ojo Alamo at 2825', set cement retainer at 2850', squeeze with 25 sks cement.
3. Perf additional squeeze holes at 360' (50' below bottom of surface csg), circulate cement to surface, leaving cement inside 7'.
4. Cut-off 7 5/8" at 3' below ground level, set P&A marker, restore surface to original conditions.

Nacimiento plug 1616' - 1516'


Well bore schematic attached

sdo 6/20/05

plug #1 7000' - 6615' Gallup  
#2 5530' - 5430' Mesaverde  
#3 3440' - 3122' PC/Fr & Ojo Alamo  
#4 1616' - 1516' Nacimiento  
#5 360' - surface

Spud 6/59/66

**B-M-G DRILLING CORP., INC.**  
**JIC 200 #1 (D-21) API #30-039-08126**  
**660' FNL-825' FWL, SEC 21-T27N-R1W**



sdo 6/27/05