

Submit 1 Copy To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
1301 W. Grand Ave., Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
1220 S. St. Francis Dr., Santa Fe, NM  
87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
October 13, 2009

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

WELL API NO. <b>30-031-20150</b>
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name <b>Santa Fe Railroad</b>
8. Well Number #23
9. OGRID Number <b>291567</b>
10. Pool name or Wildcat <b>Hospah</b>

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☐ Gas Well ☒ Other ☐

2. Name of Operator  
**Dominion Production Co. LLC**

3. Address of Operator  
**1414 W. Swann, Suite 100, Tampa Florida 33606**

4. Well Location  
Unit Letter C : 5 feet from the North line and 1330' feet from the East line  
Section 7 Township 17N Range 8W NMPM McKinley County

11. Elevation (Show whether DR, RKB, RT, GR, etc.)  
**6900' GR**

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐  
DOWNHOLE COMMINGLE ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ P AND A ☐  
CASING/CEMENT JOB ☐

OTHER: ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Please see the attached plugging procedure.


Notify NMOCD 24 hrs  
prior to beginning  
operations

RCVD SEP 3 '14  
OIL CONS. DIV.

# Bring top of plug #1 up to 1300'  
# Submit before and after schematics as required by rule 19.15.25.9.B DIST. 3

Spud Date:

Rig Release Date:



I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE [Signature] TITLE President DATE: 7-28-2014

Type or print name David Burns E-mail address: davidburns@dominionproduction.com PHONE: 918-260-7620  
For State Use Only

APPROVED BY: [Signature] TITLE AV DATE 9/12/14  
Conditions of Approval (if any):

**Plug and Abandonment Plan**  
**Dominion Production Co, LLC.**  
**SFRR #23**  
**API# 3003120150**  
**1330' FWL & 5' FNL**  
**Sec. 7 T17N R8W**  
**McKinley County, New Mexico**

1. Comply with all OCD, DPC and contractor safety rules and regulations. Hold safety meetings each morning.
2. MIRU, Check Braden head for pressure. Bleed pressure off of well if necessary.
3. Rods: Yes   X   , No        , Unknown        .  
Tubing: Yes   X   , No        , Unknown        , Size   2-7/8"   , Length   1541'    
Packer: Yes   X   , No        , Unknown        , Type   unknown, possibly set at 1541'

If this well has rods or a packer, then modify the work sequence in step #2 as appropriate.

4. **Plug # 1- (Upper Gallup Sand 1469' – 1359')** Round trip 4.5" gauge ring to 1469', or as deep as possible. RIH and set 4.5" wireline CR at 1469'. Mix and Pump 12 Sks, Class B Cement to cover Gallup. TOH.
5. **Plug #2-(Mancos Plug/ Surface Plug, 550'-Surface)** MIRU Wireline Truck, RIH with CBL Tool, from 1400' to Surface. Shoot 3-3/8" Squeeze holes at approx. 550', actual to be determined from Bond Log.  
MIRU Pump Truck, Pump Approx. 20 bbls Fresh Water to establish circulation through Squeeze Holes. At Successful Circulation, Mix and pump 125 down 4.5" casing and circulate good cement to surface.
6. Cut off well 3' below ground and install P&A marker per OCD specifications. RD, cleanup MOL.
7. ND BOP and cut off wellhead below surface casing flange. Install P&A marker with cement to comply with regulations. Record GPS coordinate for P&A marker on tower report. Photograph P&A marker in place. Cut off anchors and clean up location. Restore location per NMOCD stipulations.

