		ľ -				
Form 3160-5 (February 2005)	UNITED ST DEPARTMENT OF T BUREAU OF LAND M	HE INTERIOR	FEB 13 2	FORM APPROVED OMB No. 1004-0137 Expires: March 31, 2007		
			- ·	5. Lease-Serial No.		
	IDRY NOTICES AND REF		r on	N0-G=1401-1868		
	l well. Use Form 3160-3 (6. If Indian, Allottee or Tribe Name		
······································				791-45		
	SUBMIT IN TRIPLICATE O	ther instructions on page 2.		7. If Unit of CA/Agreement, Name ar	1d/or No.	
1. Type of Well	Gas Well Other			8. Well Name and No. CHACO 2308-08A #285H		
2. Name of Operator			· · · · · · · · · · · · · · · · · · ·	9. API Well No.		
WPX Energy Production	n, LLC			30-045-35643		
<u> </u>	ec, NM 87410	3b. Phone No. <i>(include are</i> 505-333-1816	ea code)	10. Field and Pool or Exploratory Area NAGEEZI GL/BASIN MC		
4. Location of Well <i>(Foot</i> SHL: 328' FNL & 334' F BHL: 380' FSL & 230' FV		ption)		11. Country or Parish, State SAN JUAN, NM		
12. 0	CHECK THE APPROPRIATE BOX	(ES) TO INDICATE NATUR	E OF NOTICE, RI	EPORT OR OTHER DATA		
TYPE OF SUBMISS	ION	ТҮ	PE OF ACTION			
Notice of Intent	Acidize	Deepen	Start/Resu	1 Water Shut_Off		
	Alter Casing	Fracture Treat New Construction	Reclar	mation Well Integrity		
Subsequent Report	Change Plans	Plug and Abandon	Tempo	CHANGE OF OPS P	LANS	
Final Abandonment N		Plug Back	Abandon Water	Disposal		
duration thereof. If th all pertinent markers subsequent reports m recompletion in a new	e proposal is to deepen directionally and zones. Attach the Bond under w ust be filed within 30 days following	or recomplete horizontally, g hich the work will be perform completion of the involved o led once testing has been comp	ive subsurface loca ed or provide the E perations. If the op pleted. Final Abance	date of any proposed work and approxin tions and measured and true vertical de 3 ond No. on file with BLM/BIA. Requin eration results in a multiple completion 1 onment Notices must be filed only afte ready for final inspection.)	pths of red or	
WPX plans to adjust	the surface depth from 400' to	o~320". Attached is an	updated Opera	tional Plan.		
CONDITIONS OF		RECEIVED	•	M'S APPROVAL OR ACCEPTANCE FION DOES NOT RELIEVE THE E		
	/			ERATOR FROM OBTAINING ANY	OTHER	
Adhere to previously is	sued stipulations	FEB 2 0 2015		THORIZATION REQUIRED FOR FEDERAL AND INDIAN LANDS	OPERATIONS	
14. I hereby certify that the	foregoing is true and correct.	NIMOCD				
Name (Printed/Typed)	- n			NG TECH III		
Signature			ate 2/11/15	······		
	THE SPACE F	OR FEDERAL OR ST		1		
the applicant holds legal or e	y, are attached. Approval of this notice equitable title to those rights in the subj	e does not warrant or certify that ect lease which would entitle th	e Office FF	ineer Date 2-17-20	>/5	
	and Title 43 U.S.C. Section 1212, ma		wingly and willfully	to make to any department or agency of t	the	
	tious or fraudulent statements or repre	sentations as to any matter with	In its jurisdiction.	· · · · · · · · · · · · · · · · · · ·		
(Instructions on page 2)			₽	- h		

7

Ŋ

KP

Copyright 2006 Forms in Word (<u>www.formsinword.com</u>)#For individual or single-branch use only.

4

WPXENERGY.

WPX ENERGY

Operations Plan

(Note: This procedure will be adjusted on site based upon actual conditions)

DATE:		FIELD:	Nageezi Gallup / Basin Mancos
WELL NAME:	Chaco 2308-08A 285H	SURFACE:	BLM
SH Location:	NENE Section 8 T23N R8W.	ELEVATION:	6846' GR
BH Location:	SWSW Section 5 T23N R8W San Juan Co., NM	MINERALS:	BLM

MEASURED DEPTH: 10,458'

I. <u>GEOLOGY:</u> Surface formation – Nacimiento

A.	FOR	MA ⁻	ΓΙΟΝ	TOPS:	(KB)

TONIATION TOPS. (RB)						
Name	MD	TVD ·	Name	MD	TVD	
	•					
Ojo Alamo	1007	1005	Point Lookout	4078	3955	
Kirtland	1195	1190	Mancos	4274	4147	
Picture Cliffs	1589	1569	Kickoff Point	4738	4608	
Lewis	1709	1684	Top Target	5495	5202	
Chacra	1980	1943	Landing Point	5816	5275	
Cliff House	3111	3027	Base Target	5816	5275	
Menefee	3164	3077				
			TD .	10458	5143	

- B. MUD LOGGING PROGRAM: Mudlogger on location from surface csg to TD.
- C. LOGGING PROGRAM: LWD GR from surface casing to TD.
- D. **NATURAL GAUGES:** Gauge any noticeable increases in gas flow. Record all gauges in Tour book and on morning reports.

II. DRILLING

- A. <u>MUD PROGRAM:</u> LSND mud (WBM) will be used to drill the 12-1/4" Surface hole, the 8 ¾" Directional Vertical hole, and the curve portion of the wellbore. A LSND (WBM) or (OBM) will be used to drill the lateral portion of well. Treat for lost circulation as necessary. Obtain 100% returns prior to cementing. Notify Engineering of any mud losses.
- B. <u>BOP TESTING:</u> While drill pipe is in use, the pipe rams and the blind rams will be function tested once each trip. The anticipated reservoir is expected to be less than 1300 psi, so the BOPE will be tested to 250 psi (Low) for 5 minutes and 1500 psi (High) for 10 minutes. Pressure test surface casing to 600 psi for 30 minutes and intermediate casing to 1500 psi for 30 minutes. Utilize a BOPE Testing Unit with a recording chart and appropriate test plug for testing. The drum brakes will be inspected and tested each tour. All tests and inspections will be recorded in the tour book as to time and results.

III. MATERIALS

A. CASING PROGRAM:

CASING TYPE	OH SIZE (IN)	DEPTH (MD) (FT)	CASING SIZE (IN)	WEIGHT(LB)	GRADE
Surface	12.25"	320'	9.625"	36#	J-55
Intermediate	8.75"	5,816	7"	23#	K-55
Prod. Liner	6.125"	5666' - 10458'	4-1/2"	11.6#	N-80
Tie-Back String	N/A	Surf 5666'	4-1/2"	11.6#	N-80

B. FLOAT EQUIPMENT:

- 1. <u>SURFACE CASING:</u> 9-5/8" notched regular pattern guide shoe. Run (1) standard centralizer on each of the bottom (4) joints of Surface Casing.
- INTERMEDIATE CASING: 7" cement nose guide shoe with a self-fill insert float. Place float collar one joint above the shoe. Install (1) centralizer on each of the bottom (3) joints and one standard centralizer every (3) joints to 2,500 ft. Run (1) centralizer at 2,700 ft., 2,500 ft., 2,300ft., 2,000ft., 1,500 ft., and 1,000 ft.
- <u>PRODUCTION LINER</u>: Run 4-1/2" Liner with cement nose guide Float Shoe + 2jts. of 4-1/2" casing + Landing Collar + 4-1/2" pup joint + 1 RSI (Sliding Sleeve) positioned inside the 330ft Hard line. Centralizer program will be determined by Wellbore condition and when Lateral is evaluated by Geoscientists and Reservoir Engineers. Set seals on Liner Hanger. Test TOL to 1500 psi for 15 minutes.
- 4. <u>TIE-BACK CASING:</u> None

C. CEMENTING:

(Note: Volumes may be adjusted onsite due to actual conditions)

- <u>SURFACE</u>: 5 bbl Fresh Water Spacer, 100 sx (160 cu.ft.) of 14.5 ppg Type I-II (Neat G) + 20% Fly Ash cement w/ 7.41 gal/sack mix water ratio @ 1.61 cu ft/sx yield. Calculated @ volume + 50% excess. WOC 12 hours. Test csg to 600psi. Total Volume: (160 cu-ft/100 sx/ Bbls).TOC at Surface.
- 2. <u>INTERMEDIATE:</u> 20 bbl (112 cu-ft) Mud Flush III spacer + Lead: +/- 700 sx Foamed 50/50 Poz Cement. 13.0 ppg + 0.1% Halad 766 + 0.2% Versaset + 1.5% Chem-Foamer 760 (Yield :1.43 cu-ft/ sk. / Vol: 1216 cu-ft / 216.5 Bbls.) + TAIL: 100 sx 13.5 #/gal. + 0.2% Versaset + 0.15% HALAD-766 (Yield: 1.28 cu-ft / sk / Vol: 128 cu-ft / 22.8 Bbls.). + Fresh Water Displacement (1,362 cu-ft / +/- 242 Bbls) + 100 sx Top-Out Cement Premium: Yield: (1.17 cu-ft / sk / (Vol: 117 cu-ft / 20.8 Bbls). WOC 12 hrs. Test Casing to 1500 PSI for 30 minutes. Total Cement Volume: (900 sx / 1461 cu-ft / 260 bbls). Mix with +/- 84,000 SCF Nitrogen. TOC at surface.
- <u>PRODUCTION LINER</u>: STAGE 1:10 bbl (56.cu-ft) Fr Water Spacer. STAGE 2:40 bbl 9.5 ppg (224.6 cu-ft) Tuned Spacer III + 0.5 gal/bbl Musol + 38.75 ppb Barite + 0.5 gal/bbl SEM-7. STAGE 3: 10 bbl Fr Water Spacer. STAGE 4: Lead Cement: 50 / 50 Poz Premium + 0.2% Versaset + 0.2% Halad -766, Yield 1.43 cu ft/sk, 13.0 ppg, (10 sx / 14.3 cu ft. / 2.5 bbls). STAGE 5: 200 sx. Foamed Lead Cement: 50 / 50 Poz Standard + 0.2% Versaset + 0.2% HALAD-766 + 1.5% Chem-Foamer 760. Yield 1.97 cu-ft/sk. 13.0 ppg (200 sx / 394 cu-ft. / 70.2 bbls.). STAGE 6: Tail Cement : 100 sx. 50/50 Poz Standard + 0.2% Versaset + 0.05% HALAD-766 + .05% SA-1015, Weight: 13.5 ppg (100 sx / Yield 1.28 cu ft/sk. / 128 cu ft. / 22.8 bbls) STAGE 7: Displace w/ +/- 137 bbl Fr Water. Total Cement (563.3 cu ft / 95.5 bbls). Mix Foamed Cement w/ +/- 75,000 SCF Nitrogen. Est. TOC +/- 5,644 ft.

IV. COMPLETION

A. <u>CBL</u>

1. Run CCL for perforating.

B. PRESSURE TEST

1. Pressure test 4-1/2" casing to 4500 psi max, hold at 1500 psi for 30 minutes. Increase pressure to Open RSI sleeves.

C. STIMULATION

- 1. Stimulate with approximately 2,805,000# 20/40 mesh sand and 340,000# 16/30 mesh sand in 619,113 gallons water with 42,696 mscf N2 for 17 stages.
- 2. Isolate stages with flow through frac plug.
- 3. Drill out frac plugs and flowback lateral.

D. RUNNING TUBING

- 1. <u>Production Tubing</u>: Run 2-7/8", 6.5#, J-55, EUE tubing with a SN on top of bottom joint. Land tubing near Top of Liner.
- Although this horizontal well will be drilled past the applicable setbacks, an unorthodox location application is not required because the completed interval in this well, as defined by 19.15.16.7 B(1) NMAC, will be entirely within the applicable setbacks. This approach complies with all applicable rules, including 19.15.16.14 A(3) NMAC, 19.15.16.14 B(2) NMAC, 19.15.16.15 B(2)NMAC, and 19.15.16.15. B(4) NMAC.

NOTE:

Installation of RSI sleeves at Toe of Lateral.

Proposed Operations:

A 4-1/2" 11.6# N-80 Liner will be run to TD and landed +/- 150 ft. into the 7" 23# K-55 Intermediate casing with a Liner Hanger and pack-off assembly then cemented to top of liner hanger.

After cementing and TOL clean up operations are complete, the TOL will be tested to 1500 psi (per BLM).

The Drilling Rig will be rigged down at this point and Completion operations will begin.¹

A 4-1/2" 11.6# N-80 tie-back string with seal assembly will be run and stung into the PBR of the liner hanger, tested to 1500 PSI and hung off at the surface. After Stimulation and Testing operations are complete the 4-1/2" tie-back string will be removed from the well.