


UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
OMB No. 1004-0135
Expires November 30, 2000

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or reenter an abandoned well. Use Form 3160-3 (APD) for such proposals.

SUBMIT IN TRIPLICATE - Other instructions on reverse side



5. Lease Serial No. NM0560223
6. If Indian, Allottee or Tribe Name
7. Unit or CA/Agreement, Name and/or N
8. Well Name and No. Frew Federal 8
9. API Well No. 30-045-22651
10. Field and Pool, or Exploratory Area Waw Fruitland Sand PC
11. County or Parish, State San Juan, New Mexico

1. Type of Well
☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator
Running Horse Production Company

3a. Address PO Box 737, Ignacio, CO 81137
3b. Phone No. (include area code) 970-563-0145

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
1850' FSL & 1450' FEL, Section 19, T26N-R12W

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Acidize <input type="checkbox"/> Deepen <input type="checkbox"/> Production (Start/Resume) <input type="checkbox"/> Water Shut-Off
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Alter Casing <input type="checkbox"/> Fracture Treat <input type="checkbox"/> Reclamation <input type="checkbox"/> Well Integrity
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Casing Repair <input type="checkbox"/> New Construction <input type="checkbox"/> Recomplete <input type="checkbox"/> Other
	<input type="checkbox"/> Change Plans <input checked="" type="checkbox"/> Plug and Abandon <input type="checkbox"/> Temporarily Abandon
	<input type="checkbox"/> Convert to Injection <input type="checkbox"/> Plug Back <input type="checkbox"/> Water Disposal

13. Describe Proposed or Completed Operations (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zone. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed when Testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator determined that the site is ready for final inspection.)

Running Horse Production Company proposes to plug and abandon this well according to the attached prognosis.

RECEIVED
2003 JUN 19 PM 5:00
070 Farmington, NM

14. I hereby certify that the foregoing is true and correct
Name (Printed/Typed) Robert J. Voorhees Title Vice President Engineering & Development
Signature [Signature] Date June 5, 2003

THIS SPACE FOR FEDERAL OR STATE USE

Approved by Original Signed: Stephen Mason Title Date JUN 27 2003
Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon. Office

Title 18 U.S.C. Section 1001, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on reverse)

NMOCED

June 5, 2003
Running Horse Production Company
P&A Procedures for Frew Federal #8
Location: SE/4 Sec 19, T26N-R12W, San Juan County, NM
Field: Waw Fruitland Sand PC
Surface: Navajo
Lease: NM 0560223
Elevation: 6057'
Production String: 2 7/8" @1276'
PBTD: 1242'

Procedure:

1. MIRU service unit.
2. NU 2 3/8" relief line. Blow well down and kill with water if necessary.
Laydown tubing.
3. Connect cement truck directly to 2 7/8" tubing and fill casing with 40 sx (47 cu ft) of Class H cement with 1/4#/sk celloflake. Pump cement until tubing stands full.
4. Cut off wellhead and install dry hole marker. Reclaim location as per BLM specifications.