Submit 3 Gopies To Appropriate District	State of	of New Me	xico		Form C-103
Office District I	Energy, Minera	ls and Natur	ral Resources		May 27, 2004
1625 N. French Dr., Hobbs, NM 88240				WELL API NO.	0.45.040/0
<u>District II</u> 1301 W. Grand Ave., Artesia, NM 88210	OIL CONSE	RVATION	DIVISION		-045-31969 Type of Lease
District III	1220 South St. Francis Dr.			STATE	Type of Lease  FEE
1000 Rio Brazos Rd., Aztec, NM 87410 District IV	Santa	Fe, NM 87	505		& Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM		16	19 19 20 21 20 31		
87505	ICES AND REPORTS	100	177	7 Lease Name or	Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPO	SALS TO DRILL OR TO D	EEPEN/OR PLL	IG B <b>ÁGASTÍO</b> A 😌	<u>[</u>	_
DIFFERENT RESERVOIR. USE "APPLI	CATION FOR PERMIT" (F				arren LS
PROPOSALS.)  1. Type of Well: Oil Well   (	log Wall M Other		RIE DINO	-8. Well Number	<b>3</b> D
2. Name of Operator	ias well 🔼 Other	(F)	DIEL S	9. OGRID Numb	2B
BP America Production Compar	ov - Attn: Mary Cor	lev (5)	Dres	<b>(</b> 2)	000778
3. Address of Operator	iy Attai Mary Cor	(O)		10. Pool name or	
P.O. Box 3092 Houston, TX 77	/253	14	35 p E Con 1	Blanco Mesavero	le/Otero Chacra
4. Well Location					
Unit Letter H : 1	140 feet from the	<u>North</u>	line and1095	feet from the	East line
Section 12	Township 28N	Range 09V	W NMPM	San Juan	County
	11. Elevation (Show				
	<u>_</u>	5745'	GR		
Pit or Below-grade Tank Application	or Closure 🗌				
Pit type Workover Depth to Gro	undwater_ <u>&gt;100'</u> Distanc	ce from nearest	fresh water well <u>&gt;100</u>	00' Distance from nea	rest surface water <u>&gt;1000'</u>
Pit Liner Thickness: 12 mil	Polow Crado Tonke Vo	luma	hhler Canet	mustian Matarial	
				· · · · · · · · · · · · · · · · · · ·	
12. Check	Appropriate Box to	Indicate N	ature of Notice,	Report or Other	Data
NOTICE OF IN	NTENTION TO:		l eur	SEQUENT RE	DODT OF:
PERFORM REMEDIAL WORK		ON 🗆	REMEDIAL WOR		ALTERING CASING
TEMPORARILY ABANDON			COMMENCE DRI		P AND A
PULL OR ALTER CASING		ā	CASING/CEMENT		
_		_	·	_	
OTHER: Complete into Chac			OTHER:		
13. Describe proposed or comp					
of starting any proposed w or recompletion.	ork). SEE RULE 1103	. For Multipl	le Completions: Att	tach wellbore diagra	am of proposed completion
BP America Production Comp	any request nermis	sion to reco	mnlete the subjec	et well into the O	itero Chacra Pool and
commingle production Downh					
The Blanco Mesaverde (72319)	<u> </u>		•	_	
per NMOCD order R-11363.					÷ •
are identical, therefore no add	_	_	• •		
Production is proposed to be a	llocated based on th	e subtractio	on method using	the projected fut	ure decline for
production from the Mesaverd	le. That production	ı shall serve	as a base for pro	oduction subtrac	ted from the total
production for the commingle			uction will be att	ributed to the Cl	hacra. Attached is the
future production decline estin					
Commingling Production Dow	nhole in the subject	well from t	the proposed Poo	ls with not reduc	e the value of the total
remaining production			_		
		11/2	2230 A	2	
Themshy and Code at the Code	ahan takun 1				
I hereby certify that the information SIGNATURE	above is true and com		est of my knowledge egulatory Analyst		04/12/200 <u>6</u>
Type or print name Cherry Hlava			lavacl@bp.com		No. <u>281-366-4081</u>
For State Use Only APPROVED BY:	than -	TITI F	uty on a gas ins	ACTOR, DIST.	DATE APR 1 8 2006
Conditions of Approval (if any):	1/			- 123/	

District I

1625 N. French Dr., Hobbs, NM 88240

District II 811 South First, Artesia, NM 88210

District III

1000 Rio Brazos Rd., Aztec, NM 87410

District IV

2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico Energy, Minerals & Natural Resources Department

Form C-102 Revised August 15, 2000

## **OIL CONSERVATION DIVISION**

2040 South Pacheco Santa Fe, NM 87505 Submit to Appropriate District Office

State Lease - 4 Copies

Fee Lease - 3 Copies AMENDED REPORT


WELL LOCATION AND ACREAGE DEDICATION PLAT

<sup>1</sup> API Number 30-045-31969	<sup>2</sup> Pool Code 82329	<sup>3</sup> Pool Name Otero Chacra			
<sup>4</sup> Property Code 001212		<sup>6</sup> Well Number 2B			
<sup>7</sup> OGRID No. 000778	ВР	<sup>8</sup> Operator Name America Production Company	<sup>9</sup> Elevation		

<sup>10</sup> Surface Location

UL or lot no.	Section	Township	Range	Lot Idn	Feet from	North/South	Feet from	East/West	County
F	12	28N	09W		1140	North	1095	East	San Juan
	Bottom Hole Location If Different From Surface								
UL or lot no.	Section	Township	Range	Lot Idn	Feet from	North/South	Feet	East/West	County
						L			
		<sup>14</sup> Consolidation (	Code	e 15 Order No.					
160									

NO ALLOWABLE WILL BE ASSIGNED TO THIS COMPLETION UNTIL ALL INTERESTS HAVE BEEN CONSOLIDATED OR A NON-STANDARD UNIT HAS BEEN APPROVED BY THE DIVISION



## SJ Basin Recompletion Procedure

Well Name: Warren LS 2B

API: 30-045-31969

Location: T28N-R8W-Sec12 County: San Juan, NM

Date: April 11, 2006

Objective: Perforate and frac Chacra, and downhole co-mingle Chacra, with existing Mesaverde

1. Perforate and fracture Chacra.

2. Return well to production.

3. Downhole co-mingle Chacra, and Mesaverde.

## Procedure:

- 1. Perform pre-rig site inspection. Check for: size of location, Gas Taps, other wells, other operators, running equipment, wetlands, wash (dikes req.), H2S, barriers needed for equipment, Landowner issues, location of pits (buried lines in pits), Raptor nesting, critical location, check anchors. Check ID wellhead, if earth pit is required have One Call made 48 hours prior to digging.
- 2. Perform second site visit after lines are marked to ensure all lines clear marked pit locations. Planning and Scheduling to ready location for rig.
- 3. RU slickline or wireline unit. Pressure test lubricator and equipment. Tag for fluid and fill.
- 4. RIH and set two composite bridge plugs at 3700'. Fill casing w/ 2% KCl.
- 5. Check and record tubing, casing and bradenhead pressures. Ensure production casing has double casing valves installed. Double valve all casing strings.
- 6. LO/TO all necessary equipment including but not limited to: meter run, automation, separators and water lines.
- 7. Pressure test casing to 5,000 psi.
- 8. Prepare for explosive operations. Follow Schlumberger Explosive SOP including radio silence, suspension of welding operations, and isolation of electrical devices from the work area. Perform Pre-job Safety Meeting to review JSA and procedures. Meeting should address the VDR (vehicle data recorder) System that Bp people have installed on their vehicles. They must be shut off at the 300 foot sign by hitting 00 and then the enter button, and then wait for about 5 minutes for the unit to turn off. When the green light goes out, call the control center at 326-9475. This number is on a pickup list in the Optimizer room and should be your first point of contact followed by the front desk then the weekend pager. Verify the unit is not transmitting. You then can drive to location and park, but do not to exceed 10 Miles/hr. Note: 20 MPH will turn unit back on. If someone has On Star on their vehicle they cannot enter closer than 300 foot. On Star cannot be turned off. PLEASE take special caution. This is in conjunction with all cell phones, pagers, radios and any electronic devise that transmits a signal.

9. RIH with 1-11/16" HSC perforating guns w/lubricator. Perforate Chacra formation:

## 2 SPF:

- 10. Rigless frac.
- 11. NU frac isolation equipment. Install and monitor production casing and treating pressure during entire job in frac van via pressure transducers on production casing and treating line. Spearhead 500 gal 15% HCL, establish injection rate, and proceed with fracture stimulation according to Schlumberger schedule. Maintain surface pressures, less than 5,000 psi during frac job. Flush frac with foam. Fill out GWSI scorecard.
- 12. Flowback frac immediately. Flow well through choke manifold on 1/4", 1/2" and 3/4" chokes increasing drawdown until well dies or stabilizes. This is to aid in reducing sand flowback. Recommend 8 hours of flow for each choke size.
- 13. MIRU Coil Tubing Unit. Rig up air package/unit, pressure test all lines (Testing procedure to be supplied from air company).
- 14. Cleanout fill to top of BP set at 3,700'. Perform well test on Chacra for regulatory and document well test in DIMS. Notify Cherry Hlava (281-366-4081) when well test information is in DIMS.
- 15. Drill out composite bridge plugs at 3700' and cleanout to PBTD at +/- 4700'. Blow well dry.
- 16. Test well for air. Return well to production.