Form 3160-5 (June 2015)

## UNITED STATES DEPARTMENT OF THE INTERIOR

FORM APPROVED OMB NO. 1004-0137 Expires: January 31, 2018

DI		CATCALL					
BUREAU OF LAND MANAGEMENT  SUNDRY NOTICES AND REPORTS ON WELLS  Do not use this form for proposals to drill or to re-enter an abandoned well. Use form 3160-3 (APD) for such proposals.					5. Lease Serial No. NMSF078213		
					6. If Indian, Allottee or Tribe Name		
SUBMIT IN TRIPLICATE - Other instructions on page 2					7. If Unit or CA/Agreement, Name and/or No. NMNM99464		
1. Type of Well ☐ Other ☐ Other					8. Well Name and No. TIGER 3		
2. Name of Operator Contact: AMANDA WALKER HILCORP ENERGY COMPANY E-Mail: mwalker@hilcorp.com					9. API Well No. 30-045-29507-00-S1		
			one No. (include area code) 05-324-5122		10. Field and Pool or Exploratory Area FULCHER KUTZ PICTURED CLIFFS		
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)					11. County or Parish, State		
Sec 34 T30N R13W NESE 1377FSL 565FEL 36.766324 N Lat, 108.186026 W Lon					SAN JUAN COUNTY, NM		
12. CHECK THE A	PPROPRIATE BOX(ES) T	O INDICAT	E NATURE OF	F NOTICE,	REPORT, OR OTH	IER DATA	
TYPE OF SUBMISSION	TYPE OF ACTION						
■ Notice of Intent	☐ Acidize	☐ Deep	☐ Deepen		☐ Production (Start/Resume)		Off
_	☐ Alter Casing	Alter Casing		ation	■ Well Integri	ty	
☐ Subsequent Report ☐ Casing Repair		□ New	☐ New Construction ☐		mplete		
☐ Final Abandonment Notice	☐ Plug and Abandon     ▼ Ten			porarily Abandon			
BP	☐ Plug Back ☐ Water I			Disposal			
If the proposal is to deepen directions Attach the Bond under which the wor following completion of the involved testing has been completed. Final Abdetermined that the site is ready for final REVISED NOI TO CORRECT temporarily abandon the subjectives rise. Please see the att NOI APPROVED ON 8/30/2010	rk will be performed or provide the operations. If the operation result that operation result of the operation result of the operation result of the operation result of the operation.  THE PROCEDURE AND sect well with the intent to retached procedure and wellboard.	te Bond No. on lits in a multiple only after all research of the second	file with BLM/BIA completion or reco equirements, including the C. Hilcorp Energy to production or	. Required su mpletion in a ing reclamatio y Company ice gas NCEL THE	bsequent reports must be new interval, a Form 316 n, have been completed a requests permission	filed within 30 days 0-4 must be filed or and the operator has	s ice
SEP 1 7 2019							
DISTRICT III							
	Electronic Submission #48 For HILCORP ENE mmitted to AFMSS for proce	ERGY COMP	ANY, sent to the IN HOFFMAN on	Farmington 09/13/2019	(19JH0189SE)		
Name (Printed/Typed) AMANDA	Citle OPERATIONS REGULATORY TECH						
Signature (Electronic S	Submission)	Date 09/12/2019					
	THIS SPACE FOR	R FEDERA	L OR STATE	OFFICE U	SE		
Approved By JOHN HOFFMAN			TitlePETROLE	UM ENGIN	EER	Date 09/1	3/2019
Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.			Office Farmington				

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.





## Hilcorp Energy Company TIGER 3

Temporarily Abandon API#: 3004529507

## PROCEDURE

- 1. Hold a pre-job safety meeting prior to beginning all operations or during a change in operational scope or initiation of SIMOPs. Properly document all operations via the JSA process. Insure that all personnel onsight abide by HEC safety protocol, including PPE, housekeeping, and procedures. Verify cathodic protection is off and wellhead instrumentation is properly disconnected from wellhead. Comply with all NMOCD, BLM, and HEC safety and environmental regulations. Verify there is no H2S present prior to beginning operations. If H2S is present, take the necessary actions to insure that the operation is safe prior to beginning operations. Observe and record pressures across all strings daily, prior to beginning operations. Notify NMOCD and BLM 24 hours in advance of beginning operations
- 2. MIRU service rig and associated equipment, ND casing risers
- 3. LOTO pumping unit, remove HH and bridle, PU on PR and unseat pump. POOH LD rods and pump.
- 4. ND tree and NU BOPs. Pressure and function test BOPs to 150/1500 psi.
- 5. PU on tbg, release hanger, scan and visually inspect tbg and POOH
- 6. PU junk mill and RIH to 1550', POOH LD junk mill
- 7. RIH w/ CBIP on tbg and set at 1500', PT CIBP and casing to 600 psi, POOH w/ setting tool.
- 8. RBIH w/ 250' of tbg to use as a kill string. NDNU tree verify tree and wellhead are equipped with functional pressure gauges. RDMO
- 9. Contact BLM and NMOCD to schedule witnessed MIT. PT csg to 600 psi.

