

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or reenter an abandoned well. Use Form 3160-3 (APD) for such proposals.

SUBMIT IN TRIPLICATE - Other instructions on reverse side

FORM APPROVED
OMB No. 1004-0135
Expires July 31, 1996

RCVD DEC 15 06
OIL CONS. DIV.
DIST. 9

5. Lease Serial No.

Contract #398

6. If Indian, Allottee or Tribe Name

Jicarilla Apache

7. If Unit or CA/Agreement, Name and/or N

8. Well Name and No.

Martin Whittaker #29

9. API Well No.

30-039-23454

10. Field and Pool, or Exploratory Area

S. Lindrith Gallup Dakota ext.

11. County or Parish, State

Rio Arriba County, NM

1. ☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Elm Ridge Exploration Co., llc

3a. Address

PO Box 156 Bloomfield, NM 87413

3b. Phone No. (include area code)

505-632-3476 x 201

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

M- Sec 15-T23N-R4W

850' FSL X 770' FWL

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

| TYPE OF SUBMISSION | TYPE OF ACTION |
|--|---|
| <input checked="" type="checkbox"/> Notice of Intent | <input type="checkbox"/> Acidize <input type="checkbox"/> Deepen <input type="checkbox"/> Production (Start/Resume) <input type="checkbox"/> Water Shut-Off |
| <input type="checkbox"/> Subsequent Report | <input type="checkbox"/> Alter Casing <input type="checkbox"/> Fracture Treat <input type="checkbox"/> Reclamation <input type="checkbox"/> Well Integrity |
| <input type="checkbox"/> Final Abandonment Notice | <input type="checkbox"/> Casing Repair <input type="checkbox"/> New Construction <input type="checkbox"/> Recomplete <input type="checkbox"/> Other _____ |
| | <input type="checkbox"/> Change Plans <input checked="" type="checkbox"/> Plug and Abandon <input type="checkbox"/> Temporarily Abandon |
| | <input type="checkbox"/> Convert to Injection <input type="checkbox"/> Plug Back <input type="checkbox"/> Water Disposal |

13. Describe Proposed or Completed Operations (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleat in a new interval, a Form 3160-4 shall be filed once Testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)

Based on interest considerations and after further uphole review, Elm Ridge Exploration has decided to plug and abandon this wellbore, in accordance with the previously approved sundry notice. We expect to be completed with this work by March 1, 2007. A subsequent sundry notice will be submitted upon completion of plugging operations.

14. I hereby certify that the foregoing is true and correct

Name (Printed/Typed)

Amy Mackey

Title

Production Assistant

Signature

Date

December 1, 2006

THIS SPACE FOR FEDERAL OR STATE USE

Approved by

Original Signed: Stephen Mason

Title

Date

DEC 18 2006

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on reverse)

NWOC

Plug and Abandonment Procedure for Martin Whittaker #29:

- 1) TOOH with rods and tubing. RIH with 5-1/2" casing scraper to 6960'. TOOH. TIH with 5-1/2" cement retainer and set at 6948'. Squeeze below retainer with 17 sacks to cover top of Dakota inside casing from 6948'-7048'. Spot 6 sacks on top of retainer. TOOH.
- 2) TIH with 5-1/2" casing scraper to 5610'. TOOH. TIH with 5-1/2" cement retainer and set at 5600'. Squeeze below retainer with 40 sacks to cover perforations and top of Gallup inside casing from 5600'-5852'. Spot 6 sacks cement on top of retainer. TOOH.
- 3) ~~TIH with 5-1/2" cement retainer and set at 4196'. Squeeze below retainer with 17 sacks to cover top of Mesaverde inside casing at 4246'. Spot 6 sacks on top of retainer.~~
4296-4196
- 4) Pull up to 3234'. Set 17 sack balanced plug from 3234'-3134' to cover top of Chacra inside casing.
- 5) Pull up to 2817'. Spot 66 sack balanced plug from 2817' to 2224', to cover Pictured Cliffs, Fruitland, Kirtland, and Ojo Alamo tops inside casing.
- 6) PU to 1192'. Spot 17 sack balanced plug from 11⁴92-10⁴92' to cover top of Nacimiento inside casing.
- 7) PU to 424'. Spot 17 sack plug from 424-324', to cover across 9-5/8" casing shoe inside 5-1/2" casing.
- 8) TIH with 4-3/4" bit to 310'. TOOH. Perforate 4 holes at 300' (top of cement). Tie onto 5-1/2" casing and squeeze with 105 sacks, or sufficient volume to cover from 300' to surface, inside and outside.
- 9) Cut off casing, set dry hole marker, and remediate location in accordance with regulatory requirements.