Submit 3 Copies To Appropriate District Office	State of New Mexico	Form C-103
District I	Energy, Minerals and Natural Resources	May 27, 2004
1625 N. French Dr., Hobbs, NM 88240 District II	OH CONGERNATION BRAGON	WELL API NO. 30-045-22365 ROVE JOSEL BOT
1301 W. Grand Ave., Artesia, NM 88210	OIL CONSERVATION DIVISION	5. Indicate Type of Lease
District III 1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Francis Dr.	STATE FEE DEELS
<u>District IV</u> 1220 S. St. Francis Dr., Santa Fe, NM	Santa Fe, Nivi 87303	6. State Oil & Gas Lease No.
87505		
		7. Lease Name or Unit Agreement Name
DIFFERENT RESERVOIR. USE "APPLIC		Roelofs B
PROPOSALS.) 1. Type of Well: Oil Well X G	as Wall Cother	
2. Name of Operator	as well Other	
•	y - Attn: Cherry Hlava	000778
3. Address of Operator		10. Pool name or Wildcat
P.O. Box 3092 Houston, TX 77	253	Blanco Mesaverde & Pictured Cliffs
4. Well Location		
		(6.)
Pit or Below-grade Tank Application 🗖 o		
Pit typeDepth to Groundwater_	_Distance from nearest fresh water well Distance from	n nearest surface water
Pit Liner Thickness: mil F	Below-Grade Tank: Volume bbls: Const	ruction Material
12. CHECK P	Appropriate Box to indicate Nature of Notice	c, Report of Other Data
PERFORM REMEDIAL WORK		
FULL OR ALTER CASING	MOLTIPLE COMPL CASING/CEME	INT JOB [
or recompletion.	ork). SEE ROLE 1103. For Multiple Completions:	Attach wellbore diagram of proposed completion
•	as been T&A'd since 1995 & has not produce	ed since that time. BP America
		f tubing & Downhole Commingle the
		· ·
3160-5.	,	
Production is proposed to be al	located based on the subtraction method usir	g the projected future decline for
_	<u>=</u>	-
-	•	ll be attributed to the Blanco Mesaverde.
		age will not reduce the value of the total
remaining production	inoic in the subject wen from the proposed r	ools will not reduce the value of the total
9 (#110 274C	, / ,
	U17C25T8 -	103/1999
I hereby certify that the information	above is true and complete to the best of my knowle	dge and belief. I further certify that any pit or below-
Ω / I	//	ப or an (attached) afternative OCD-approved pian ப
Type or print name Cherry Hlava For State Use Only	/ //-	
APPROVED BY:	TITLESPATTY ON & GAS II	ISPECTOR, DIST. OF DATE JAN 19 2007
Conditions of Approval (if any): 5.	Santa Fe, NM 87505 Santa F	

SJ Basin Downhole Commingling Procedure

Well Name: Roelofs B 3A – PC / MV dual well

Version: 1.0

Horizon:

T29N-R8W-Sec15D

Location: T29N-R County: San Jua API #: 30-045-22365

San Juan State:

State: New Mexico Engr: Andrew Berhost

ph (505) 326-9208 mobile: (505) 486-0139 fax (505) 326-9262

Objective: Remove short string tubing (PC), cleanout fill above packer, pluck packer, Pull long tubing string (MV), Clean out wellbore, TIH and reland single string of tubing, and return to production.

1. TOH with short tubing string set @ 3038'

2. Tag for fill above Model "D" packer – C/O if necessary

Picture Cliff / Mesa Verde

- 3. TOH with long tubing string set @ 5509'
- 4. Mill and pluck packer @ 3086'
- 5. Tag for fill C/O to PBTD
- 6. TIH with 2-3/8" tubing land @ 5509'
- 7. Return well to production.

Pertinent Information: Gas BTU content for this well is 1114 (PC production); Sp gr. is 0.635 (PC). Venting and Flaring document needs to be followed if BTU content is above 950.


Procedure:

- 1. Perform pre-rig site inspection. Check for: size of location, Gas Taps, other wells, other operators, running equipment, wetlands, wash (dikes req.), H2S, barriers needed for equipment, Landowner issues, location of pits (buried lines in pits), Raptor nesting, critical location, check anchors. Check ID wellhead; if earth pit is required have One Call made 48 hours prior to digging.
- 2. Perform second site visit after lines are marked to ensure all lines clear marked pit locations. Planning and scheduling to ready location for rig.
- 3. RU slickline unit. Pressure test lubricator and equipment. RIH and set two barriers (CIBP, tbg collar stop w/plug, or plug set in nipple) for isolation in each tubing string. See wellbore Diagram below for BHA details of each tubing string.
- 4. Check and record tubing, casing, and bradenhead pressures. Ensure production casing has double casing valves installed. Double valve all casing strings.
- 5. MIRU workover rig. LOTO all necessary equipment including but not limited to: meter run, automation, separator, and water line.
- 6. Blow down well. Kill with 2% KCL water ONLY if necessary.

Roelofs B 3A - DHC Page 2 of 4

7. Check all casing strings to ensure no pressure exist on any annulus. The operations of removal of wellhead and installation of BOP's will be performed under a dispensation for one (1) barrier on the backside.

- 8. Nipple down Wellhead. NU BOPs and diversion spool with 3" outlets and 3" pipe to the blow tank. Pressure test BOPs to 200 psi above BHP. Monitor flowing casing pressure with gauge throughout workover.
- 9. Install stripping rubber, pull tubing hanger and shut pipe rams. Strip tubing hanger out of hole.
- 10. Tag for fill above Model 'D' packer at 3086' and TOH with 1-1/4" (1.328#, HS-70, 0.109) short production tubing currently set at 3038'.
- 11. If fill was detected above Model 'D' packer, TIH and cleanout fill above packer. TOH and LD 2-3/8" workstring.
- 12. TOH with 2-3/8" long production tubing currently set @ 5509'.
- 13. Mill slip elements on 7" Model 'D' packer set at 3086' and retrieve packer with packer plucker.
- 14. RIH with bit and scraper for 4-1/2" casing. Check the distance between the top of the blind rams and the length of the bottomhole assembly that is being run. If the BHA is too long then the well has to be top killed and monitored prior to opening bind rams. Work casing scraper across Mesaverde perforations @ 4629'-5559'. TOH with bit and scraper.
- 15. Cleanout to PBTD to ensure wellbore is clean and dry. Reference Under-Balanced Well Control Tripping Procedure. TOH w/ workstring.
- 16. Rabbit tubing and RIH with 2-3/8" production tubing. (With muleshoe, F-nipple with plug, 4 ft pup, X-nipple with plug).
- 17. Land 2-3/8" production tubing at 5509'. Lock down tubing hanger.
- 18. Pressure test tubing to 500 psi with air unit, make sure tubing spool valves are open. Care should be taken during pressure testing of the tubing due to potential problem caused if tubing parts close to the surface. Check all casing string for pressure. The operations of removal of BOP's and installation of wellhead will be performed under a dispensation for one (1) barrier on the backside.
- 19. ND BOP's. NU Wellhead. During Master valve placement ensure the top of hanger has spacer nipple in place to bottom of bonnet flange so plunger equipment will not hang up through tree. Pressure test Wellhead.
- 20. RU WL unit. Run gauge ring for 2-3/8" tubing. Broach out any tight spots noticed in WL trip. Pull plugs and set tubing stop for plunger. Communicate plunger equipment status to operations team personnel.



updated: 12/14/06 ADB

Roelofs B 3A - DHC Page 3 of 4

- 21. RD slickline unit.
- 22. Test well for air. Return well to production. RD and release all equipment. Remove all LOTO equipment.

23. Ensure all reports are loaded into DIMS. Print out summary of work and place in Wellfile.

Discussion with production operations team about particulars of well when handing off the well file.

Roelofs B 3A Future Production Decline Estimate Pictured Cliffs

Gas Volume		1232 1225 1219 1213 1206	1194 1188 1175 1169 1163	1145 1139 1127 1127 1110 1104 1093
Month		Jan-2007 Feb-2007 Mar-2007 Apr-2007 May-2007 Jun-2007	Jul-2007 Aug-2007 Sep-2007 Oct-2007 Dec-2007 Jan-2008 Feb-2008	Mar-2008 Jun-2008 Jul-2008 Jul-2008 Sep-2008 Oct-2008 Nov-2008 Jan-2009
In(Qf/Qi) = -dt Qf= 1318 Qi= 1632 rate= 44 time= 41 dt= -0.21369082	decline= -0.005211971	.		
Month: Gas Volume Jan-2006 833 Feb-2006 Mar-2006 Apr-2006 789 May-2006 Jun-2006 859				
Gas Volume 1471 1340 1470 1406 1357	1423 1223 1340 1364 1598	1562 1049 1396 1387	1652 1600 1482 1465 1351 1252 1292	1423 1383 1462 1258 1339 1140 1151 1150
Month Jan-2003 Feb-2003 Mar-2003 Apr-2003 May-2003 Jun-2003	Jul-2003 Aug-2003 Sep-2003 Oct-2003 Nov-2003	Jan-2004 Feb-2004 Mar-2004 Apr-2004 May-2004 Jun-2004	Jul-2004 Sep-2004 Oct-2004 Nov-2004 Dec-2004 Jan-2005 Feb-2005	Mar-2005 Apr-2005 Jun-2005 Jul-2005 Aug-2005 Oct-2005 Nov-2005
Gas Volume 1069 1184 1233 1202 1220 1195	1230 1230 1177 1196 1184	983 947 1208 1016 1425	1246 1212 1173 1205 1076 1166 1098	1344 1252 1418 1159 1632 1613 1613 126
Month San-2000 Feb-2000 Mar-2000 Apr-2000 May-2000 Jun-2000	Jul-2000 Aug-2000 Sep-2000 Oct-2000 Nov-2000	Jan-2001 Feb-2001 Mar-2001 Apr-2001 May-2001 Jun-2001	Jul-2001 Sep-2001 Oct-2001 Nov-2001 Dec-2001 Jan-2002 Feb-2002	Mar-2002 Apr-2002 May-2002 Jun-2002 Aug-2002 Sep-2002 Oct-2002 Dec-2002

Roelofs B 3A Future Production Decline Estimate Pictured Cliffs

Jan-2012	Dec-2011	Nov-2011	Oct-2011	Sep-2011	Aug-2011	Jul-2011	Jun-2011	May-2011	Apr-2011	Mar-2011	Feb-2011	Jan-2011	Dec-2010	Nov-2010	Oct-2010	Sep-2010	Aug-2010	Jul-2010	Jun-2010	May-2010	Apr-2010	Mar-2010	Feb-2010	Jan-2010	Dec-2009	Nov-2009	Oct-2009	Sep-2009	Aug-2009	Jul-2009	Jun-2009	May-2009	Apr-2009	Mar-2009	Feb-2009	Month
906	910	915	920	925	930	934	939	944	949	954	959	964	969	974	979	984	990	995	1000	1005	1010	1016	1021	1026	1032	1037	1042	1048	1053	1059	1064	. 1070	1076	1081	1087	Gas Volume
	_	_1		- 1	Aug-2014		_	-	Apr-2014	Mar-2014	Feb-2014			Nov-2013	Oct-2013					-	Apr-2013	Mar-2013			Dec-2012	Nov-2012	Oct-2012		Aug-2012				Apr-2012			Month
751	755	759	763	766	770	775		783		791	795	799	803			816												869		878		887	892	896	┝╼┪	Gas Volume
Jan-2018	Dec-2017	Nov-2017	Oct-2017	Sep-2017	Aug-2017	Jul-2017	Jun-2017	May-2017	Apr-2017	Mar-2017	Feb-2017	Jan-2017	Dec-2016	Nov-2016	Oct-2016	Sep-2016	Aug-2016	Jul-2016	Jun-2016	May-2016	Apr-2016	Mar-2016	Feb-2016	Jan-2016	Dec-2015	Nov-2015	Oct-2015	Sep-2015	Aug-2015	Jul-2015	Jun-2015	May-2015	Apr-2015	Mar-2015	Feb-2015	Month
622	626	629	632	635	639	642	645	649	652	656	659	662	666	669	673	676	680	683				698	702	705	709	713	716						739	743	_	Gas Volume
Jan-2021	Dec-2020	Nov-2020	Oct-2020	Sep-2020	Aug-2020	Jul-2020	Jun-2020	May-2020	Apr-2020	Mar-2020	Feb-2020	Jan-2020	Dec-2019	Nov-2019	Oct-2019	Sep-2019	Aug-2019	Jul-2019	Jun-2019	May-2019	Apr-2019	Mar-2019	Feb-2019	Jan-2019	Dec-2018	Nov-2018	Oct-2018	Sep-2018	Aug-2018	Jul-2018	Jun-2018	May-2018	Apr-2018	Mar-2018	Feb-2018	Month
516		521						538						555			564	567						585												Gas Volume
Jan-2024	Dec-2023	Nov-2023	Oct-2023	Sep-2023	Aug-2023	Jul-2023	Jun-2023	May-2023	Apr-2023	Mar-2023	Feb-2023	Jan-2023	Dec-2022	Nov-2022	Oct-2022	Sep-2022	Aug-2022	Jul-2022	Jun-2022	May-2022	Apr-2022	Mar-2022	Feb-2022	Jan-2022	Dec-2021	Nov-2021	Oct-2021	Sep-2021	Aug-2021	Jul-2021	Jun-2021	May-2021	Apr-2021	Mar-2021	Feb-2021	Month
428	430	432	434	437	439	 					453						467	470	472				482	485	487	490	492	495	497	500	503			510	513	Gas Volume