Form 3160-5 (September 2001)

UNITED STATES DEPARTMENT OF THE INTERIOR **BUREAU OF LAND MANAGEMENT**

FORM APPROVED OMB No. 1004-0135 Expires: January 31, 2004

					No.	
SUNDRY NOTICES AND REPORTS ON WELLS Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.				NMNM 005		
				6. If Indian, Al	lottee or Tribe Name	
		· · · · · · · · · · · · · · · · · · ·	2007 MAR - 8 A	M 11: 21 R	CVD MAR16'07	
SUBMIT IN TRIPLICATE - Other instructions on reverse side				7. If Unit or CA	/Agreement, Name and/or No.	
1. Type of Well					IL CONS. DIV.	
Oil Well Gas Well Other			210 FAR 11	8. Well Name and NIST, 3		
2. Name of Operator				Hanson 21		
Mountain States Petroleum Corp 3a. Address 3b. Phone N			9. API Well No. (include area code) 30-031-20159			
		3b. Phone No. (incl	10		ool, or Exploratory Area	
3001 Northridge Drive, Farmington, NM 87401 505-4 4. Location of Well (Footage, Sec., T, R, M., or Survey Description)		505-486-0211	FUZ11		Hospah Upper & Lower Sand, South	
1335' FSL & 2635' FWL, Sec 6, T17N, R8W, NMPM				11. County or F	 	
				McKinley C	McKinley County, NM	
12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, RE						
	ROTRIATE BOX(ES) TO		· · · · · · · · · · · · · · · · · · ·	EFORT, OR C	THERDATA	
TYPE OF SUBMISSION	· · · · · · · · · · · · · · · · · · ·		TYPE OF ACTION		······································	
<u></u>	Acidize [Deepen	Production (Star	rt/Resume)	Water Shut-Off	
Notice of Intent	Alter Casing	Fracture Treat	Reclamation		Well Integrity	
Subsequent Report	Casing Repair	New Construction	n Recomplete		Other	
	Change Plans	Plug and Abando	n 🔲 Temporarily Al	oandon		
Final Abandonment Notice	Convert to Injection	Plug Back	Water Disposal			
Mountain States Petroleum Corp	p plans to plug and abandon th	is well in accoradan	ce with the attached pro	ocedure and well-	bore diagram.	
14. 1 hereby certify that the foregoing	is true and correct					
Name (PrintedlTyped)		Tial				
Charles Neeley		11116	Title Agent			
Signature /hnh	Huley	Date	3/8/06			
	THIS SPACE FO	R FEDERAL OR	STATE OFFICE USE			
Approved by (Signature)	Original Signed: Stephe	n Mason	Name (Printed/Typed)	Tit	le	
Conditions of approval, if any, are attached. Approval of this notice does not warrant certify that the applicant holds legal or equitable title to those rights in the subject leg which would entitle the applicant to conduct operations thereon.			Office		Date MAR 1 3 2007	

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

PLUG AND ABANDONMENT PLAN

Mountain States Petroleum Corp Hanson 21 1335' FSL & 2635' FWL Sec 6, T17N, R8W McKinley County, New Mexico

Note: All cement volumes use 50' excess inside/outside of pipe. The stabilizing well-bore fluid will be 8.3 ppg, sufficient to balance all exposed formation pressures.

- 1. Install and/or test rig anchors. Prepare flow back tank. Comply to all BLM, MSPC and contractor safety rules and regulations. Hold safety meetings each morning and on a regular basis, as needed.
- 2. MOL and RUSU. Check tubing, casing and braden head for pressures. Blow well down, kill with water if necessary. ND wellhead and NU BOP.
- 3. Unseat pump, POOH and LD rods (Note rods may be parted and/or stuck).
- 4. POH, tally & LD tubing.
- 5. Plug #1 (Lower Hospah Open Hole, Upper Hospah Perfs & Gallup Top, 1578' 1219'): Pick up & TIH with knotched collar and 2 3/8" tubing workstring to 1578' TD or as deep as possible. Load hole with water and circulate hole clean. Mix and pump 30 sxs Class B cement and spot balanced plug from 1578' 1219', cover Lower Hospah Open Hole, Upper Hospah perfs and Gallup top. POH with tubing and WOC. MIRU wireline truck. RIH with wireline and tag TOC at 1219', minimum 1269'. POOH.
- 6. PU and RIH with casing cutter for 4 ½" 9.5# casing. Freepoint and Cut off casing at 544', 50' below top of Mancos formation. POOH and rig down wireline truck. POOH, laydown casing.
- 7. Plug #2 (Csg Stub, Pt Lookout Base/Top and Surface, 594' Surface): TIH with 2 3/8" tubing to 4 ½" casing top at 544', work into casing & TIH to 594' 50' below csg top. Establish circulation with water and circulate hole clean. With tubing at 594', mix and pump Class B cement from 594' to surface (will probably take 138+- sxs), circulate good cement out surface casing. POH and LD tubing. Top off surface casing, to 3' below ground level, with cement.
- 8. ND BOP and cut off wellhead (3' below final restored ground level) and install P&A marker to BLM specifications. RD, cleanup and MOL. Cut off anchors.
- Restore location per BLM stipulations.

Mountain States Petroleum Corp

Hanson 21

South Hospah Upper & Lower Sand Oil Pools 1335' FSL & 2635' FWL Sec 6, T17N, R8W McKinley County, New Mexico

<u>Well-Bore Diagram</u> Proposed Plugging Plan

Elev: 6876' GL, 6888' KB

