In Lieu of Form 316 (June 199	0 DEPARTME	ED STATES ENT OF INTERIOR AND MANAGEMENT	FORM APPROVED Budget Bureau No. 1004-0135 ZMD Expires: March 31, 1993	
Do not u	SUNDRY NOTICE AND use this form for proposals to drill or to deepen or TO DRILL" for permi	5. Lease Designation and Serial No. NMSF-078770 6. 27 If Indian, Allottee or Tribe Name		
	SUBMIT IN T	7. If Unit or CA, Agreement Designation Rosa Unit		
1.	Type of Well Oil Well X Gas Well Other		8. Well Name and No. Rosa Unit #006C	
2	Name of Operator WILLIAMS PRODUCTION COMPANY	9. API Well No. 30-039-30181		
3	Address and Telephone No. PO Box 640 Aztec, NM 87410-0640		10. Field and Pool, or Exploratory Area BLANCO MV/BASIN DK	
4.	Location of Well (Footage, Sec., T., R., M, or Surface 755' FSL & 880' FWL/BHL 1650' F NMPM	-	11. County or Parish, State Rio Arriba, New Mexico	
	CHECK APPROPRIAT	TE BOX(s) TO INDICATE NATURE OF NOTICE, REP	ORT, OR OTHER DATA	
	TYPE OF SUBMISSION	ТҮРЕ	OF ACTION	
#	Notice of Intent X Subsequent Report Final Abandonment	Abandonment Recompletion Plugging Back Casing Repair Altering Casing X Other Multiple zone completion	Change of Plans New Construction Non-Routine Fracturing Water Shut-Off Conversion to Injection Dispose Water (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)	

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work)*

Williams Production Company, LLC. hereby requests authority to drill this as a Mesa Verde/Dakota dual as per attached plat and Operations plan.

RCVD AUG 23 '07 OIL CONS. DIV.

DIST. 3

HOLD ON FOR divectional survey

I hereby certify that the Signed Larry Higgs	foregoing is true and correct Higgin	Title <u>Drilli</u>	ing C.O.M.	Date 8-13-07	
(This space for Federal Approved by Conditions of approval	Imbolo	Title _	Petr. [<u>`</u>	Date8 20 67

Title 18 U.S.C Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction

District I 1625 N French Dr., Hobbs, NM 88240

1000 Rio Brazos Rd., Aztec, NM 87410

State of New Mexico

Energy, Minerals & Natural Resources Department

District II 1301 W. Grand Avenue, Artesia, NM B8210

OIL CONSERVATION DIVISION 1220 South St. Francis Dr. Santa Fe, NM 87505

District IV 1220 S St. Francis Dr., Santa Fe, NM 87505 ALLE ALLE

Appropriate District Office

State Lease - 4 Copies

Affect Lease - 3 Copies

AMENDED REPORT

RCVD AUG 23 '07 OIL CONS. DIV.

Submit to Appropriate District Office

Reviser Dotaber 12, 2005 Instructions on back


Form C-102

210 537

WELL LOCATION AND ACREAGE DEDICATION PLAT 30-039-30151							
'API Numbe		³Pool Name BLANCO MESAVERDE / BASIN DAKOTA					
Property Code		Property Name ROSA UNIT					
'OGRID No. 120782	•	*Operator Name WILLIAMS PRODUCTION COMPANY .					

¹⁰ Surface Location UL or lot no Section Township Plange Let Idn Feet from the North/South line Feet from the East/West line RIO 755 M 27 31N 5W SOUTH 880 WEST ARRIBA ¹¹ Bottom From Surface Hole Location Τf Different Lot Idn North/South line Feet from the UL or lot no Township Range Feet from the East/West line RIO 27 31N 5W 1650 SOUTH 2310 WEST К ARRIBA 12 Dedicated Acres ¹³ Joint or Infill ¹⁴ Consolidation Code ¹⁵ Order No 320.0 Acres - (S/2)

NO ALLOWABLE WILL BE ASSIGNED TO THIS COMPLETION UNTIL ALL INTERESTS HAVE BEEN CONSOLIDATED OR A NON-STANDARD UNIT HAS BEEN APPROVED BY THE DIVISION





WILLIAMS PRODUCTION COMPANY

Operations Plan

(Note: This procedure will be adjusted on site based upon actual conditions)

DATE:

8/10/2007

FIELD:

Basin DK/BlancoMV

WELL NAME:

Rosa #6C

SURFACE:

USFS

BH LOCATION:

NESW Sec 27-31N-5W

MINERALS:

BLM

SURF LOCATION:

SWSW Sec 27-31N-5W

Rio Arriba, NM

Rio Arriba, NM

ELEVATION:

6,782' GR

LEASE #

SF-078770

MEASURED DEPTH: 8,911'

I. I. GEOLOGY:

Surface formation - San Jose

A. FORMATION TOPS: (KB)

Name	MD	TVD	Name	MD	TVD
Ojo Alamo	3,342	2,906	Menefee	6,381	5,906
Kirtland	3,537	3,086	Point Lookout	6,576	6,101
Fruitland	3,915	3,446	Mancos	6,881	6,406
Pictured Cliffs	4,149	3,676	Gallup	7,806	7,331
Lewis	4,426	3,951	Greenhorn	8,596	8,121
Cliff House	6,336	5,861	Graneros	8,646	8,171
			Dakota	8,781	8,306
			TD	8,911	8,436

- B. MUD LOGGING PROGRAM: Mudlogger on location at 100' above Gallup SS to TD. Mudlogger to pick TD.
- C. LOGGING PROGRAM: Cased Hole Logs only.
- D. NATURAL GAUGES: Gauge any noticeable increases in gas flow. Record all gauges in Tour book and on morning reports.

II. DRILLING

- A. MUD PROGRAM: Clear water with benex to 7-5/8" casing point. Convert to a LSND mud to log and run pipe. Treat for lost circulation as necessary. Obtain 100% returns prior to cementing. Notify Engineering of any mud losses. Use air w/Air Hammer from 7-5/8in. csg.to TD.
- B. BOP TESTING: While drill pipe is in use, the pipe rams and the blind rams will be function tested once each trip. The anticipated reservoir is expected to be less than 1300 psi, so the BOPE will be tested to 250 psi (Low) for 5 minutes and 1500 psi (High) for 10 minutes. Utilize a BOPE Testing Unit with a recording chart and appropriate test plug for testing. The drum brakes will be inspected and tested each tour. All tests and inspections will be recorded in the tour book as to time and results.

III. MATERIALS

A. CASING PROGRAM:

CASING TYPE	OH SIZE (IN)	DEPTH (MD) (FT)	CASING SIZE (IN)	WEIGHT(LB)	GRADE
Surface	14 3/4	300	10 3/4	40.5	K-55
Intermediate	9 7/8	4,625	7 5/8	26.4	K-55
Longstring	6 3/4	8,911	5 1/2	17	N-80

B. FLOAT EQUIPMENT:

- 1. <u>SURFACE CASING:</u> 10 3/4" notched regular pattern guide shoe. Run (1) standard centralizer on each of the bottom (4) joints of Surface Casing.
- 2. <u>INTERMEDIATE CASING:</u> 7 5/8" cement nose guide shoe with a self-fill insert float. Place float collar one joint above the shoe. Install (1) Turbulent centralizer on each of the bottom (3) joints and one standard centralizer every (3) joints to 2,500 ft. Run (1) Turbulent centralizer at 2,700 ft., 2,500 ft., 2,300ft., 2,000ft., 1,500 ft., and 1,000 ft. (NTL-FRA 90-1).
- 3. <u>PRODUCTION LINER / CASING:</u> 5-1/2" whirler type cement nose guide shoe with a latch collar on top of 20' bottom joint. Place marker joint above 5,400'. Place centralizers as needed across selected production intervals.

C. <u>CEMENTING</u>:

(Note: Volumes may be adjusted onsite due to actual conditions)

- 1. <u>SURFACE</u>: Slurry: <u>255sx</u> (356 cu.ft.) of "Type III" + 2% CaCl₂ + ¼ # of cello-flake/sk (Yield = 1.39 cu.ft./sk, Weight = 14.5 #/gal.). The 100% excess should circulate cement to the surface. WOC 12 hours. Test csg to 1500psi.
- 2. INTERMEDIATE: Lead 820 sx (1,709) cu.ft.) of "Premium Light with 8% gel and 1/4# cello-flake/sk (Yield = 2.09 cu.ft./sk, Weight = 12.1 #/gal.). Tail 100 sx (139cu.ft.) of "Type III" with 1/4# cello-flake/sk, (Yield = 1.4 cu.ft./sk, Weight = 14.5#/gal.). Use 100% excess in Lead Slurry to circulate to surface. No excess in Tail Slurry. Total volume = 1,848 cu.ft. Bump Plug to 1,500 psi. Notify engineering if cement is not circulated to surface.
- 3. PRODUCTION CASING: 10 bbl Gelled Water space. Cement: 210 sx (440 ft³) of Premium Light HS + 1% FL-52 + .2% CD-32, 0.1% R-3, 3 #/sk CSE, ¼ #/sk cello flake and 4% Phenoseal. (Yield = 2.15 ft³/sk, Weight = 12.3 #/gal.). Displace cement at a minimum of 8 BPM. The 20% excess in slurry should cover 100 ft into intermediate casing. Total volume 440ft³. WOC 12 hours

IV. IV COMPLETION

A. CBL

1. Run Cement Bond Log across all intervals to be perforated and find Top of Cement behind all casing strings if cement not circulated to surface..

B. PRESSURE TEST

1. Pressure test 5-1/2" casing to 6000 psi max, hold at 1500 psi for 30 minutes.

C. STIMULATION

- Stimulate Dakota with approximately 10,000# of LiteProp 108TM sand in slick water..
- Isolate Dakota with a RBP.
- Stimulate Point Lookout with approximately 9300# of 14/30 LiteProp™ in slick water.
- Isolate Point Lookout with a RBP.
- 5. Perforate the Menefee/Cliff House as determined from the open hole logs.
- Stimulate with approximately 9300# of 14/30 LiteProp™ in slick water.
- Test each zone before removing bridge plugs.

D. RUNNING TUBING

- 1. Dakota: Run 2-1/16", 3.25#, J-55, IJ tubing with 1/2 mule shoe on bottom, SN with pump-out plug on top of adeem joint and 5 Seal Units. Land tubing approximately 100' below top Dakota perf.
- 2. Mesa Verde: Run 2-1/16", 2.9#, J-55, EUE tubing with a SN (1.91" ID) on top of bottom joint. Land tubing approximately 25' above the bottom Point Lookout perforations.

Gary Sizemore
Sr. Drilling Engineer

Lowy Magain