

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
OMB No 1004-0137
Expires March 31, 2007

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.

SUBMIT IN TRIPLICATE- Other instructions on reverse side.

1. Type of Well ☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator **Benson-Montin-Greer Drilling Corp.**

3a. Address
4900 College Blvd., Farmington, NM, 87402

3b. Phone No. (include area code)
505-325-8874

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
1650' FSL, 790 FEL, Sec. 28, T25N, R2W NMPM

5. Lease Serial No
NM 23039

6. If Indian, Allottee or Tribe Name

RCVD JAN 9 '08

7. If Unit or CA/Agreement, Name and/or No

OIL CONS. DIV.

8. Well Name and No

Full Sail A #2 DIST. 3

9. API Well No
30-039-23612

10. Field and Pool, or Exploratory Area
Blanco Mesaverde

11. County or Parish, State
Rio Arriba, NM

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION			
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Acidize	<input type="checkbox"/> Deepen	<input type="checkbox"/> Production (Start/Resume)	<input type="checkbox"/> Water Shut-Off
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Alter Casing	<input type="checkbox"/> Fracture Treat	<input type="checkbox"/> Reclamation	<input type="checkbox"/> Well Integrity
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> New Construction	<input type="checkbox"/> Recomplete	<input type="checkbox"/> Other
	<input type="checkbox"/> Change Plans	<input checked="" type="checkbox"/> Plug and Abandon	<input type="checkbox"/> Temporarily Abandon	
	<input type="checkbox"/> Convert to Injection	<input type="checkbox"/> Plug Back	<input type="checkbox"/> Water Disposal	

13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleat in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)

Objective is to plug and abandon wellbore.

Plug #1: Dump ball 35' cement on top of existing CIBP @ 5188' (Cliff House perforations 5223'-5228').

Plug #2: Fill inside of 5-1/2" casing with cement from 3328'-3025' (Ojo Alamo 3278'-3075').

Plug #3: Perforate @ 277', Circulate cement down 5-1/2" and up through bradenhead (Surface plug 277'-0').

Re: Letter dated December 12, 2007 requiring submission of procedure to either recompleat to Dakota or P&A. A rig is schedule to P&A this well March 1, 2008.

RECEIVED

DEC 26 2007

**Bureau of Land Management
Farmington Field Office**

14. I hereby certify that the foregoing is true and correct
Name (Printed/Typed)

Zach Stradling

Title **Engineer**

Signature

Date

12/27/2007

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Original Signed: Stephen Mason

Approved by

Title

Date

JAN 07 2008

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office

Title 18 USC, Section 1001 and Title 43 USC Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on page 2)

NMOCD

BENSON-MONTIN-GREER DRILLING
P&A Procedure

Operator: **Benson-Montin Greer**
Date: December 27, 2007
Field: Blanco Mesaverde
Contractor: Llaves Well Service
Supervisor: Ben Gonzales

Well Name: Full Sail A #2
API Number.: 30-039-23612
Location: Sec. 28, T25N, R2W
Foreman: Jaime Serna

1. MIRU. Prepare blow pit. ND wellhead, NU BOP. Kill well with water if necessary.
2. Tally out 2-7/8" tubing (83 stands).
3. Plug #1 (Cliff House perforations, (5223'-5228'). CIBP already set at 5188' (9/13/05). Dump bail 35' of cement (~5 sx) on top of CIBP. TOOH and WOC. Circulate well with water. Pressure test to 500#. If casing does not test, spot subsequent plug as necessary. TOOH.
4. Plug #2 (Ojo Alamo, 3328'-3025'). TIH open ended, mix 31 sx cement and fill inside 5-1/2" casing to cover Ojo Alamo. TOOH with tubing and WOC. TIH and tag cement. Circulate well clean with water. Pressure test casing to 500#. TOOH with tubing.
5. Plug #3 (Surface plug, 277'-0'). Perforate squeeze holes at 277'. Establish circulation out bradenhead valve. Mix and pump approximately 120 sx down 5-1/2" casing and circulate out bradenhead valve. Shut well in and WOC.
6. ND BOP and cut off casing below surface. Install P&A marker with cement to comply with regulations. RDMO, cut off anchors and restore location.

Benson-Montin-Greer Drilling Corp. Full Sail A #2 - Mesaverde - Current

Section 28 T25N R2W

API: 30-039-23612

Cliff House

Rio Arriba, NM

Lat/Long: N 36.3639/W 107.04822

Spud Date: 12/6/1984

Elev: 7251' GL, 7263' KB

FORMATION TOPS:

Ojo Alamo	3075'
Kirtland	3278'
Fruitland	3310'
Pictured Cliffs	3420'
Lewis	3502'
Cliff House	5105'
Menefee	5235'
Point Lookout	5576'
Mancos	5818'
Niobrara	6790'
Greenhorn	7636'
Graneros	7707'
Dakota	7751'

Cemented w/ 130 sx (Circ 2 bbls to surf)

SURFACE CASING RECORD:

9-5/8" 40# J-55 set @ 227'
12-1/4" hole

3rd Stage: Cemented w/ 405 sx
TOC 1700' (TS 12/27/84)

DV @ 3527'

2nd Stage: Cemented w/ 400 sx
TOC @ 4400' (CBL 8/23/02)

TUBING RECORD:

2-7/8" landed @ 5232' (1/16/03)
CIBP @ 5340' (1/16/03)

CIBP @ 5791' (8/22/02)

DV @ 5851'

1st Stage: Cemented w/ 360 sx

CIBP @ 6791' (8/22/02)

PRODUCTION CASING RECORD:

5-1/2" 15.5/17# J-55/K-55 set @ 8092'
17# surf-595', 15.5# 595'-6754', 17# 6754'-8092'
8-1/2" hole

WORKOVER HISTORY:

2/27/02: Pulled 1 joint of tubing to
retrieve broken plunger, landed SN @
6645'

PERFORATIONS: 5223'-5228'

STIMULATION: 30,000# sand, 21,589 gal
AmborMax 10/15

PERFORATIONS: 5582'-5645'

STIMULATION: 1750 gal 15% HCL, SGF w/
50,220# sand, 21,042 gal AmborMax 10/15

PERFORATIONS: 6791'-7045'

7245'-7437'

STIMULATION: SGF w/ 57,200# sand,
20# Puregel

PBTD @ 7888'

TD @ 8110'

ZAS 12/19/07

Benson-Montin-Greer Drilling Corp. Full Sail A #2 - Mesaverde - Proposed

Section 28 T25N R2W

API: 30-039-23612

Cliff House

Rio Arriba, NM

Lat/Long: N 36.3639/W 107.04822

Spud Date: 12/6/1984

Elev: 7251' GL, 7263' KB

FORM. TOPS:

Ojo Alamo	3075'
Kirtland	3278'
Fruitland	3310'
Pictured Cliffs	3420'
Lewis	3502'
Cliff House	5105'
Menefee	5235'
Point Lookout	5576'
Mancos	5818'
Niobrara	6790'
Greenhorn	7636'
Graneros	7707'
Dakota	7751'

Cemented w/ 130 sx (Circ 2 bbls to surf)

SURFACE CASING RECORD:

9-5/8" 40# J-55 set @ 227'
12-1/4" hole

Plug #3: 277'-0'

Perf @ 277'

Cement w/ 120 sx

3rd Stage: Cemented w/ 405 sx
TOC 1700' (TS 12/27/84)

Plug #2: 3328'-3025'

Cement w/ 31 sx

Cover Ojo Alamo

DV @ 3527'

2nd Stage: Cemented w/ 400 sx
TOC @ 4400' (CBL 8/23/02)

Plug #1: Dump bail 35' cement on top of CIBP (5 sx)

CIBP @ 5188' (9/13/05)

PERFORATIONS: 5223'-5228'

STIMULATION: 30,000# sand, 21,589 gal
AmborMax 10/15

CIBP @ 5340' (1/16/03)

PERFORATIONS: 5582'-5645'

CIBP @ 5791' (8/22/02)

DV @ 5851'

1st Stage: Cemented w/ 360 sx

CIBP @ 6791' (8/22/02)

PERFORATIONS: 6791'-7045'

7245'-7437'

SGF w/ 57,200# sand,

PRODUCTION CASING RECORD:

5-1/2" 15.5/17# J-55/K-55 set @ 8092'
17# surf-595', 15 5# 595'-6754', 17# 6754'-8092'
8-1/2" hole

PBSD @ 7888'

TD @ 8110'

ZAS 12/19/07

**UNITED STATES DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
FARMINGTON DISTRICT OFFICE
1235 LA PLATA HIGHWAY
FARMINGTON, NEW MEXICO 87401**

Attachment to notice of
Intention to Abandon:

Re: Permanent Abandonment
Well: 2 Full Sail

CONDITIONS OF APPROVAL

1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal and Indian Lease."
2. Farmington Office is to be notified at least 24 hours before the plugging operations commence (505) 599-8907.
3. The following modifications to your plugging program are to be made:
 - a) Bring the top of the Mesaverde plug to 5053'
 - b) Place the Pictured Cliffs/Fruitland/Kirtland/Ojo Alamo plug from 3468' - 3022'.
 - c) Place the Nacimiento plug to 1702' – 1602' inside and outside the 5 ½" casing.

You are also required to place cement excesses per 4.2 and 4.4 of the attached General Requirements.

Office Hours: 7:45 a.m. to 4:30 p.m.