

Submit 3 Copies To Appropriate District
Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
1301 W. Grand Ave., Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM
87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
May 27, 2004

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-045-32783
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. Federal Lease # 101058
7. Lease Name or Unit Agreement Name Juniper SWD; Blanco Mesa Verde
8. Well Number #4
9. OGRID Number 004838
10. Pool name or Wildcat SWD; Blanco Mesa Verde

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH
PROPOSALS)

1. Type of Well: Oil Well ☐ Gas Well ☐ Other ☒ Disposal

2. Name of Operator
Coleman Oil & Gas, Inc.

3. Address of Operator
P.O. Drawer 3337 Farmington, NM 87499

4. Well Location

Unit Letter : N : 660 feet from the South line and 2015 feet from the West line

Section 17 Township 24N Range 10W NMPM County San Juan

11. Elevation (Show whether DR, RKB, RT, GR, etc.)
6650' GR.

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐

OTHER: Step Rate Test ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐

OTHER Step rate Test ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.


Coleman Oil & Gas, Inc. would like to request permission to run a step rate test on the Juniper SWD #4 disposal well. See attached procedure. Coleman Oil & Gas, Inc. anticipates with approval to schedule the Step Rate Test within the next thirty to ninety days.

RCVD OCT 23 '08

OIL CONS. DIV.
DIST. 3

I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed and closed according to NMOCD guidelines ☐ a general permit ☐ or an (attached) alternative OCD-approved plan ☐.

SIGNATURE




TITLE: Operations Engineer DATE: October 22, 2008

Michael T. Hanson cogmhanson@sprynet.com (505) 327-0356

For State Use Only

Deputy Oil & Gas Inspector,
District #3

APPROVED BY:



TITLE

DATE

NOV 20 2008

Conditions of Approval (if any):

Coleman Oil & Gas, Inc.

Procedure Step Rate Test Blanco Mesa Verde Formation

Wednesday, October 22, 2008

Well:	Juniper SWD #4	Field:	Blanco Mesa Verde
Location:	660' FSL & 2015' FWL (SESW) Sec 17, T24N, R10W, NMPM San Juan County, New Mexico	Elevation:	6662' RKB 6650' GL
By:	Michael T. Hanson	Lease:	NMNM - 101058

Procedure: (Note: This procedure will be adjusted on site based upon actual conditions)

1. Notify NMOCD and Farmington BLM 24 hours prior to test.
2. Shut in Well 12 - 24 hours prior to test.
3. Move in and rig up slick line equipment.
4. RIH with sinker bar and tag up.
5. RIH with Electronic Pressure gauge and set @ 2815 Ft. KB (Record Time When on Bottom).
6. Set and fill five 400 Barrel frac tanks with produced water.
7. MIRU Pump Truck. Record casing and tubing pressure through out job.
MONITOR PRESSURE ON ALL CASING STRINGS - INCLUDING SURFACE CSG (BRADENHEAD)

Step Rate Test

1. Load tubing with produced water and start injection test @ 1 barrel per minute. Hold each step for 30 minutes. Increase rate in 1 BPM increments up to an estimated 12 BPM.
2. Record Pressures during each step.
3. Record the following pressure ISIP, 5, 10, 15, 20, 25, 30, 35, 40, 45, 50, 55, and 60 minute.
4. Rig down pump truck.
5. Retrieve Bottom hole pressure recorders and rig down slick line equipment.
6. Put well back on injection.