

Submit 3 Copies To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
1301 W. Grand Ave., Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
1220 S. St. Francis Dr., Santa Fe, NM  
87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
Revised March 25, 1999

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

WELL API NO. 30-045-06793
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name:  Farming C Com
8. Well No. #1
9. Pool name or Wildcat Blanco P.C. South

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
Oil Well ☐ Gas Well ☒ Other

2. Name of Operator  
Four Star Oil and Gas Company

3. Address of Operator  
P.O. Box 1289 Farmington, New Mexico 87499-1289

4. Well Location  
  
Unit Letter D : 1190 feet from the North line and 790 feet from the West line  
  
Section 2 Township 27N Range 9W NMPM San Juan County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)  
6184 GR

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

**NOTICE OF INTENTION TO:**

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

**SUBSEQUENT REPORT OF:**

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐


CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

Four Star Oil and Gas proposes to plug and abandon the subject well according to the attached procedure:

*called Ken Jackson w/changes 12-10-03*



I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Ken Jackson TITLE Regulatory Specialist DATE 12/4/03

Type or print name Ken Jackson Telephone No. (281) 561-4991

(This space for State use)  
APPROVED BY [Signature] TITLE DEPUTY OIL & GAS INSPECTOR, DIST. #3 DATE DEC - 5 2003  
Conditions of approval, if any:

**Farming "C" Com #1**  
**Proposed P & A Procedure**

- 1) Install and test rig anchors. Prepare blow pit.
- 2) MIRU. Conduct safety meeting with all personnel on location. N/U Relief line. Blow down well, and kill well with H2O if necessary. N/D Wellhead. N/U BOPE and test.
- 3) TOOH with 1 1/4" tubing. RIH w/ gauge ring to 2275'. Set CIBP @ ~~2260~~ <sup>2290 + 50' cement</sup>.
- 4) PU 2 3/8" tubing & tag CIBP @ ~~2260~~ <sup>2290 + cement to 2290</sup>. Load hole and pressure test to 500 PSI.
- 5) Plug #1 (PC Fruitland) ~~2260-2160~~ <sup>2120-2020 + 100% excess</sup>. 12 sx. POOH to 1460'. Fruitland top 2070  
plug #1 2120-2020  
+ 100% excess
- 6) Plug #2 (Kirtland) ~~1460-1360~~ <sup>+ 100% Alamo 1270 + 100% excess</sup>. 18sx. POOH to 229'. top 1320
- 7) Plug #3 (229'-Surface) Mix and Pump cement until good returns are evident. (Approximately 26sx)

ND BOPE and RD floor. Dig cellar and cut off wellhead. Top off casing strings as needed. RD and MOL. Cut off anchors and install dry hole marker. Reclaim location.