

RECEIVED
UNITED STATES
DEPARTMENT OF INTERIOR
BUREAU OF LAND MANAGEMENT
MAR 25 2010

FORM APPROVED
Budget Bureau No. 1004-0135

SUNDRY NOTICE AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir. Use APPLICATION TO DRILL for permit for such proposals

5. Lease Designation and Serial No.
SF-078766
6. If Indian, Allottee or Tribe Name
7. If Unit or CA, Agreement Designation
8920005870
8. Well Name and No.
Rosa Unit #18
9. API Well No.
30-039-07690 07960
10. Field and Pool, or Exploratory Area
BLANCO MESAVERDE
11. County or Parish, State
RIO ARRIBA, NEW MEXICO

SUBMIT IN TRIPLICATE

1. Type of Well
Oil Well ☒ Gas Well ☐ Other ☐
2. Name of Operator
WILLIAMS PRODUCTION COMPANY
3. Address and Telephone No.
PO BOX 3102 MS 25-4, TULSA, OK 74101 (918) 573-3046
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
1470' FNL, 800' FEL, SE/4 NE/4, SEC 22, T31N, R06W

CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

TYPE OF ACTION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment

- Abandonment
Recompletion
Plugging Back
Casing Repair
Altering Casing
☒ Other Commingling

- Change of Plans
New Construction
Non-Routine Fracturing
Water Shut-Off
Conversion to Injection
Dispose Water
(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Williams recommends comingling the Rosa Unit #18. We recommend comingling this well for two reasons; packer repair, and production optimization. In doing so, Williams can install an artificial lift system and produce both zones effectively.

Commingling Procedure:

1. Pull Pictured Cliffs tubing
2. Pull Mesa Verde tubing
3. Remove Production packer
4. Clean out to PBTD
5. Acid stimulate each formation if needed.
6. Complete with single string 2-3/8" tubing, landed @ 5600', below MV perfs
7. Install plunger lift system.
8. Remove one set of wellhead facilities
9. Return to production as PV/MV comingle

RCVD MAR 31 '10
OIL CONS. DIV.
DIST. 3

No DHC order

14. I hereby certify that the foregoing is true and correct

Signed

Rachel Lippert

Title Engineering Technician II

Date March 23, 2010

(This space for Federal or State office use)

Approved by

Original Signed: Stephen Mason

Title

Date

MAR 26 2010

Conditions of approval, if any:

NRCCD

04-7-10



EXPLORATION & PRODUCTION

COMMUNICATION REPAIR & COMINGLING PROCEDURE

ROSA #18
T31N, R6W, SECT. 22
ELEVATION: 6275' GR
PBTD: 5740' MD

WELLBORE STATUS:

MV 1-1/2", 2.9 #/FT EUE, To 5665' MD

PC 1-1/2", 2.9 #/FT EUE, To 3153' MD

5" BAKER MODEL D PACKER @ 4000' MD

OBJECTIVE: Remove failed packer and commingle MV and PC

1. Pull Pictured Cliffs tubing
2. Pull Mesa Verde tubing
3. Remove Production packer
4. Clean out to PBTD
5. Acid stimulate each formation if needed.
6. Run completion profiler for allocation purposes.
7. Complete with single string 2-3/8" tubing, landed @ 5600', below MV perfs
8. Install plunger lift system.
9. Remove one set of wellhead facilities
10. Return to production as PV/MV commingle

PRIOR TO PRIMARY JOB

- 1) Test rig anchors.
- 2) Verify location is OK for rig operations.
- 3) Ensure JSA, ECP's and lockout procedures are in place for the flowline and other energized piping or equipment.
- 4) Acquire 6000' of 2-3/8" N-80 or stronger work string.
- 5) Acquire ~5700' of 2-3/8", EUE, 8rd, 4.7 #/ft J-55 tubing.
- 6) Acquire wellhead and convert from dual tubing string to a single, 2-3/8" tubing string.
- 7) Acquire 2-3/8", I.D. Type X or XN type nipple.

- 8) **KCL** on location to treat kill water as needed.

SAFETY NOTICE

PERSONNEL SAFETY IS THE NUMBER ONE JOB.
NO EXCEPTIONS!!!
**PLEASE FOLLOW APPROPRIATE WILLIAMS CONTRACTOR
PROTOCOLS FOR THIS JOB PLAN**

Please see your Williams Business Representative if you have any questions; Contractor protocols can be located in the Williams E&P Contractor Guide

PRIMARY JOB

Note: Safety meetings shall be held each morning before work and subsequent "tailgate" safety meetings are to be held during the day when operation objectives shift in nature and intent (i.e. beginning/ending fishing operations, squeeze jobs, rigging down, perforating, etc.) Please ensure these are documented per section 2.2.7 of the Williams E&P Contractor Guide

1. MI and spot equipment to include fluid pumps and tanks.
2. MIRU.
3. ND/NU killing well with KCL water as necessary
4. Test the BOP's to 2500 psig minimum. If they fail, then rebuild and retest. If they cannot pass tests **DO NOT PROCEED** and notify Production Engineer.
5. Pick up on long string (MV) to determine if the long string will pull.
6. If long string will release, then POOH with short string (PC) and proceed to step # 7. If the long string will not release, proceed with sub-steps 6.1 through 6.3 below:
 - 6.1. POOH with short string one or two joints to confirm ability to move.
 - 6.2. Pick up additional joints of 1-1/2" pipe and wash to top of packer at 4000' using heavy air mist. Wash as necessary until returns clean up to approximately 1/4 cup of sand in 5 gallons of water returns.
 - 6.3. After returns clean up, POOH with pipe laying down string.
7. Spear or screw in and POOH with 1-1/2" 2.9 #/ft long string (MV) string using straight pull to pull out of Baker Model D packer seal assembly up to 40,000 #'s.
8. POOH with lay down tubing 1-1/2" 2.9# J-55 and seal assembly.
9. NU additional pipe ram for work string or replace pipe ram with annular preventer.
10. Pick up work string.

11. Pick up Baker Model D packer millover & pulling tool, using DC's and assembly as necessary and RIH on work string to mill over Baker Model D packer @ 4000' MD and RIH on work string. If work string not inspected prior to work do not exceed 70% of joint strength of the work string pipe when pulling.
12. Millover and attempt to pluck Baker Model D packer at 4000' MD. If using 4.7 #/ft work string, weight of dry string above packer is 18.8k #s. If using 6.5 #/ft work string, dry string weight will be 26k #s. When attempting to pull packer and tail pipe determine work string weight and do not pull more than 70% of joint strength.
13. POOH with packer and lay down work string, tools and packer.
14. RIH w/ work string.
15. Clean out to 5740' PBTD using a bit, scraper, and air unit package. Acid stimulate if needed.
16. TOOH w/ work string.
17. TIH with 2-3/8" production string to 2940' (+/- 150 above top PC perf @ 3088').
18. MIRU slickline
19. TIH w/ gauge ring/dummy assembly w/ to PBTD.
 - 19.1. Ensure slickline unit can run @ 30 to 150 fpm
20. Allow flow to stabilize overnight.
21. RIH w/ completion profiler and log the production intervals per ProTechnics procedures.
22. TIH w/ completion profiler and **record final wellhead pressure.**
23. TIH w/ blanking plug and set a blanking plug in the F-nipple to isolate tubing from well.
24. TOH w/ slick line and bleed tubing pressure down to zero.
25. RD slick line

Note: Only use pipe dope on the pins. Do not dope the couplings.

26. RIH w/ tubing and set @ 5600' w/ seat nipple & standing valve, testing tubing to 1000 psi every 900'. Report leaks and replace.

Note: This well should be dead and the BOP's shall be closed and locked at the end of daily operations.

27. Ensure tubing is not plugged prior to releasing the rig

28. N/D BOP's and N/U wellhead.

29. Return well to production.

30. R/D, move off location.

31. Return well to production.



Exploration & Production

Production Allocation Recommendation Rosa #18 (PC/MV)

WELLNAME: Rosa #18
LOCATION: SE/4 NE/4 Sec.22, T31N, R06W
API No.: 03-039-07960

FIELD: Rosa Blanco
COUNTY: Rio Arriba, NM
Date: March 4, 2010

Current Status: The Rosa 18 is currently a dual completion well producing from the Pictured Cliff and Mesa Verde formations. The packer assembly at 4000' has failed and repair is mandatory. Williams recommends comingling this well for two reasons; packer repair, and production optimization. A plunger lift system will be installed to help unload this well successfully.

Commingle Procedure:

1. Pull Pictured Cliffs tubing
2. Pull Mesa Verde tubing
3. Remove Production packer
4. Clean out to PBTD
5. Acid stimulate each formation if needed.
6. Complete with single string 2-3/8" tubing, landed @ 5600', below MV perfs
7. Install plunger lift system.
8. Remove one set of wellhead facilities
9. Return to production as PV/MV comingle

Allocation Method: Historical production data was gathered and analyzed. Average production was considered to calculate baseline allocations. Williams will run a completion profiler once well is comingled to re-evaluate allocation percentages.

Average production used for baseline allocation:

Total Production from well = 245 MCFD
Total Production from PC = 200 MCFD
Total Production from MV = 45 MCFD

PC allocation = PC prod / Total prod = 200 MCFD / 245 MCFD = **82%**

MV allocation = MV prod / Total prod = 45 MCFD / 245 MCFD = **18%**


WELLBORE DIAGRAM

ROSA UNIT #18 MV

Location: SE/4 NE/4 Sec. 22
T31N, R06W, Rio Arriba Co., NM

Elevation: 6275' GR
KB = 12'

<i>Tops</i>	<i>Depth</i>
Nacimiento	N/A
Ojo Alamo	2310'
Kirtland	2411'
Fruitland	2908'
Pictured Cliffs	3082'
Lewis	3475'
Cliff House	5210'
Menefee	5307'
Point Lookout	5544'



STIMULATION

PC: 3088' to 3171'

110,000# 20 / 40 in 12,180 gals of 30# X-Link gel in a 70 quality foam.

MV:

1. 50,000# of sand in 75,000 gals of water. Dropped 193 balls
2. Re-frac: 151,200 gals of water & 625 balls.

Hole Size	Casing	Cement	Volume	Top Of CMT
13 - 3/4"	9-5/8", 32.3#	175 sx	207 cu. ft.	surface
8 - 3/4"	7", 20#	200sx	347 cu. ft.	2255'(calc)
6 - 1/4"	5", 11#	150 sx	177 cu. ft.	4615'(calc)