RECEIVED

In Lieu of Form 3160 (June 1990)

UNITED STATES DEPARTMENT OF INTERIOR BUREAU OF LAND MANAGEMENT

JUL 29 2010

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

	L. C.						
Do no	SUNDRY NOTICE AND ot use this form for proposals to drill or to deepen or	ce 5. pent	Lease Designation and Serial No. NMSF-078773				
TO DRILL" for permit for such proposals				If Indian, Allottee or Tribe Name			
	SUBMIT IN T	RIPLICATE	7.	If Unit or CA, Agreement Designation Rosa Unit			
1.	Type of Well Oil Well Gas Well X Other	8.	Well Name and No. Rosa Unit #184C				
2.	Name of Operator WILLIAMS PRODUCTION COMPANY	9.	API Well No. 30-039-30143				
3.	Address and Telephone No. PO Box 640 Aztec, NM 87410-0640	10.	Field and Pool, or Exploratory Area BLANCO MV/BASIN MC/BASIN DK				
4.	Location of Well (Footage, Sec., T., R., M., or 845' FNL & 2525' FEL Sec. 34,	11.	County or Parish, State Rio Arriba, New Mexico				
	CHECK APPROPRIA	TE BOX(s) TO INDICATE NATURE OF NOTICE, F	EPORT, OR	OTHER DATA			
	TYPE OF SUBMISSION	E OF ACTIO	DN				
	V Notice of Intent	Abandanment		Change of Plane			

TYPE OF SUBMISSION

Abandonment
Recompletion
Plugging Back
Casing Repair
Altering Casing
X Other MANCOS COMPLETION

TYPE OF ACTION

Change of Plans
New Construction
Non-Routine Fracturing
Water Shut-Off
Conversion to Injection
Dispose Water
(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

The Dakota and MesaVerde formations on this well were completed in 2007. The well is presently flowing the MesaVerde and Dakota formations. At this time, Williams plans to move back on this well and complete the Mancos as per the attached procedure. After Mancos completion the formations will be commingled. Sundries for commingle authorization will be filed at a later date. Also attached is an updated plat showing all three formations.

RCVD AUG 2'10 OIL CONS. DIV. DIST. 3

14.	I hereby certify that the foregoing is true and correct	
	Signed Heather Riley	Title Regulatory Specialist Sr Date 7/29/2010
	(This space for Federal or State office use)	
	Approved by Original Signed: Stephen Mason	Title DateJUL 3 C 2010
	Conditions of approval, if any:	

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

District I 1625 N. French Dr., Hobbs, NM 88240

State of New Mexico Energy, Minerals & Natural Resources Department

1301 W. Grand Avenue, Artesia, NM 88210

Form C-102
Revised October 12, 2005
Instructions on back
Submit to Appropriate District Office
State Lease – 4 Copies
Fee Lease – 3 Copies

Certificate Number

District III 1000 Rio Brazos Rd., Aztec, NM 87410

District (IV 1220 S. St. Francis Dr., Santa Fe, NM 87505

OIL CONSERVATION DIVISION 1220 South St. Francis Dr. Santa Fe, NM 87505 AMENDED REPORT

WELL LOCATION AND ACREAGE DEDICATION PLAT												
'API Number	72319	*Pool Code *Pool Name 72319 / 71599 / 97232 BLANCO MESAVERDE / BASIN DAKOTA / BASIN MANCOS										
*Property Code	°Property Name ROSA UNIT						*Well Number 184C					
'OGRID No. 120782	*Operator Name WILLIAMS PRODUCTION COMPANY						°Elevation 6776'					
¹⁰ Surface Location												
UL or lot no. Section B 34	Township 31N	Range 5W	Lot Idn	Feet from the 845	North/South line NORTH			st line ST	County RIO ARRIBA			
		ottom	Hole L	ocation I		From Surf	ace					
UL or lot no. Section	Township	Range	Lot Idn	Feet from the	North/South line	Feet from the East/		est line	County			
12 Deducated Acres 320.0 Acres - E/2 3 Joint or Infill 4 Consolidation Code 5 Order No.												
NO ALLOWABLE WILL BE ASSIGNED TO THIS COMPLETION UNTIL ALL INTERESTS HAVE BEEN CONSOLIDATED OR A NON-STANDARD UNIT HAS BEEN APPROVED BY THE DIVISION												
2638.68 LAT: 36.86104 N LONG: 107.34926 W DATUM: NAD1983 DATUM: NAD1983 CO BC CO BC CO CO CO CO CO CO								mation contained the best of my this organization or unleased of my this organization or unleased or the second of the color of the col				

5280.001



RECOMPLETE MANCOS

ROSA UNIT #184C RIO ARRIBA, NEW MEXICO AUGUST 2010

WELLBORE STATUS:

PBTD 8395' MD 8420'

198 Jts. 2-1/16", 3.25#/ft, J-55 IJ To 6327' KB--- MESA VERDE COMPLETION

262 JTS 2-1/16", 3.25#/FT, J-55 TO 8376' KB--- DAKOTA COMPLETION

188 Jts. 5-1/2" 17# N-80 LT&C csg @ 8418'

ARROW MODEL "B" PACKER @ 6390'

Objective: Pull dual completion, Recomplete Mancos and commingle.

- 1) MIRU, kill well.
- 2) NDWH & NUBOP
- 3) TOOH w/ tubing and packer.
- 4) RIH w/ bridge plug set above Dakota.
- 5) Perf lower Mancos zone.
- 6) RIH w/ frac strg and packer.
- 7) Set packer between perf intervals.
- 8) Frac 1st stage
- 9) TOH w/ packer and frac strg
- 10) Set plug between zones and perf upper.
- 11) TIH w/ packer and frac strg set above upper zone.
- 12) frac 2nd stage
- 13) TOH w/ frac strg and packer.
- 14) Drill out bridge plugs.
- 15) TIH and land production tbg.
- 16) Return to production as commingled well.

PRIOR TO PRIMARY JOB

- 1) Have 12 Frac Tanks filled with clean fresh water with 2% KCl (may use filtered produced water for only Pad and slick water portion of frac). Add biocide while filling.
- 2) Test rig anchors.
- 3) Verify location is OK for rig operations.
- 4) Ensure JSA, ECP's and lockout procedures are in place for the flowline and other energized piping or equipment.

SAFETY NOTICE

PERSONNEL SAFETY IS THE NUMBER ONE JOB.

NO EXCEPTIONS!!!

PLEASE FOLLOW APPROPRIATE WILLIAMS CONTRACTOR PROTOCOLS FOR THIS JOB PLAN

Please see your Williams Business Representative if you have any questions; Contrator protocols can be located in the Williams E&P Contractor Guide

PROCEDURE:

Note: A safety meeting shall be held each morning before work and subsequent "tailgate" safety meetings are to be held during the day when operation objectives shift in nature and intent (i.e. beginning/ending fishing operations, squeeze jobs, rigging down, etc.) Please ensure these are documented per section 2.2.7 of the Williams E&P Contractor Guide

- 1. Spot equipment, MIRU.
- 2. Blow down well.

<u>Note:</u> Steps 2 is to be performed each day before work begins and as necessary throughout the workday (with expected departure(s) when tubing is out of the hole).

- 3. ND tree and NU BOP's (blind & pipe rams).
- 4. Test BOP's for operation and have shop test report for pressure on location.

Note: Step 4 is to be performed each time BOP stack is nippled up.

- 5. TOOH and LD prod tbg.
- 6. Remove Arrow drill permanent seal bore packer @ 6390'
- 7. After removing packer make a bit and scraper run to clean out casing.
- 8. Set CompBP above Dakota.
- 9. RU perforating company and perforate lower Mancos zone.
- 10. TIH w/ 3-1/2" N-80 Frac string tbg and Packer. Set Packer above Mancos zone.
- 11. Load annulus with water (MV was squeezed it may not hold a full column of fluid).
- 12. Load tbg w/ 2% KCl wtr.
- 13. Frac lower Mancos according to Frac company proposal.
- 14. Unseat packer and TOH
- 15. Set comp BP between zones to isolate lower Mancos
- 16. RU perforating company and perforate upper Mancos zones.
- 17. TIH with packer and frac strg set packer to isolate Mesa Verde perf's.
- 18. Frac upper Mancos according to Frac company proposal.
- 19. Unseat packer TOH.
- 20. RIH with workstring drillout CompBP.

ATTENTION

Only use pipe dope on the pins. Do not dope the couplings. If pipe dope gets on the exterior of the couplings or the pipe it should be wiped clean from the pipe or coupling. Do not use excess pipe dope and only dope the threads on the pins.

- 21. RIH w/ completion string, MU ½ mule shoe, seat nipple w/ standing valve.
- 22. Hang off tubing @ 8,376'.

Note: This well should be dead and the BOP's shall be closed and locked at the end of daily operations.

- 23. Ensure tubing is not plugged prior to releasing the rig 24. N/D BOP's and N/U wellhead.
- 25. Return well to production.
- 26. R/D, move off location.