

State of New Mexico  
Energy, Minerals and Natural Resources Department  
Oil Conservation Division

**Sundry Notices and Reports on Wells**

<b>1. Type of Well</b> OIL	<b>API # (assigned by OCD)</b> 30-031-20980
	<b>5. Lease Number</b> Fee
	<b>6. State Oil &amp; Gas Lease #</b>
<b>2. Name of Operator</b> Geo Engineering	<b>7. Lease Name/Unit Name</b> Santa Fe Pacific I
	<b>8. Well No.</b> #13
<b>3. Address &amp; Phone No. of Operator</b> P. O. Box 2966 Santa Fe, NM 87505	<b>9. Pool Name or Wildcat</b>
<b>4. Location of Well, Footage, Sec., T, R, M</b> Sec. 20, T-20-N, R-9-W, NMPM, McKinley County Unit C, 452' FNL and 2740' FEL	<b>10. Elevation:</b>

**Type of Submission**

☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment

**Type of Action**

☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other -

☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut off  
☐ Conversion to Injection

**RECEIVE**  
**R** JAN 22 1998  
**OIL CON. DI**  
**DIST. 3**

**13. Describe Proposed or Completed Operations**

A-Plus Well Service, contractor, will plug and abandon said well according to the attached procedure prepared by NMOCD.

This work will be in accordance with State of New Mexico Contract No. 98-521.25-059.

SIGNATURE William F. Clark Contractor

December 30, 1997

(This space for State Use)

Approved by Johnny Robinson Title

DEPUTY OIL & GAS INSPECTOR, DIST. #3

Date

JAN 22 1998

COMPANY

Geo Engineering

PROPERTY NAME

Santa Fe Pacific I

WELL NO.

13

DATE

LOCATION (ULSTR)

C-29-20N-09W

FOOTAGE

API NO.

POOL

2" pipe two feet above  
ground level.

## CASING RECORD:

2" casing @ 460'  
calc. T.O.C. @ 358'

350'  
calc T.O.C

460'

O.H.  
460'

COMPANY Geo Engineering		PROPERTY NAME Santa Fe Pacific I	WELL NO. 13
DATE	LOCATION (ULSTR) C-29-20N-09W	FOOTAGE	
API NO.		POOL	

2" pipe two feet above  
ground level.

CASING RECORD:

2" casing @ 460'  
calc. T.O.C. @ 358'

1. Determine depth of well
2. If depth is 300' or more continue with procedure. If not clean out csg. to 300'
3. Perf. @ 300' & 20' & est. circ. to the surf.
4. G.H. with slickline and load csg. with cement.
5. P.O.H. with slickline & pump cement down csg. & circ. cement to the surf.
6. Install dry hole marker

O.H.  
485'

350'  
calc T.O.C

460'