

(June 1990)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135

Expires: March 31, 1993

5. Lease Designation and Serial No.

CONTRACT 161

6. If Indian, Allottee or Tribe Name

JICARILLA APACHE

7. If Unit or CA, Agreement Designation

8. Well Name and No.

JICARILLA #1

9. API Well No.

30-039-20555

10. Field and Pool, or Exploratory Area

BLANCO P.C., SOUTH

11. County or Parish, State

RIO ARRIBA, NM

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.

Use "APPLICATION FOR PERMIT --" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

CONOCO INC.

3. Address and Telephone No.

10 DESTA DR. STE 100W, MIDLAND, TX. 79705 (915) 686-5400

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

SURFACE 1850' FWL & 1850' FSL, SEC. 16, T 23N, R 2W, UNIT LTR 'K', BLK. U00
TD:

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☐ Notice of Intent
☒ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

On 11-1-93 MIRU, lay blow line to pit. POOH W/ 94 jts 1 1/4' tbg.
GIH to 3118' Plug #1, from 3118' to 2077', pump 43 sx Class 'B' cmt inside 3 1/3' csg, POOH.
GIH, tag cmt @ 2170', spt 17 bbls 9# mud from 2170' to 210', POOH.
Plug #2, from 231' to Surface, pump 28sx Class 'B' inside 3 1/2' csg circulate good cmt to surface.
Cut off wellhead, install P&A marker W/ 15 sx cmt.
11-2-93 RDMO. Well has been plugged.

See attached cement summary.
Greg Vick (505) 324-5819

RECEIVED
MAR 1 5 1995
OIL

14. I hereby certify that the foregoing is true and correct

Signed

Bill R. Keathly

Bill R. Keathly
SR. REGULATORY SPECIALIST

Date 2-8-95

(This space for Federal or State office use)

Approved by

(David R. Citzler) DAVID R. CITZLER

Title

Date 3-1-95

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side

A - PLUS WELL SERVICE, INC.

P.O. BOX 1979
FARMINGTON, NM 87499
505-325 2627 • FAX: 505-325-1211

November 3, 1993

Page 1 of 1

CONOCO INC.**Jicarilla #1 (PC)****1850' FSL & 1860' FWL****Rio Arriba County, NM****Apache Jicarilla Contract #161****PLUG AND ABANDONMENT REPORT****Cementing Summary:**

Plug #1 With 43 sxs Class B cement from 3118' to 2077' inside 3-1/2" casing.

Plug #2 With 28 sxs Class B cement from 231' to surface inside 3-1/2" casing, circulate good cement to surface.

Plugging Summary:

11-1-93 Repaired rig and continued driving rig to location. Spot rig and equipment. Safety Meeting. Rig up. Lay blow line to pit; bleed well down. Pump 7 bbls down tubing to kill well. ND wellhead and NU BOP. Change rams to 1-1/4". POH with 94 joints 1-1/4" tubing. RIH with open ended tubing to 3118'. Plug #1 from 3118' to 2077' with 43 sxs Class B cement inside 3-1/2" casing. POH and WOC. Shut in well and SDFN.

11-2-93 Safety Meeting. RIH and tag cement at 2170'. POH to 2170'. Load well with water and pressure test casing to 500#, OK. Mix and spot 17 bbls 9# 50 vis mud from 2170' to 210'. POH to 231'. Plug #2 from 231' to surface with 28 sxs Class B cement inside 3-1/2" casing, circulate good cement to surface. POH and LD tubing. ND BOP and cut wellhead off; install P&A marker with 15 sxs cement. Rig down and move off location.