

Submit 3 Copies
to Appropriate
District Office

SEP 1 1995

State of New Mexico
Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CON. DIV.
CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30 - 039 - 05440
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. S - 11240
7. Lease Name or Unit Agreement Name BIGBEE
8. Well No. 1-48
9. Pool name or Wildcat ESCRITO GALLUP

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator UNIVERSAL RESOURCES CORPORATION
3. Address of Operator 1331-17TH STREET, SUITE 300, DENVER, COLORADO 80202 (303) 672-6970	4. Well Location Unit Letter <u>0</u> : <u>780</u> Feet From The <u>SOUTH</u> Line and <u>2,000</u> Feet From The <u>EAST</u> Line Section <u>16</u> Township <u>24 NORTH</u> Range <u>7 WEST</u> NMPM RIO ARRIBA County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 7,084' KB	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

IT IS OUR INTENT TO PLUG AND ABANDON THIS WELL USING THE FOLLOWING PROCEDURE:

- 1) Move on location and rig up daylight pulling unit. Nipple up relief line. Blow down well and kill with water as necessary. Nipple down wellhead and nipple up BOP. Test BOP.
- 2) Release Baker Model "D" packer and pull out of hole with 188 joints of 2-3/8" tubing (5,909'). Lay down packer. Visually inspect tubing. If necessary, lay down 2-3/8" tubing and pick up 2" workstring.
- 3) Plug #1 (Gallup perforations & top 5,988'-5,670'): Run in hole with open ended tubing to 5,983' or as deep as possible. Pump 30 barrels of water down tubing. Mix 48 sacks Class "B" cement and spot a balanced plug from 5,988' to 5,670' over Gallup perforation and top. Pull out of hole with tubing and wait on cement. While waiting on cement, pick up a 4-1/2" casing scraper or wireline gauge ring and run in hole to 3,200'. After waiting on cement, run in hole and tag cement. Pull out of hole to 3,250'. Load well with water to circulate casing clean. Pressure test casing to 500#. Pull out of hole with tubing.

CONTINUED ON BACK OF PAGE

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Jane Seiler TITLE COORDINATOR, ADMIN
EL J. GARNER DIV. OPERATIONS SUPERINTENDENT DATE 9/5/95
TELEPHONE NO. 303-672-697

(This space for State Use)

APPROVED BY Johnny Robinson TITLE STATE ENGINEER DATE 9/5/95

CONDITIONS OF APPROVAL, IF ANY:

* Not to be used in time to witness