308 Washington SE., Albuquerque, NM 87107. 1. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* 1850' FSL 790' FEL 14. PERMIT NO. 18. ELEVATIONS (Show whether DF, RT, GR, etc.) 7313' GR 16. Check Appropriate Box To Indicate Nature of Notice, Report, or O NOTICE OF INTENTION TO: SUBSEQU. 1851 WATER SHUT-OFF PULL OR ALTER CASING WATER SHUT-OFF FRACTURE TREAT MULTIPLE COMPLETE SHOOT OR ACIDIZE ABANDON* SHOOTING OR ACIDIZING (Other) (Nother) (Nother) (Nother) (Nother) (Nother) (Nother) (Thing of the completion of Recomplete or proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical nent to this work.)* 1. Establish circulation down 1-1/4" tubing and up 2-7/8"x4-1/2 (Circulate well full of cement - use 95 sks neat cement (theory or complete to top of cement at 2500'). 2. Squeeze 2-7/8"x4-1/2" annulus with 98 sks neat cement (theory or complete to top of cement at 2500'). 3. Squeeze 4-1/2"x8-5/8" annulus (bradenhead) with 30 sks neat (theoretical volume to bottom of 8-5/8" is 26 sks).	REPAIRING WELL ALTERING CASING ABANDONMENT* of multiple completion on Well tion Report and Log form.) ncluding estimated date of starting and depths for all markers and zones perti
OIL WELL WELL WOLLER OFFER OF OPERATOR Minel, Inc. 3. Address of operators Minel, Inc. 3. Address of operators A Location of well (Report location clearly and in accordance with any State requirements.* At surface 1850' FSL 790' FEL 14. PERMIT NO. 15. ELEVATIONS (Show whether DF, RT, GR. etc.) 7313' GR Check Appropriate Box To Indicate Nature of Notice, Report, or O NOTICE OF INTENTION TO: TEST WATER SHUT-OFF FRACTURE TREAT SHOOT OR ACIDIZE ABANDON* CHANGE PLANS CHANGE PLANS CHANGE PLANS CONTROL OF RECOMPLETE OTHER TO DESCRIBE PROTUSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, nent to this work.) T. DESCRIBE PROTUSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, nent to this work.) T. DESCRIBE PROTUSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, nent to this work.) T. Establish circulation down 1-1/4" tubing and up 2-7/8"x4-1/2 Circulate well full of cement - use 95 sks neat cement (theory volume 91 sks). 3. Squeeze 2-7/8"x4-1/2" annulus with 98 sks neat cement (theory volume to top of cement at 2500'). 4. Squeeze 4-1/2"x8-5/8" annulus (bradenhead) with 30 sks neat (theoretical volume to bottom of 8-5/8" is 26 sks). 5. Cut off well head and install dry hole marker.	8. FARM OR LEASE NAME E.A. Stevie Joe 9. WELL NO. 10. FIELD AND POOL, OR WILDCAT Tapacito Pictured Cliff 11. SEC., T., E., M., OR BLK. AND SURVEY OR AREA Sec 6, T25N, R3W NMPM 12. COUNTY OR PARISH 13. STATE RIO Arriba NM ther Data ENT REPORT OF: REPAIRING WELL ALTERING CASING ABANDONMENT* of multiple completion on Well tion Report and Log form.) ncluding estimated date of starting and depths for all markers and zones perti
Minel, Inc. 308 Washington SE., Albuquerque, NM 87107 4. Location of well (Report location clearly and in accordance with any State requirements.* 308 Washington SE., Albuquerque, NM 87107 4. Location of well (Report location clearly and in accordance with any State requirements.* 308 Washington SE., Albuquerque, NM 87107 4. Location of well (Report location clearly and in accordance with any State requirements.* 308 Washington SE., Albuquerque, NM 87107 4. Location of well (Report location clearly and in accordance with any State requirements.* 308 Washington SE., Albuquerque, NM 87107 4. Location of well (Report location clearly and in accordance with any State requirements.* 308 Washington SE., Albuquerque, NM 87107 4. Sec also space 17 below. 308 Washington SE., Albuquerque, NM 87107 3707 3713' GR 37313' GR 3718 Water shut-off Water shut-off Practice Treatment of Notice, Report, or Ontice of Intention to Subseque Water Shut-off Practice Treatment Shoot on According Continue of According Continue of According Continue Continue of Recomple Completion of Recomple Completion of Recomple Completion of Recomple Proposed work, if well is directionally drilled, give subsurface locations and measured and true vertical ment to this work, if well is directionally drilled, give subsurface locations and measured and true vertical ment to this work, if well is directionally drilled, give subsurface locations and measured and true vertical ment to this work, if well is directionally drilled, give subsurface locations and measured and true vertical ment to this work, if well is directionally drilled, give subsurface locations and measured and true vertical ment to this work, if well is directionally drilled, give subsurface locations and measured and true vertical ment to this work, if well is directionally drilled, give subsurface locations and measured and true vertical ment to this work, if well is directionally drilled, give subsurface locations and measured and true vertical ment to this work, if well	Stevie Joe 9. WELL NO. 10. FIELD AND POOL, OR WILDCAT Tapacito Pictured Cliff 11. SEC., T., E., M., OR BLE. AND SURVEY OR AREA Sec 6, T25N, R3W NMPM 12. COUNTY OR PARISH 13. STATE Rio Arriba NM ther Data Charling Casing ABANDONMENT* of multiple completion on Well tion Report and Log form.) ncluding estimated date of starting and depths for all markers and zones perti
308 Washington SE., Albuquerque, NM 87107. 1. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* 1850' FSL 790' FEL 14. PERMIT NO. 18. ELEVATIONS (Show whether DF, RT, GR, etc.) 7313' GR 16. Check Appropriate Box To Indicate Nature of Notice, Report, or O NOTICE OF INTENTION TO: SUBSEQU. 1851 WATER SHUT-OFF PULL OR ALTER CASING WATER SHUT-OFF FRACTURE TREAT MULTIPLE COMPLETE SHOOT OR ACIDIZE ABANDON* SHOOTING OR ACIDIZING (Other) (Nother) (Nother) (Nother) (Nother) (Nother) (Nother) (Thing of the completion of Recomplete or proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical nent to this work.)* 1. Establish circulation down 1-1/4" tubing and up 2-7/8"x4-1/2 (Circulate well full of cement - use 95 sks neat cement (theory or complete to top of cement at 2500'). 2. Squeeze 2-7/8"x4-1/2" annulus with 98 sks neat cement (theory or complete to top of cement at 2500'). 3. Squeeze 4-1/2"x8-5/8" annulus (bradenhead) with 30 sks neat (theoretical volume to bottom of 8-5/8" is 26 sks).	Tapacito Pictured Cliff 10. FIELD AND POOL, OR WILDCAT Tapacito Pictured Cliff 11. SEC., T., E., M., OR BLE. AND SURVEY OR AREA Sec 6, T25N, R3W NMPM 12. COUNTY OR PARISH 13. STATE RIO Arriba NM ther Data ENT REPORT OF: REPAIRING WELL ALTERING CASING ABANDONMENT* of multiple completion on Well tion Report and Log form.) ncluding estimated date of starting and depths for all markers and zones perti
308 Washington SE., Albuquerque, NM 87107 4. Location of well (Report location clearly and in accordance with any State requirements.* 1850' FSL 790' FEL 14. PERMIT NO.	Tapacito Pictured Cliff 11. SEC., T., E., M., OR BLE. AND SURVEY OR AREA Sec 6, T25N, R3W NMPM 12. COUNTY OR PARISH 13. STATE Rio Arriba NM ther Data STATE REPORT OF: REPAIRING WELL ALTERING CASING ABANDONMENT* of multiple completion on Well tion Report and Log form.) Including estimated date of starting and depths for all markers and zones perticular.
18. Check Appropriate Box To Indicate Nature of Notice, Report, or O NOTICE OF INTENTION TO: TEST WATER SHUT-OFF PULL OR ALTER CASING WATER SHUT-OFF PRACTURE TREATMENT SHOOT OR ACIDIZE ABANDON* REPAIR WELL CHANGE PLANS (Other) (Other) T. DESCRIBE TROUSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give subsurface locations and measured and true vertical ment to this work.) If well is directionally drilled, give subsurface locations and measured and true vertical volume 91 sks). 3. Squeeze 2-7/8"x4-1/2" annulus with 98 sks neat cement (theory volume to top of cement at 2500'). 4. Squeeze 4-1/2"x8-5/8" annulus (bradenhead) with 30 sks neat (theoretical volume to bottom of 8-5/8" is 26 sks). 5. Cut off well head and install dry hole marker.	Tapacito Pictured Cliff 11. SEC., T., E., M., OR BLK. AND SURVEY OR AREA Sec 6, T25N, R3W NMPM 12. COUNTY OR PARISH 13. STATE RIO Arriba NM ther Data ENT REPORT OF: REPAIRING WELL ALTERING CASING ABANDONMENT* of multiple completion on Well tion Report and Log form.) ncluding estimated date of starting and depths for all markers and zones perticular.
1850' FSL 790' FEL 14. PERMIT NO. 15. ELEVATIONS (Show whether DF. RT. GR. etc.) 7313' GR 16. Check Appropriate Box To Indicate Nature of Notice, Report, or O NOTICE OF INTENTION TO: SUBBEQUION TEST WATER SHUT-OFF PULL OR ALTER CASING WATER SHUT-OFF PRACTURE TREAT MULTIPLE COMPLETE FRACTURE TREATMENT SHOOT OR ACIDIZE ABANDON* X SHOOTING OR ACIDIZING (Other) (Note: Report results Completion or Recomple (Other) (Note: Report results Completion or Recomplement to this work.)* 17. DESCRIBE PROPUSED OR COMPLETED OPERATIONS (Clearly State all pertinent details, and give pertinent dates, proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical nent to this work.)* 18. Establish circulation down 1-1/4" tubing and up 2-7/8"x4-1/2 Circulate well full of cement - use 95 sks neat cement (theory volume 91 sks). 19. Squeeze 2-7/8"x4-1/2" annulus with 98 sks neat cement (theory volume to top of cement at 2500'). 20. Squeeze 4-1/2"x8-5/8" annulus (bradenhead) with 30 sks neat (theoretical volume to bottom of 8-5/8" is 26 sks). 21. Cut off well head and install dry hole marker.	Tapacito Pictured Cliff 11. SEC., T., E., M., OR BLK. AND SURVEY OR AREA Sec 6, T25N, R3W NMPM 12. COUNTY OR PARISH 13. STATE RIO Arriba NM ther Data ENT REPORT OF: REPAIRING WELL ALTERING CASING ABANDONMENT* of multiple completion on Well tion Report and Log form.) ncluding estimated date of starting and depths for all markers and zones perticular.
16. Check Appropriate Box To Indicate Nature of Notice, Report, or O NOTICE OF INTENTION TO: TEST WATER SHUT-OFF FRACTURE TREAT SHOOT OR ACIDIZE REPAIR WELL (Other) 7. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical nent to this work.) It is proposed to plug and abandon this well as follows: 1. Establish circulation down 1-1/4" tubing and up 2-7/8"x4-1/2 2. Circulate well full of cement – use 95 sks neat cement (theory volume 91 sks). 3. Squeeze 2-7/8"x4-1/2" annulus with 98 sks neat cement (theory volume to top of cement at 2500'). 4. Squeeze 4-1/2"x8-5/8" annulus (bradenhead) with 30 sks neat (theoretical volume to bottom of 8-5/8" is 26 sks). 5. Cut off well head and install dry hole marker.	SEC., T., E., M., OR BLK. AND SURVEY OR AREA Sec 6, T25N, R3W NMPM 12. COUNTY OR PARISH 13. STATE RIO ATTIBA NM ther Data ENT REPORT OF: REPAIRING WELL ALTERING CASING ABANDONMENT* of multiple completion on Well tion Report and Log form.) ncluding estimated date of starting and depths for all markers and zones perti
Check Appropriate Box To Indicate Nature of Notice, Report, or O NOTICE OF INTENTION TO: TEST WATER SHUT-OFF FRACTURE TREAT SHOOT OR ACIDIZE ABANDON* CHANGE PLANS (Other) T. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, proposed work, if well is directionally drilled, give subsurface locations and measured and true vertical nent to this work.) It is proposed to plug and abandon this well as follows: 1. Establish circulation down 1-1/4" tubing and up 2-7/8"x4-1/2 Circulate well full of cement - use 95 sks neat cement (theory volume 91 sks). 3. Squeeze 2-7/8"x4-1/2" annulus with 98 sks neat cement (theory volume to top of cement at 2500'). 4. Squeeze 4-1/2"x8-5/8" annulus (bradenhead) with 30 sks neat (theoretical volume to bottom of 8-5/8" is 26 sks). 5. Cut off well head and install dry hole marker.	RIO Arriba NM ther Data SIT REPORT OF: REPAIRING WELL ALTERING CASING ABANDONMENT* of multiple completion on Well tion Report and Log form.) ncluding estimated date of starting and depths for all markers and zones perti
Check Appropriate Box To Indicate Nature of Notice, Report, or O NOTICE OF INTENTION TO: TEST WATER SHUT-OFF FRACTURE TREAT SHOOT OR ACIDIZE ABANDON* CHANGE PLANS (Other) T. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, proposed work, if well is directionally drilled, give subsurface locations and measured and true vertical nent to this work.) It is proposed to plug and abandon this well as follows: 1. Establish circulation down 1-1/4" tubing and up 2-7/8"x4-1/2 Circulate well full of cement - use 95 sks neat cement (theory volume 91 sks). 3. Squeeze 2-7/8"x4-1/2" annulus with 98 sks neat cement (theory volume to top of cement at 2500'). 4. Squeeze 4-1/2"x8-5/8" annulus (bradenhead) with 30 sks neat (theoretical volume to bottom of 8-5/8" is 26 sks). 5. Cut off well head and install dry hole marker.	Rio Arriba NM ther Data ENT REPORT OF: REPAIRING WELL ALTERING CASING ABANDONMENT* of multiple completion on Well tion Report and Log form.) ncluding estimated date of starting and depths for all markers and zones perti
Check Appropriate Box To Indicase Nature of Notice, Report, or O NOTICE OF INTENTION TO: SUBSEQUE TEST WATER SHUT-OFF PRACTURE TREAT SHOOT OR ACIDIZE REPAIR WELL (Other) T. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical nent to this work.) It is proposed to plug and abandon this well as follows: 1. Establish circulation down 1-1/4" tubing and up 2-7/8"x4-1/2 2. Circulate well full of cement – use 95 sks neat cement (theory volume 91 sks). 3. Squeeze 2-7/8"x4-1/2" annulus with 98 sks neat cement (theory volume to top of cement at 2500'). 4. Squeeze 4-1/2"x8-5/8" annulus (bradenhead) with 30 sks neat (theoretical volume to bottom of 8-5/8" is 26 sks). 5. Cut off well head and install dry hole marker.	ther Data ENT REPORT OF: REPAIRING WELL ALTERING CASING ABANDONMENT* of multiple completion on Well tion Report and Log form.) ncluding estimated date of starting and depths for all markers and zones perti
NOTICE OF INTENTION TO: SUBSEQUE TEST WATER SHUT-OFF PRACTURE TREAT SHOOT OR ACIDIZE REPAIR WELL (Other) 7. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical nent to this work.)* It is proposed to plug and abandon this well as follows: 1. Establish circulation down 1-1/4" tubing and up 2-7/8"x4-1/2 2. Circulate well full of cement - use 95 sks neat cement (theory volume 91 sks). 3. Squeeze 2-7/8"x4-1/2" annulus with 98 sks neat cement (theory volume to top of cement at 2500'). 4. Squeeze 4-1/2"x8-5/8" annulus (bradenhead) with 30 sks neat (theoretical volume to bottom of 8-5/8" is 26 sks). 5. Cut off well head and install dry hole marker.	REPAIRING WELL ALTERING CASING ABANDONMENT* of multiple completion on Well tion Report and Log form.) ncluding estimated date of starting and depths for all markers and zones perti
TEST WATER SHUT-OFF FRACTURE TREAT SHOOT OR ACIDIZE REPAIR WELL (Other) 7. DESCRIBE PROPOSED OR COMPLETE OPERATIONS (Clearly state all pertinent details, and give pertinent dates, proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical nent to this work.) It is proposed to plug and abandon this well as follows: 1. Establish circulation down 1-1/4" tubing and up 2-7/8"x4-1/2 2. Circulate well full of cement – use 95 sks neat cement (theory volume 91 sks). 3. Squeeze 2-7/8"x4-1/2" annulus with 98 sks neat cement (theory volume to top of cement at 2500'). 4. Squeeze 4-1/2"x8-5/8" annulus (bradenhead) with 30 sks neat (theoretical volume to bottom of 8-5/8" is 26 sks). 5. Cut off well head and install dry hole marker.	ALTERING WELL ALTERING CASING ABANDONMENT* of multiple completion on Well tion Report and Log form.) ncluding estimated date of starting and depths for all markers and zones perti
FRACTURE TREAT SHOOT OR ACIDIZE REPAIR WELL (Other) 7. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical nent to this work.) It is proposed to plug and abandon this well as follows: 1. Establish circulation down 1-1/4" tubing and up 2-7/8"x4-1/2 2. Circulate well full of cement - use 95 sks neat cement (theory volume 91 sks). 3. Squeeze 2-7/8"x4-1/2" annulus with 98 sks neat cement (theory volume to top of cement at 2500'). 4. Squeeze 4-1/2"x8-5/8" annulus (bradenhead) with 30 sks neat (theoretical volume to bottom of 8-5/8" is 26 sks). 5. Cut off well head and install dry hole marker.	ALTERING CASING ABANDONMENT* of multiple completion on Well tion Report and Log form.) ncluding estimated date of starting and depths for all markers and zones perti
SHOOT OR ACIDIZE REPAIR WELL (Other)	of multiple completion on Welltion Report and Log form.) ncluding estimated date of starting and depths for all markers and zones perti
(Other) (Other) (Other) (Other) (Other) (Other) (Note: Report results Completion or Recompletion or Recompletion or Recompletion or Recompletion of Reco	of multiple completion on Welltion Report and Log form.) ncluding estimated date of starting and depths for all markers and zones perti
(Other) (Note: Report results Completion or Recompletion or Recompletion or Recompletion or Recompletion of R	ncluding estimated date of starting and depths for all markers and zones perti
7. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical nent to this work.)* It is proposed to plug and abandon this well as follows: 1. Establish circulation down 1-1/4" tubing and up 2-7/8"x4-1/2 2. Circulate well full of cement - use 95 sks neat cement (theory volume 91 sks). 3. Squeeze 2-7/8"x4-1/2" annulus with 98 sks neat cement (theory volume to top of cement at 2500'). 4. Squeeze 4-1/2"x8-5/8" annulus (bradenhead) with 30 sks neat (theoretical volume to bottom of 8-5/8" is 26 sks). 5. Cut off well head and install dry hole marker.	ncluding estimated date of starting and depths for all markers and zones perti
Agent: L.O. Van Ryan 207 W. 38th	
Farmington, NM 87401	
Ph. No. (505) 325-8900	· · · · · · · · · · · · · · · · · · ·
3. I hereby certify that the foregoing is true and correct	APPEND !
SIGNED Van Lyan TITLE Agent	ратв 7-12-89
(This space for Federal or State office use)	III O A secon
APPROVED BY	JUL 2 0 1999
CONDITIONS OF APPROVAL, IF ANY:	Your Townsand
*See Instructions on Reverse Side	A CONTRACTOR
itle 18 U.S.C. Section 1001, makes it a crime for any person knowingly and withit is make to	FARMULE, A RADA (CE ALEA)

BURFAU OF LAND MANAGEMENT 1235 La Plata Highway Farmington, New Mexico 87401 Phone (505) 327-5344

Attachment to Notice of

Re: Permanent Abandonment

Intention to Abandon

Well: 4 Stevie Joe

CONDITIONS OF APPROVAL

1. Plugging operations authorized are subject to the attached "General Require-ments for Permanent Abandonment of Wells on Federal Leases."

- 2. Mark Kelly with the Farmington Office is to be notified at least 24 hours before the plugging operations commence (505) 327-5344.
- 3. Blowout prevention equipment is required.
- 4. The following modifications to your plugging program are to be made (when applicable):

Office Hours: 7:45 a.m. to 4:30 p.m.

GENERAL REQUIREMENTS FOR PERMANENT ABANDONMENT OF WELLS ON FEDERAL AND INDIAN LEASES FARMINGTON RESOURCE AREA

- 1. Secure prior approval either on a Sundry Notice (Form 3160-5) or verbally from the Fluids Drilling & Production Section at this office before changing the approved plugging program.
- 2. Plugging equipment used shall have separate mixing and displacement pumps and a calibrated tank to assure proper displacement of plugs. The Operator is responsible for providing all measuring devices needed to assure proper measurement of materials being used.
- 3. A proper tank or pit will be used to contain all fluids pumped from the well during plugging operations. Unattended pits are to be fenced.
- 4. All cement plugs are to be placed through tubing (or drillpipe) and shall be a minimum of 100 feet in length with 50% excess inside casing or 100% excess when plug is set in open hole or squeezed into perforations. 15.6#/gal slurry weight is to be used when using class B neat cement or when CaCl₂ is used. Use the recommended slurry weight of other type cements when they are used (Class C, Pozzolan etc.).
- 5. Any cement plugs placed when well is not full of fluid, or when well may be taking fluid, (i.e. across perfs-unless bridge plug or retainer is used, across bad csg., or fresh water formations) will be tagged (touched) after cement has set to verify proper location.
 - 5a. Testing The first plug below the surface plug shall generally be tested by either tagging the plug with the working pipe string, or pressuring to a minimum pump (surface) pressure of 1000 psig, with no more than a 10 percent drop during a 15-minute period (cased hole only). If the integrity of any other plug is questioned, it must be tested in the same manner. Also, any cement plug which is the only isolating medium for a fresh water interval or a zone containing a valuable mineral deposit should be tested by tagging with the drill string.
- 6. Mud must be placed between plugs. Plugging mud is to be made up with a minimum of 15 lbs/bbl of sodium bentonite, and a nonfermenting polymer.

 Minimum consistency of plugging mud must be 9 lbs/gal and with a minimum viscosity of 50 sec/qt. Fresh water is to be utilized for mixing mud.
- 7. Following the placement of a cement plug, the withdrawl rate for at least the length of the cement plug shall not exceed 30 ft/min, in order to minimize the contamination of the plug.

- 8. Within 30 days after plugging work is completed, file a Sundry Notice (Subsequent Report of Abandonment, Form 3160-5), in quintuplicate with Area Manager, Bureau of Land Management, 1235 La Plata Highway, Farmington, NM 87401. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. Show date well was plugged.
- 9. All permanently abandoned wells are to be marked with a regulation marker (4" pipe extending 4' above the ground line) containing the information as specified in 43 CFR 3162.6(d). Unless otherwise approved.
- 10. After plugging work is completed the surface is to be rehabilitated in accord with instructions from the Fluids Surface Management Section of the Farmington Resource Area Office.

All above are minimum requirements. The period of liability under the bond of record will not be terminated until the lease is inspected and surface work approved.

Please advise this office when the well location is ready for final inspection.

Failure to comply with the above conditions of approval may result in an assessment for noncompliance and/or a Shut-in Order being issued pursuant to 43 CFR 3163.1.

You are further advised that any instructions, orders or decisions issued by the Bureau of Land Management are subject to administrative review pursuant to 43 CFR 3165.3 and appeal pursuant to 43 CFR 3165.4 and 43 CFR 4.700.